




Wireless Headset (RZ04-0379)

IMPORTANT PRODUCT INFORMATION GUIDE

WHAT'S INSIDE / WHAT'S NEEDED


WHAT'S INSIDE

- Wireless Headset (RZ04-0379)




- A. Type-C charging port
- B. 3.5 mm audio + mic jack
- C. Status indicator
- D. Power button
- E. Volume control wheel
- F. Mic mute button
- G. Adjustable padded headband
- H. Ultra-soft leatherette memory foam ear cushions
- I. Razer SmartSwitch button


- Type-C wireless dongle




- Type-C charging cable



- Type-A to Type-C adapter cable



- 3.5 mm combo cable



- Important Product Information Guide

WHAT'S NEEDED

PRODUCT REQUIREMENTS

- [Wireless] Devices with Bluetooth audio capability / USB Type-C or Type-A port
- [Wired] 3.5 mm audio + mic combined jack

RAZER SYNAPSE REQUIREMENTS

- Windows® 10 64-bit (or higher)
- Internet connection for software installation


RAZER AUDIO APP REQUIREMENTS

- iOS 12 / Android 8.1 Oreo (or higher) device with Bluetooth connectivity
- Internet connection for app installation

! *Compatible with Android / PC / PS4 / PS5 / Switch (wired and wireless) and Xbox (wired). Although compatible with most Android devices, earlier models may not fully support wireless USB-C audio. For a comprehensive list of compatible devices, please visit support.razer.com*

LET'S GET YOU COVERED

You've got a great device in your hands, complete with a 2-year limited warranty coverage. Now maximize its potential and score exclusive Razer benefits by registering at razerid.razer.com





Got a question? Ask the Razer Support Team at support.razer.com

GETTING STARTED

CHARGING YOUR HEADSET

Connect your Wireless Headset to a powered USB Type-A port using the charging cable. For best results, please fully charge your headset before using it for the first time. A depleted unit will fully charge in about 3 hours.




Indicator	Battery level
	Fully charged
	Charging


CONNECTING TO YOUR DEVICES

A. Via Type-C wireless dongle (2.4 GHz)


1. Plug the Type-C wireless dongle into your device.



2. Press and hold the Power button until the status indicator is briefly lit.



3. Wait until the status indicator briefly becomes static green indicating that the headset is now connected to the Type-C wireless dongle.



Indicator	Battery level
●	Connected

4. On your device (if applicable), set the Wireless Headset as the default **Input** and **Output Device**.

On PC / Laptop

- a. Right-click on the sound icon on the system tray and then select **Open Sound settings**.
- b. On the Sound window, set Wireless Headset 2.4 as the default **Output** and **Input** device.

On PlayStation 5, go to Settings > Sound


- On **Microphone**, set the **Input Device** to Wireless Headset 2.4.
- On **Audio Output**, set the **Output Device** to Wireless Headset 2.4.

On PlayStation 4, go to Settings > Devices > Audio Devices

- Set the **Input Device** and **Output Device** to Wireless Headset 2.4.

B. Via Bluetooth


While powered on, press the Razer SmartSwitch button for 5 seconds to activate Bluetooth pairing mode. Follow your device's instructions and select "Wireless Headset (BT)" from the list of found devices. The status indicator will briefly change to static blue to indicate that the headset is now paired with your device.



Indicator	Status
●	Pairing
●	Paired

C. Via 3.5 mm audio + mic jack

If your device has a 3.5 mm audio + mic combined jack, plug the 3.5 mm combo cable from your headset's microphone jack into your device's audio jack.



RAZER SMARTSWITCH

With the Wireless Headset connected to your PC or console (via Type-C wireless dongle) and a mobile device (via Bluetooth), you'll be able to manage calls from your mobile device even while gaming. The status indicator will briefly show static white to indicate that the headset is connected to both audio sources.

PERSONALIZE YOUR EXPERIENCE

Razer Audio app (Mobile)


Making advanced customization just got a whole lot easier for the Wireless Headset. With the Razer Audio App, you'll be able to customize its EQ settings and auto shutoff feature, enable or disable gaming mode, and much more — anytime, anywhere.



Razer Audio



OR



RZR.TO/AUDAPP

(For China only)

i When using the app, make sure that the headset is only connected to your mobile device via Bluetooth. A solid blue status indicator indicates this connection.

Razer Synapse (PC)

Use the Razer Synapse* app to select from any of the headset's EQ presets or customize your own, enhance sound and mic settings, enable and adjust real-time mic monitoring, and other headset features for a phenomenal audio experience that's genuinely yours.

*Install Razer Synapse when prompted or download the installer from razer.com/synapse.

Activate THX Spatial Audio*

Unleash the full potential of your Wireless Headset by enabling 360° positional audio for a natural and lifelike experience through Razer Synapse.




**Only available on Windows 10 64-bit and above*

USING YOUR HEADSET

BATTERY LEVEL

When unplugged and powered on, the status indicator will show the connection and battery status. While in use, you'll hear a voice prompt when the headset needs to be recharged; during such time, the indicator will continue showing the battery level until you charge the headset.




Indicator	Prompt	Battery level
	Voice	Low

POWER BUTTON

Power ON / OFF

Power on the headset by holding the Power button until the status indicator is on, and holding the Power button again to turn off. An audio prompt will help notify you when the headset is powered on or off.



Other functions

Other power button functions are available when the headset is powered on with Bluetooth as the audio source. These functions operate based on your device's current activity and may not apply to certain devices.


	Play/pause*
Single press	Accept incoming call or end current call
	Put call on-hold and accept incoming call
	End call and swap to on-hold call
Double press	Reject incoming call
	Swap calls
	Skip track
Triple press	Previous track
While powered off, press and hold for 5 seconds	Activate Bluetooth pairing mode

**You can also use this function when using the Type-C wireless dongle as an audio source.*

RAZER SMARTSWITCH BUTTON

Switching audio source


When powered on and connected to any audio source, double press the Razer SmartSwitch button to switch between Type-C wireless dongle and Bluetooth audio source or vice versa.



i Using Bluetooth as the audio source will reconnect the headset to the last known device. Pairing mode will be activated if no device is found.

Enabling / Disabling Gaming Mode


While connected via Bluetooth, triple press the Razer SmartSwitch button, then hold the last press for 2 seconds to activate Gaming Mode. Once enabled, the headset will function at a lower latency; giving you real-time audio feedback while gaming. Repeat to disable gaming mode,



i This feature is only available on Bluetooth connection. For best performance, keeping the headset within a very close distance of the audio source is recommended.


VOLUME WHEEL

Rotate the Volume wheel to increase or decrease the volume.




MUTING / UNMUTING THE MICROPHONE

Press the mic mute button to mute or unmute the microphone.



EXTENDING YOUR HEADSET'S LIFESPAN

We recommend stretching the headset gently apart before placing them over your head to minimize headband stress. However, please avoid overstressing the headset beyond its technical limits.



SAFETY AND MAINTENANCE

SAFETY GUIDELINES

In order to achieve maximum safety while using your Wireless Headset, we suggest that you adopt the following guidelines:

Should you have trouble operating the device properly and troubleshooting does not work, unplug the device and contact the Razer hotline or go to support.razer.com for assistance.

Do not take apart the device (doing so will void your warranty) and do not attempt to operate it under abnormal current loads.

Keep the device away from liquid, humidity or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, unplug and/or switch off the device in order to let the temperature stabilize to an optimal level.

The device isolates external ambient sounds even at low volumes, resulting in lowered awareness of your external surroundings. Please remove the device when engaging in any activities that requires active awareness of your surroundings.

Listening to excessively loud volumes over extended periods of time can damage your hearing. Furthermore, legislation of certain countries permits a maximum sound level of 86db to affect your

hearing for 8 hours a day. We therefore recommend that you reduce the volume to a comfortable level when listening for prolonged periods of time. Please, take good care of your hearing.

MAINTENANCE AND USE

The Wireless Headset requires minimum maintenance to keep it in optimum condition. Once a month we recommend you clean the device using a soft cloth or cotton swab to prevent dirt buildup. Do not use soap or harsh cleaning agents.

BATTERY WARNING

The Wireless Headset contains a Li-ion rechargeable battery. In general, the life expectancy of such batteries is dependent upon usage. If you suspect that the Li-ion rechargeable battery inside the Wireless Headset may be drained (has a low charge), try charging it.

Caution: Do not open, mutilate, or expose to conducting materials (metal), moisture, liquid, fire, or heat. Doing so may cause batteries to leak or explode, resulting in personal injury. Battery life varies with usage.

LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2022 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, and "For Gamers. By Gamers." are trademarks or registered trademarks of Razer Inc. and/or affiliated companies in the United States or other countries. All other trademarks are the property of their respective owners.

Android, Google, Google Logo, Google Play, and the Google Play logo are trademarks of Google LLC.

Apple, the Apple logo, and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by Razer is under license.

"PlayStation", "PS4", and "PS5" are registered trademarks of Sony Interactive Entertainment Inc.

Windows and the Windows logo are trademarks or registered trademarks of the Microsoft group of companies.

Razer Inc. ("Razer") may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent or other intellectual property right. The Wireless Headset (the "Product") may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit razer.com/warranty.

LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer's liability exceed the retail purchase price of the Product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to

try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RADIATION EXPOSURE STATEMENT

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC

RF Rules. This equipment must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers

must be provide with antenna installation instructions and consider removing the no-collocation statement.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

this device may not cause harmful interference, and

this device must accept any interference received, including interference that may cause undesired operation.

Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Canada Statement

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement

économique Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

CANADA SAR

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed

and operated with a minimum distance of 0mm between the radiator and your body. Cet émetteur
ne doit pas être Co-place ou ne fonctionnant

en même temps qu'aucune autre antenne ou émetteur. Cet équipement devrait être installé et
actionné avec une distance minimum de 0mm
entre le radiateur et votre corps.

NOTICE FOR CANADA

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

CANADIAN CLASS B STATEMENT: This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as

set out in the radio interference regulations of Industry Canada.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les

limites applicables aux appareils numériques de Classe B

prescrites dans le règlement sur le brouillage radioélectrique édicté par Industrie Canada.



STATEMENT OF COMPLIANCE WITH EU DIRECTIVE

ENGLISH

STATEMENT OF COMPLIANCE WITH EU DIRECTIVE

Razer (Europe) GmbH, declares that this Razer Barracuda (Wireless Headset: RZ04-0379 and USB Wireless Transceiver: RC30-0378) is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU & 2015/863/EU.

[Wireless Headset]

Radio Frequency: 2.4GHz SRD/Bluetooth/BLE

Frequency Band: 2402MHz to 2480MHz

RF Power: <16dBm

Software/Firmware: V1.0

[USB Wireless Transceiver]

Radio Frequency: 2.4GHz SRD

Frequency Band: 2402MHz to 2480MHz

RF Power: <16dBm

Software/Firmware: V1.0

The full Declaration of Conformity is accessible via the following:

Internet address: www.razer.com/legal/compliance



Li-ion

This equipment is for home use, and has acquired electromagnetic conformity registration, so it can be used not only in residential areas, but also other areas.



EU PRODUCT AND BATTERY DISPOSAL INFORMATION

BATTERY INFO

Risk of fire or explosion or defeat the safeguard of equipment if the battery is replaced by an incorrect type. Replace only with the same or equivalent type. Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion. High or low extreme temperatures or low air pressure at high altitude that the battery can be subjected to during use, storage or transportation. Leaving the battery in an extremely high temperature and/or low air pressure surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.

BATTERY WARNING

The Razer Barracuda contains a Li-ion rechargeable battery. In general, the life expectancy of such batteries is dependent upon usage. If you suspect that the Li-ion rechargeable battery inside the Razer Barracuda may be drained (has a low charge), try charging it. Caution: Do not open, mutilate, or expose to conducting materials (metal), moisture, liquid, fire, or heat. Doing so may cause batteries to leak or explode, resulting in personal injury. Battery life varies with usage.

The elements of the instructional safeguard shall be as follows:



- element 1a: the symbol , IEC 60417-6044 (2011-01)
- element 2: "High sound pressure" or equivalent wording
- element 3: "Hearing damage risk" or equivalent wording
- element 4: "Do not listen at high volume levels for long periods." or equivalent wording