

# Instruction

## About battery


The wireless mouse uses one AA Alkaline battery.

## Installing battery into the Mouse

**Step 1. Remove the battery compartment cover under the mouse.**

**Step 2. Insert the battery in the 2.4GHz wireless mouse.**

**Step 3. Replace the cover**



Battery receiver  
compartment cover

## Connecting the receiver

The receiver is connected to your computer USB port.

## Power Function

1. Push the ON/OFF switch to OFF and turn off the mouse to save the electricity.
2. Push the ON/OFF switch to ON, the mouse will turn on and catch the code automatically.



OFF/ON



## Switch DPI

→ Press the button to switch the DIP from 800 / 1200/ 1600

### FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.