

Dragon Models Ltd.

Micro X Tech 90-Day Limited Warranty

Radio Control Vehicle and Transmitter

Dragon Models Limited. (the "Guarantor") warrants this Radio Control Vehicle and Transmitter (the "Product") to be free from defects in material and workmanship for a period of ninety (90) days from the date of purchase to the buyer other than for the purpose of resale. Guarantor will repair or replace the product if any such defect should appear within the period of the warranty. This warranty shall apply only if the product fails to function properly under normal use. The warranty will not be granted if, in the opinion of Dragon Models Ltd., the defect or malfunction was caused by accident, abuse and misuse, neglect or improper modification.

Service Procedure: If a defect covered by this warranty should appear within 90 days, it should be returned to the place of purchase for inspection. The buyer is responsible for returning the product properly packaged in its original container or an equivalent.

Not Covered Under Warranty: If the product is found to have been misused or abused, it will not be covered by this warranty, and you will be advised. You will also be advised of the cost of the repair if you desire it. If the product is sent without a dated sale receipt, this may result in the product not being covered by our warranty. This warranty does not cover any claim concerning worn or defective batteries, or damages caused to your unit from defective batteries.

The Guarantor's sole and exclusive liability for defects in material and workmanship shall be limited to repair or replacement at our customer service department and we shall not be liable for incidental, consequential, or contingent damages.

Customer Service Department

For assistance and queries, please contact

Customer Information

1. If vehicle receives interference from other electrical / electronic items, move the vehicle away from such equipment.
2. Always insert batteries in the transmitter and charger noting the correct polarity.
3. Turn the switch OFF and remove batteries from the charger after use.
4. Never run the vehicle in crowded areas, near or toward people or animals, to prevent property damage and / or personal injury.
5. Small and sharp parts included. Keep out of reach of children.
6. Never run your vehicle on roads or streets, as it could endanger traffic.
7. DO NOT disassemble the kit or it may cause damage.
8. To avoid breakdowns, DO NOT run the vehicle on sandy, wet or dusty terrain.
9. DO NOT drop the vehicle from heights.
10. Storage in humid or hot places may deform the vehicle or cause damage / malfunction.

CAUTION: Only use supplied charger with this toy. DO NOT use any other charging source.

Safety Tips

- Keep fingers and hair away from the vehicle if the vehicle or transmitter is switched ON.
- Adult supervision is recommended when this vehicle is being operated.
- Never drive your vehicle on the streets as it may endanger ongoing traffic.

Battery Performance Tips

- For best vehicle performance, the use of alkaline batteries for the charger is recommended. Battery life may vary depending on battery brand.
- The vehicle is powered by Nickel-Metal Hydride (NiMH) rechargeable battery technology, which has no special procedures or precautions for disposal. However, you should dispose of your battery pack in an environmentally responsible and considerate manner as with all products.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC ID : S3GDML65501001

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



MICRO•TECH


1/35 Palm Top R/C

How To Place the Figure

Pull out the steering wheel with care as shown

Place the figure on the seat

Push the steering wheel back into the steering pole




How To Charge Jeep



Open charger battery cover with a Philips head screw driver

Insert 4 x AAA size batteries

Close battery cover



(Remark: Please make sure the power switch of Jeep is OFF when charging)



Use the specified cable to connect the charger and Jeep

Turn on the power switch of the charger

Red LED will light up


Red LED will turn off when the Jeep is fully charged

How to Adjust the Steering Knob

Adjust steering by rotating the steering knob bit by bit

After adjustment, place your Jeep on the ground and take it for a spin



Simply repeat these steps until you get the best steering action



How To Install the Battery

Open controller battery cover with a Philips head screw driver

Insert 2 x AA size batteries



How To Switch On


Turn on the power switch of controller as shown

and red LED will light up, indicating that the power is "ON".

Remove the antenna cap and fully extend it.

Turn on the power switch of Jeep

How To Control The Jeep



DRAGON

Caution: DO NOT drop the Jeep from heights and play with care.
This Jeep is a precision product.