



CiNETREK



USER GUIDE

2.4Ghz Head Phone



2.4Ghz Head Phone

Copyright

© Copyright 2004 All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of our company. All brand and product names are trademarks and/or registered trademarks of their respective holders.

Disclaimer

We make no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties, merchantability or fitness for any particular purpose. Any software described in this manual is sold or licensed "as is". Should the programs prove defective following their purchase, the buyer (and not our company., its distributor, or its dealer) assumes the entire cost of all necessary servicing, repair, and any incidental or consequential damages resulting from any defect in the software. Further, we reserve the right to revise this publication and to make changes from time to time in the contents hereof without obligation to notify any person of such revision or changes.


Federal Communications Commission (FCC) Statement

This equipment has been tested and found to comply with the limits for a class B device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician help.

FCC Warning

Changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



CLASS 1 LASER PRODUCT
APPAREIL A LASER DE CLASSE 1
LASER KLASSE 1
LOUKAN 1 LASERLAITE
PRODUIT LASER
CATEGORIE 1

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

INFORMATION TO USER:

The users manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Wireless Headset (Optional)

To avoid interference noises from outer environment, you may put on the wireless headset to enjoy your favorite movie or music.



Turn ON the Headphone by toggle between ON/OFF.



Turn ON the wireless output on the player by pressing the Adjust Key for several times.

Casque audio sans fil (Optionnel)

Afin d'éviter les bruits parasites causés par l'environnement extérieur, vous pouvez porter le casque audio sans fil pour pouvoir profiter confortablement de votre film ou de votre musique préféré.



Mettez le casque audio en MARCHE en agissant sur le bouton MARCHE/ARRÊT.



Activez la sortie sans fil du lecteur en appuyant sur la touche Ajuster plusieurs fois.

Drahtloser Kopfsprechhörer (Optional)

Um Störgeräusche von Außen zu umgehen, können Sie den drahtlosen Kopfsprechhörer aufsetzen und Filme oder Musik nach Ihrer Wahl genießen.

1



Schalten Sie den Kopfhörer EIN durch Schalten von EIN/AUS.

2



Schalten Sie die drahtlose Ausgabe des Players EIN, indem Sie mehrmals die Einstelltaste drücken.

Specification (English)

Supply Voltage	2.4 VDC
Current Consumption	130mA (Typical)
Operating Temperature	-10℃ ~ +60℃
Frequency Band	2410 MHz
Modulation	FSK
Channel Number	1
Channel Spacing	9MHz
Channel Frequency	2410 MHz
Frequency Stability	+/- 100KHz
RX Sensitivity	-85 dBm
Headphone Impedance	24 Ohm
Output Power	2m WRMS
Response	20~20KHz, -3dB
Dynamic Range	92 dB (Typ.)
Separation	80 dB (Typ.)
SN Ratio	87 dB (Typ.)
THD	0.1 % (Typ.)