

# User manual




**Oblanc**


**Bluetooth  
Stereo Headphones**

[www.OBLANC.com](http://www.OBLANC.com)

## ⦿ Headphone Configuration




## ⦿ Functions Briefing




Step 1

When the headphone is off, push and hold the MFB for **5** or more seconds until the LED flashes Blue and Red, ignore the Power-on beep. Choose Oblanc from your phone or mobile device. Enter "0000" for PIN. A beep will indicate a connection has been established. The LED will turn to Blue and flash slowly.




Push and hold the MFB for **3** seconds to turn the headphone on. Push and hold for **5** or more seconds to turn the headphone off. (The Red LED will light up before shutting down)

## Step 2




Push +Vol and Vol- buttons for volume control.  
Push and hold for previous / next track.

## Step 3




When listening to music, Push the MFB to answer incoming calls. push again to end the call. Push the MFB twice to redial the last call. Pushing and hold for **3** seconds will activate voice dailing.

## Step 4



To charge the headphone, connect the device to a USB port with the mini USB cable provided. The Red LED will remain lit when charging.(About 2 hours for a full charge.)

## Step 5



Emergency recovery switch. Use a pointed object to insert into the hole. This will shutdown the headphone, and return the headphone to the manufacturer's default mode.

## Step 6

## **SCOPE OF THE WARRANTY**

Subject to legal provisions, the responsibility of OBLANC under this warranty is limited to the provisions set out below: OBLANC warrants that this product is safe from material and manufacturing defects under normal conditions of use for a period of TWO (2) YEARS from the date of end-user purchase. If a product defect is encountered within the warranty period and a valid claim is lodged, OBLANC will replace the product with either a new complete unit or with a new accessory if the default found is limited to an ancillary product. When a product or an accessory is replaced, it becomes the property of the buyer and the product or accessory exchanged becomes the property of OBLANC. The warranty accorded to the exchanged product will not exceed the original warranty.

## **EXCLUSIONS AND LIMITATIONS**

This limited warranty applies only to hardware products manufactured by or on behalf of OBLANC which can be identified by the trademark, trade name or OBLANC logo which is affixed on them. The software distributed by OBLANC without or under the trade name OBLANC (including, but not limited to, system software) is not covered by this limited warranty. Kindly refer to the accompanying software license agreement accompanying the software for details of your rights concerning its use. OBLANC does not warranty that the operation of the product will be uninterrupted or error-free. OBLANC is not liable for damage resulting from noncompliance with usage guidelines of the product.

This warranty does not apply to: (a) any damage caused by the use of products other than those in the OBLANC recommended usage guidelines (b) any damage caused by accident, abuse, misuse, flooding, fire, earthquake or other external causes, (c) any damage caused by the operation of the product outside the foreseeable and permitted usage guidelines issued by OBLANC (d) any damage caused by any intervention (including upgrades and extensions) by any person who is not a representative of OBLANC or a OBLANC-approved service provider (e) a product or a component which has been tampered with so that it significantly alters the functionality or capabilities without the written permission of OBLANC (f) consumable items such as batteries, unless the damage is caused by a material or workmanship defect (g) a product on which any OBLANC-related serial number has been removed or defaced.

FCC ID: S98NCX3

IC: 10847A-NCX3

Model: NC2-3

Do not make any changes or modifications to the equipment unless otherwise specified in the instructions. If such changes or modifications should be made, you could be required to stop operation of the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with RSS-210 of the Industry Canada Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Cet appareil est conforme à la section 15 des règles FCC. Le fonctionnement de l'appareil est soumis aux deux conditions ci-dessous : (1) cet appareil ne peut provoquer aucune interférence nuisible et (2) cet appareil doit accepter toute interférence reçue, y compris les interférences susceptibles de provoquer un fonctionnement indésirable.

Cet appareil est conforme à la norme RSS-210 de la réglementation d'Industrie Canada. Le fonctionnement de l'appareil est soumis aux deux conditions ci-dessous : (1) cet appareil ne peut provoquer aucune interférence nuisible et (2) cet appareil doit accepter toute interférence reçue, y compris les interférences susceptibles de provoquer un fonctionnement indésirable.