

# Bluetooth Sound Bar User's Manual


We Concentrate on perfect sound pursuit...

Thank you for using our product, please see the instruction manual carefully before use!

一、 Function Overview: the optical fiber,AUX, Bluetooth, FM,


The clock, EQ.

二、 Panel buttons



- 1、 ----- The standby switch;
- 2、 VOL+----- The volume increase;
- 3、 VOL- ----- The volume decreases;
- 4、 SOURCE----- The audio signal source conversion
- 5、 MUTE----- The amplifier mute.

### 三、The remote control



1、

- （电源符号） ----- The standby switch;
- 2、VOL+----- The volume increase;
- 3、VOL- ----- The volume decreases;
- 4、SOURCE----- The audio signal source conversion
- 5、MUTE----- The amplifier mute.
- 6、CH+----- RREV channel OF FM MODE
- 7、CH- -----NEXT channel OF FM MODE
- 8、TREBLE+ ----- The TREBLE volume increase;
- 9、TERBLE- ----- The TREBLE volume decreases
- 10、BASS+ ----- The BASS volume increase
- 11、BASS- ----- The BASS volume decreases
- 12、MEM ----- Memory FM radio
- 13、TIMER----- Set the time
- 14、CLOCK----- set The clock
- 15、SLEEP----- set the sleep
- 16、TUNE (◀◀ or ▶▶) ---TUNE FM RADIO In the FM mode;(p REV or next)  
In the bluetooth mode.
- 17、EQ-----EQ mode :CLASSICAL, ROCK,POP,JAZZ(IN “NO EQ MODE” IS “FLAT “(According to NOR)

### 四、INPUT & OUTPUT terminal diagram

SW OUT    R - AUX - L    .OPT IN

- 1、SW OUT-----IS SUBWOOWFER OUTPUT
- 2、R-AUX-L -----IS AUX (R channel & L channel) OUTPUT
- 3、OPT IN-----IS optical fiber INPUT

## 五、Operation

## 六、Technical parameters

- 1、RMS: 15W\*2+60W
- 2、S/N:  $\geq 75$ dB
- 3、Frequency Effect: 60Hz-18KHz
- 4、AC IN: AC100V-240V 50/60HZ.

## 七、Accessories

- 1、a soundbar +a subwoofer
- 2、a set of User's Manual (Attached warranty card)
- 3、a (RCA plug \*2 TO RCA plug \*2) audio input wiring
- 4、a remote control(Attached 3V buttoncell CR2025)

## 八、warranty card

## FCC Information and Copyright

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates,

uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference

to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator& your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.