

RC Blazer

INSTRUCTION MANUAL

BATTERY INSTALLATION

- Set the “ON-OFF” switch at the bottom of the vehicle to “OFF” position before inserting batteries.
- Unscrew and open the battery compartment cover to inset batteries in the vehicle as shown in the diagram on this packaging. Make sure all batteries are at correct polarity.
- Close the cover and tighten the screws.

VEHICLE OPERATION

- Turn the “ON-OFF” switch at the bottom of the vehicle to “ON” position and the vehicle will be idling.
- Press the right button with the upward arrow, and then the vehicle will go forward.
- Release the button, and then the vehicle will stop.
- Press the left button on the transmitter with the downward arrow, then the vehicle will go backward and turn.

INFORMATION TO USER

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio / TV technician for help.