



VISUAL LAND
Bring the World Home

Prestige

android tablet

Guide Book

Copyright © 2014 Visual Land Inc. All rights reserved.

Google, Android, Gmail, Google Maps, Chrome, Chromecast, Android Wear, Nexus, Google Play, YouTube, Google+, and other trademarks are property of Google Inc. A list of Google trademarks is available at <http://www.google.com/permissions/trademark/our-trademarks.html>. All other marks and trademarks are properties of their respective owners.

This book introduces Android 5.0, Lollipop for Google Play edition devices. Its content may differ in some details from some of the products described or the software that runs on them. All information provided here is subject to change without notice.


For best results, make sure you're running the latest Android system update. To find your device's version number or check for the latest system update, go to  **Settings > System > About tablet** and look for **Android version** or **System updates**

Table of contents

1	Welcome to Android	1
	About Android 5.0, Lollipop	1
	Android Wear	2
	Set up your device	2
	Make yourself at home	3
	Send an email	4
	Status bar	3
	Quick Settings	3
	Manage battery life	4
	Get around	5
	Navigation buttons	5
	Menus	6
	Organize your Home screens	7
	Touch & type	9
	Android version & updates	10

2	Essentials	00
	Google Now	00
	How it works	01
	Try it	02
	What you can ask Google to do for you	03
	Turn “Ok Google” on or off	03
	Display	03
	Sound and notification	04
	Manage accounts on your device	06
	Add an account	06
	Remove an account	07
	Share your device with other users	08
	Switch users	1/
	Remove a user	1/
	Guest user	1/
	Security	10
	Smart Lock	10
	Protect against harmful apps	11
	Chromecast	12
	File storage	13
	Screenshots	14

3	Use the keyboard	15
	Enter & edit text	15
	Use next-word suggestions	18
	Gesture Typing	2/
	Keyboard dictionaries	20
	Type by speaking	20
4	Try some apps	22
	All Apps	22
	Gmail	23
	Google Play	25
	Camera	26
	Photos	3/
	Contacts	30
	Hangouts	31
	Calendar	31
5	Settings	33
6	Accessibility	35

Welcome to Android

About Android 5.0, Lollipop

Android 5.0, Lollipop is the latest version of Android, the operating system that powers not just tablets, but also wearables, TVs, and even cars.

Android 5.0 features a bold and bright new design, 3D graphics support that are as good as on a desktop computer, and great new features that make your tablet work for you:

- Add guest users and other users without providing them access to your email, contacts, and whatever else you don't want to share.
- Set priorities for notifications and see them when your tablet is locked.
- Easier ways to manage battery usage, including a battery saver feature to extend battery life.
- More ways to secure your tablet.

Android Wear

Android Wear watches from other manufacturers connect your tablet to your wrist. Pause, play, and skip music tracks or quickly respond to text messages using only your watch. Android Wear organizes your information, suggests what you need, and shows it to you before you even ask. Get messages from your friends, meeting notifications, and weather updates at a glance.

Set up your device

When you first turn on your tablet, you'll see a Welcome screen. Choose the language you want and touch the arrow to continue.



IMPORTANT: To complete the setup process, it's best to have a Wi-Fi connection.

When prompted, sign in with your Google Account or create one at that time. Signing in lets you immediately access everything associated with your Google Account, like Gmail. If you prefer, you can skip this step and create an account later.

An email address that you use for any of the following counts as a Google Account:

- Gmail
- YouTube
- Google Play
- Google Apps
- AdWords
- Any other Google product

Signing in with a Google Account helps you get up and running quickly. When you sign in, you can easily get all the apps you've purchased on Google Play onto your new device. All the email, contacts, calendar events, and other data associated with that account are automatically synced with your device.

If you have multiple Google Accounts, you can add others later from  **Settings > Personal > Accounts**. You can also add guest users in  **Settings > Device > Users**.

Make yourself at home



After you finish setting up your device, the Home screen appears for the first time. Here, you can add app icons and widgets (an “at-a-glance” view of an app’s most important information) to your Home screens to easily find them.

- To move between Home screens, swipe left or right.
- To see notifications, swipe down from the top of the screen with one finger.

Send an email



Use the Gmail app to read and write email from your Gmail or other email addresses.




1. Touch  Gmail on a Home or  All Apps screen.
2. If you already signed into a Gmail account during setup, your email will be synced to your device. Otherwise, add an email address now.

Status bar

The status bar is at the very top of the screen. On the right, you can see the Wi-Fi and mobile signal strength, how much battery power is left, and the time. On the left, you can see which apps have sent you notifications. See [“Sound & notification” on page 19](#).

Quick Settings

Use Quick Settings to easily get to frequently used settings, like turning on airplane mode. To open Quick Settings, swipe down from the top of the screen with two fingers or twice with one finger. To change a setting, just touch the icon:

- **Wi-Fi network:**  Turn Wi-Fi on or off. To open Wi-Fi settings, touch the Wi-Fi network name.
- **Bluetooth settings:**  Turn Bluetooth on or off. To open Bluetooth settings, touch the word “Bluetooth”.
- **Airplane mode:**  Turn airplane mode on or off. Airplane mode means your tablet won't connect to Wi-Fi or a cell signal, even if one is available.

- **Display brightness:** ⚙️ Slide to lower or increase the brightness of your screen.
- **Auto-rotate:** 🔄 Lock your device's orientation in portrait or landscape mode.

Quick Settings look like this:



Open the main Settings app by touching **Settings** in the top right.

You can also turn Auto Rotate on or off from Quick Settings, to lock or unlock automatic screen rotation.


Manage battery life

The status bar shows how much battery you have left, but you can also see the exact percentage and approximate time of battery life remaining. Swipe down from the top of the screen, then touch **Battery**.

Your Android device's battery is built to get you through your day. When you're running low, Android's battery saver conserves your battery power so you can still make calls and send SMS (text) messages. To turn it on, go to **Settings > Battery > Battery saver**. For more information, visit [Manage battery life](#).

Get around

At the bottom of every Home screen you'll find the Favorites tray: another quick way to get to your apps.



To open an app, touch it. To drag an app in or out of the Favorites tray or anywhere else on a Home screen, touch & hold it, then move it with your finger where you want it.

Navigation buttons

At the bottom of most tablet screens, no matter what you're doing, you'll always find the navigation bar with three buttons.



Back

Opens the previous screen you were working in, even if it was in a different app. Once you back up to the Home screen, you can't go back any further.



Home

Opens the central Home screen. To open Google Now, swipe up.




Overview

Opens a list of thumbnail images of screens you've worked with recently. To open one, touch it. To remove a screen from the list, swipe it left or right or touch on the X.

Some apps hide these buttons temporarily, or fade them to small dots in the same position. To bring them back, touch the dots, touch the screen in the middle, or swipe up from the bottom.


Menus

Many screens in Apps and in Settings include a  **Menu** icon at the top right of the screen. Touch it to explore additional options, including Help and Settings.


Organize your Home screens

- To change your wallpaper, add a widget, adjust Search settings, or change screen order, touch & hold the background of any Home screen.
- You can have any number of Home screens to the right. To add a new screen, swipe to the rightmost screen and drag an app or widget to the right edge.
- The screen to the left of the main Home screen is reserved for Google Now, and is available only when Google Now is turned on.
- To create a folder, slide one icon quickly on top of another.
- To name or rename a folder, open it and touch its name.

To change the wallpaper:

1. Touch & hold the background, then touch  Wallpapers.
2. Swipe right to left to choose a wallpaper image. Or choose an image from your Photos, Downloads or Drive.

To add an app icon to a Home screen:

1. Go to the Home screen where you want to place the app.
2. Touch  All Apps.
3. Swipe from right to left, if necessary, to find the app you want.
4. Touch & hold the app until the Home screen appears, slide it into place, and lift your finger.

To add a widget:

1. Touch & hold the background, then touch Widgets. Open **All Apps > Widgets**.
2. Swipe right to choose a widget, which provides a quick view or way to access information on your home screen, like a larger size clock or a view of information in your Google Play library.

To move an app or widget to another position:

1. Touch & hold the icon.
2. Slide your finger to the new position.
To move between Home screens, slide toward the edge of the screen.
To bump another icon out of the way, slide slowly into it.
3. Lift your finger.

Touch & type


To select or activate something, touch it.

To type something, such as a name, password, or search terms, just touch where you want to type. A keyboard pops up that lets you type into the field.


Other common gestures include:

- **Touch & hold.** To select an item, touch & hold it by not lifting your finger until something happens. This is how you access accent and other special characters on the keyboard. Slide your finger to the accented letter you need.
- **Touch, hold, & drag.** Touch & hold an item for a moment and then, without lifting your finger, move your finger on the screen until you reach the target position. You can move apps around on the Home screen.
- **Swipe or slide.** Quickly move your finger across the surface of the screen, without pausing when you first touch (so you don't drag something instead). Slide a Home screen left or right to view the other Home screens.
- **Double-tap.** Tap quickly twice on a map or image to zoom in and out.
- **Scale.** In some apps (such as Maps, Chrome, and Photos), you can scale by placing two or more fingers on the screen at once

and pinching them together (to enlarge scale) or spreading them apart (to reduce it).

- **Rotate the screen.** The orientation of most screens rotates with your device as you turn it. To keep your screen locked in Portrait mode, swipe down with two fingers from the top of any screen and touch  Portrait/Auto-Rotate in Quick Settings.

Android version & updates

To check your version number or get the latest system update, first go to  **Settings > System > About tablet.**

Then look for these labels:

- **System updates.** Touch to check whether you have any pending system updates.
- **Android version.** Look partway down the list for this heading and the number just below it.


2

Essentials

Google Now

Google Now is about getting you just the right information, at just the right time. It tells you today's weather before you start your day, how much traffic to expect before you leave for work, and even your favorite team's score while they're playing.

For example, here's a Google Now card that appears when you're about to start your commute:




After you start using Google Now, you don't need to do anything else. If you like, you can fine-tune some settings, but Google Now doesn't need any elaborate setup.

How it works

To know when to show information you'll find useful, Google Now uses contextual data from your device and from other Google products, plus data from third-party products that you allow Google Now to access. For example, if you have an appointment in Google Calendar that includes an address, Google Now can check traffic and suggest when to leave.

When you decide to use Google Now, you're also turning on Location Reporting and Location History:


- **Location Reporting** allows Google to periodically store and use your device's most recent location data in connection with your Google Account. Location Reporting is a per-device setting.
- **Location History** allows Google to store a history of your location data from all devices where you're logged into your Google Account and have turned on Location Reporting.

You can control how Google Now uses your current location. To view the relevant settings, go to  **Settings > Personal > Location**. When location services are turned on for your account on a given device, certain apps can use them to give you more relevant information, such as nearby restaurants or commute traffic.

To learn more about how Google Now uses your location and other information, visit [f nnf kd-bnl .mv](#) .

Try it






You have a chance to turn on Google Now when you first set up your device. You can also turn it on or off at any time:

1. Touch & hold any empty space on your Home screen.
2. Go to  **Settings > Google Now**.

To open Google Now, swipe up from the Home button. Updates appear in the form of Google Now cards. When you don't need a card anymore, swipe it from left to right. Swiping from right to left returns you to the main Home screen.

When you want to see more cards, touch **More** at the bottom of the screen.

To adjust the way certain cards get updated:

- Manage reminders: From the  **Menu** at the top left of the screen, touch  Reminders.
- Request updates for your sports teams, stocks, and more: From the  **Menu**, touch  Customize.
- Customize other updates: At the top right of each card, touch the  three dots.