



MAGNO WIRELESS FOOT CONTROL
(MAGNO WFC) MANUAL

**Broadcast Developments Limited
t/a Autoscript Ltd
Unit 2
Heathlands Close
Twickenham, Middlesex
TW1 4BP
UK**

MAGNO WIRELESS FOOT CONTROL (MAGNO WFC)


BATTERY

Fit the battery as shown below:



ANTENNA: Screw the antenna onto the thread on side of unit

NB: Only use the supplied Antenna



SELECT FREQUENCY:

Select the required RF frequency. This must match the frequency that is set on the receiver unit.

Valid channels are 0 to D selectable on the frequency selector switch. These correspond to 902.3625 MHz for channel 0 to 902.6875 MHz for channel D (25 KHz channel spacing). The unit should be switched off and back on for the new frequency selection to be updated. Positions E and F of the switch are not used.

SCROLL CONTROLS:

The main scroll control is the foot-operated left-hand half of the top of the unit, car accelerator style. This provides proportional control of the scroll speed depending on how far the pedal is depressed.

The button on the right hand section of the top of the unit provided proportional reverse control of the scroll speed.

LOW BATTERY LED:

When the battery voltage drops to below 6.2 volts, the LED on the top of the unit will start flashing whenever one of the scroll controls is operated.

FCC STATEMENT:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This

equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device might not cause harmful interference, and (2) this device must accept any interference received, including interference that might cause undesired operation.

IMPORTANT

Changes or modifications not expressly approved by Autoscript Ltd could void the user's authority to operate the equipment.