



Before your first use, please make sure the power is fully charged with included AC adapter & cable.




### LED Status





#### Charging LED/Battery Status

Blue LED on	Fully charged
Red LED on	Charging in progress
Red LED flashes	Low-battery alert




1

Turn on the terminal. Tap the app icon  -> "About watch" -> "Certification information" to find more certification information.



2

### Appearance



3

### Quick Settings

#### Power Key:

1. When the terminal is power off, hold down the Power key for 3 seconds to switch the terminal on.
2. When the terminal is power on, briefly press the Power key to lock the screen.

#### User-defined Key:

1. The user-defined key will be set as "Home Key" by default.
2. Reset the user-defined key: Go to "Quick Setting" -> "Key Map", then set the parameters per your needs.

#### Touch the Screen:

1. Back to the previous page: Swipe inward from the left or right edge of the screen.
2. Back to the desktop: Swipe the screen from bottom to top.
3. Switch to the new task: Swipe the screen from bottom to top, then hold on until the recently used apps display.

4

1. Do not charge in a hot or humid environment. The low environment temperature will affect the charging efficiency.
2. The terminal is with a built-in battery, please do not replace it by yourself to avoid damage.
3. Do not use the terminal's wireless functionalities where wireless device use is prohibited or where it may cause interference or danger, such as in mines, gas stations.
4. Only use the dry soft cloth to clean the terminal. Cleaning it with a wet cloth or benzene/thinner/other volatile chemicals may deform and shorten the service life of the keypad and shell of the terminal.
5. The environment temperature should not be too low or too high, otherwise, it could cause malfunction. Please use the terminal under the permitted temperature.
6. If the terminal is damaged due to a drop from a high place or water, please contact the after-sales service center. Do not repair it by yourself.
7. Operations in the 5.15-5.25GHz band are restricted to indoor usage only.



R 007-AL0170

5.0 GHz(W52,W53):Indoor Use Only

5


### Support information



For more information, please visit the Newland website at <http://www.newlandaidc.com>

PN:1060090617

7



## NLS-WD1 Quick Start

V1.0

FCC ID:SL9NLS-WD1

6