



TC605 AN/AW

Handheld mobile computer

User's Manual

Version. 0 2024/02/05

About This Manual

Thank you for purchasing the iMozen TC605 Enterprise Mobile Computer. This manual explains how to install, operate and maintain our product. No part of this publication may be reproduced or used in any form, or by any electrical or mechanical means, such as photocopying, recording, or information storage and retrieval systems, without permission in writing received from iMozen. The material in this manual is subject to change without prior notice.

Regulatory

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference with radio communications. However, there is no guarantee that interference will not occur in a particular installation.

Signal Interference from TV or Radio

Data transmission or reception may fail or be affected by signal interference from nearby TV or radio devices.

Bluetooth Precautions

This device is designed based on standard Bluetooth specifications, but the following factors may affect the range and reception of Bluetooth signals:

- Obstacles such as walls, metal objects, human bodies, or other barriers between Bluetooth devices and the connected devices.
- Devices operating on the 2.4 GHz frequency spectrum (such as wireless LAN, cordless phones, microwaves, etc.) placed near the operating device.
- When using Bluetooth devices other than mobile phones (such as TVs, laptops, etc.), audio quality may be influenced by the specifications and performance of the device.

General Safety Precautions

Please read this User Manual thoroughly before using this device. Use only the components and accessories supplied by the manufacturer. Do not attempt to disassemble the TC605, as it does not contain parts that can be repaired by the user. Any tampering will void the warranty. When replacing the battery pack or at the end of life of the TC605, disposal must be performed in compliance with the laws of your jurisdiction.



Laser Safety

Do not stare into the beam of the laser light from this device. The TC605 uses an Imager Aiming System with a laser light that is visible to the human eye and is emitted from the scan window at the top of the device.



Hearing Safety

Do not listen to earphones at high volume levels to prevent the possibility of hearing damage.

Body-worn Operation Safety

This device was tested for typical body-worn operations. A minimum separation distance must be maintained between the user's body and the handset, including the antenna: 0.5 cm to comply with the RF exposure requirements in Europe. Third-party belt-clips, holsters and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided.

Important Notices and Precautions

The manufacturer has made safety the first priority during the design stage. To avoid potential mishaps, please observe the following notices:

- ❗ Do not stock this device under high temperature conditions that may cause the battery to overheat.
- ❗ Do not charge longer than required.
- ❗ Charge this device in a place without water-spray or moisture.
- ❗ Use a dry cloth to wipe any dust off the AC Adaptor plug to avoid potential fire.
- ❗ Do not drop this device on hard surfaces.
- ❗ Do not place heavy objects on this device to avoid cracking the enclosure.
- ❗ Do not unplug the AC Adaptor with wet hands to avoid electric shock.
- ❗ Do not use the TC605 AC Adaptor with any other devices.
- ❗ Do not place the device in liquids to prevent short-circuits or fire.
- ❗ Do not place this device near an open fire.
- ❗ If the power or USB cable is seriously twisted or broken, stop using it immediately to prevent electric shock, short-circuit, or fire.
- ❗ Stop using immediately if there is any unusual smell or overheating during charging or operation.
- ❗ Stop using immediately if there is liquid or dew on the device.
- ❗ Do not use the AC Adaptor outdoors.
- ❗ Do not wrap the AC Adaptor with cloth or other objects that could block heat dissipation and cause electric shock or fire.
- ❗ When not charging, remove the AC Adaptor plug from the wall AC outlet socket to avoid a fire hazard.
- ❗ The manufacturer will not be responsible for warranty claims if damage is caused due to improper personal use.

Table of Contents

About This Manual	2
Regulatory	2
Signal Interference from TV or Radio	2
Bluetooth Precautions	2
General Safety Precautions	3
Laser Safety	3
Hearing Safety	3
Body-worn Operation Safety	3
Important Notices and Precautions	4
Table of Contents	5
Chapter 1: Getting Started	7
Introduction	7
Unpacking	7
Features	8
Front View	8
Side View	9
.....	10
Back View	10
Top View	11
Bottom View	11
Initial Setup	12
Battery Installation	13
Charging the Battery	13
Nano SIM Card/Micro SD Card Installation	14
Andriod Learning Center	15
Chapter 2: Using the TC605	16
Managing Settings	16
Battery Management	17
Barcode Scanning	18
NTP Server	23
Programmable key	23
BarcodeStage	24

MDMClient	24
ScanAPP.....	25
Chapter 3: Utility Applications	26
Google Mobile Services	26
Chapter 4: Basic Care.....	28
Basic Care of the TC605	28
Product Storage	28
Cleaning	28
Troubleshooting.....	29
Appendix A: Technical Specifications.....	31
Key Features.....	31
Specifications	31
Technical characteristics	34
Appendix B: Battery & Adaptor Notes.....	36
Battery Precautions.....	36
Replacing Batteries.....	36
Storing Batteries.....	36
Adaptor Precautions.....	37
Appendix C: Barcode Types.....	38
Appendix D: Product Certification.....	39
Appendix E: Partners.....	42
Appendix F: Power and Frequency Ranges.....	43

Chapter 1: Getting Started

Introduction

The TC605 Enterprise Mobile Computer is a compact enterprise-focused mobile computer that is ideal for industrial and commercial applications such as retail, warehousing, logistics, and field service. The thin, lightweight, and rugged TC605 offers secure and reliable management of corporate data and wireless communications.

The TC605's key features include a rapid Qualcomm® Snapdragon™ QCM4490 Octa core 64-bit processor, 6" touchscreen display, barcode imager, long lasting battery, quick charge adaptor, and rugged durability.

This User's Manual provides information on how to use this device and its accessories.

Unpacking

Carefully remove and unpack the TC605 device and other package items from the protective material. Save the containers for later storage and shipping.

Check that you have received the following items:

- TC605 mobile computer
- Battery pack
- Adaptor (Optional)
- USB charging cable (Type C) (Optional)
- Quick start guide

Inspect the items for damage. If any item is damaged or missing, contact your customer support representative. Before using the TC605, remove the protective film that covers the display, camera window, and scan window.

Features

Front View




Table 1 – TC605 Front View Features and Functions

No.	Feature	Function
①	Receiver	Audio output when answering a call.
②	Front Camera	Takes photos and videos.
③	Proximity/Light Sensor	Detects when the face is close during a call and monitors ambient brightness.
④	Charging/Scan LED	Lights red during charging, green when battery is fully charged. Lights red during scanning, and green when scan is acquired.
⑤	Touch Screen	Interact with the device via the touch screen.
⑥	Speaker	Audio output for music, videos, and speakerphone.
⑦	Microphone	Receives or records voice, music, and other audio.

Side View




Table 2 – TC605 Side Views Features and Functions

No.	Feature	Function
①	Power Button	Press and hold to power on the device. Press briefly to turn the display on and off. Press and hold to power off.
②	Function Button	Engages app functions that can be set according to an app's instructions.
③	Scan Buttons	Press to scan for data capture.
④	Volume Button	Increase or decrease audio volume.

Back View




Table 3 – TC605 Back View Features and Functions

No.	Feature	Function
①	Laser Warning Label	Warns users not to stare into the laser light beam.
②	Back Camera	Takes photos and videos.
③	Flash LED	Provides camera flash.
④	Accessory Expansion Port	Connects to compatible accessory expansions for additional functionality.
⑤	Battery Cover Latches	Insert battery cover and lock with the battery cover lock switches.
⑥	Battery Pins	Connects battery.
⑦	SIM/Micro SD Card Slot	Slot for installing SIM or Micro SD Card.
⑧	Battery Cover Lock Switches	Use these switches to lock or open battery/cover.

Top View




Table 4 – TC605 Top View Features and Functions

No.	Feature	Function
①	Scan Window	Scans and captures data.

Bottom View





Table 5 – TC605 Bottom View Features and Functions

No.	Feature	Function
①	Cradle IO Connector / USB Connector	Connects to cradle for charging and communications, or connects USB cable for device charging, file transfer and MIDI use.

Initial Setup


Before using the TC605 device for the first time, please perform the following procedure.

1. Open the battery cover and remove the battery.
2. Install SIM card or Micro SD card for additional storage (optional).
3. Install the battery, close the cover, and lock the battery cover.
4. Charge the battery.
5. Power on the TC605.



Battery Installation


1. Open the two-battery lock switches and remove the battery cover.
2. Align the connectors of the battery pack and the device connectors and slide it into place. Slide the battery cover into place.
3. Push the battery lock switches to Closed to secure the battery cover.



Charging the Battery


The TC605 is shipped with a lithium-ion battery that is not fully charged. Before using the TC605 for the first time, you must fully charge the battery. For general use, if the battery has been discharged for several days, you may need to charge it for several minutes before powering on the device. Use only the Adaptor and the USB cable that came with this device or the optional charging cradle to charge the battery. When the battery power is low, use either the power Adaptor or the charging cradle to charge instead of using the USB cable to charge from your computer.

Charging via USB cable and Power Adaptor



1. Insert the USB cable's Type-C connector to the connector on the bottom of the device.
2. Insert the USB cable connector to the power Adaptor.
3. Plug the power Adaptor into a power outlet to begin charging.

Charging via the Charging Cradle



1. Insert the device into the charging cradle.
2. Plug the power cord into a power outlet to begin charging.

Nano SIM Card/Micro SD Card Installation

To install Nano SIM cards and/or a Micro SD card, please follow these steps:

1. Turn off the TC605 or put it in Battery Swap Mode.
2. Open the two-battery lock switches and remove the battery cover.
3. Remove the battery pack.
4. Locate the Nano SIM/Micro SD Card tray on the upper right side of the battery slot.
5. With your fingernail, gently pull the Nano SIM/Micro SD Card tray out.
6. Insert the Nano SIM card(s) and/or Micro SD card into the proper slots.
7. Slide the SIM tray back into place.
8. Return the battery pack and battery cover and lock the battery cover latch switches into place.

Andriod Learning Center

For the operation of Android, please follow the setup SOP or go to the [Android Learning Center](#) for inquiries.



Chapter 2: Using the TC605

This chapter describes using the TC605's unique or important special functions.

Managing Settings


You can control the TC605's settings for wireless & networks, device, personal, and system using the system settings below.

1. Swipe down from the status bar to open the quick access panel.
2. Tap the **Settings** icon: 
3. Swipe to scroll down and choose among the main device and settings below.
4. Adjust settings as needed.

Category	Settings
 Battery	Battery saver, Battery Manager, Battery percentage, Last full charge, Screen usage since full charge, Battery charge settings
 Barcode Settings	Enable Scanner, Scanner settings, Good read, Formatting, Wedge, Symbology Settings, Enable all symbologies, Disable all symbologies, Reset configuration, Export Settings Profile
 NTP Server	Default NTP Server, Self-definition, Current NTP Server
 Programmable key	Redefine key, View redefined key list

Battery Management

To manage the battery, you can monitor battery use via the battery status icons in the status bar as well as the battery settings screen; you can also save the battery by reducing the device's energy consumption.



Monitoring Battery Use

Besides keeping an eye on the battery icons in the status bar, you can also access the Battery screen in Settings for information on battery usage.

1. Swipe down from the status bar to open the quick access panel.
2. Tap the  icon to access **Settings**.
3. Scroll to **Battery** and tap to open.
4. The **Battery** screen displays percent of charge remaining and estimated time left on the battery.
5. Tap the **Battery** screen to show the discharge graph with details on usage, such as the rate of discharge since last charge.
6. Tap the applications to see details on their power consumption.

Battery charge Settings

Optimize charge mode and battery health.

- Full AI Smart Charging Mode : Full AI Smart Charging mode can automatically adjust the charging mode based on user behavior to protect the battery.
- Full Charging Mode : Full Charging Mode without battery overcharge protection.
- Balanced Charging Mode : Device stops charging at 80% capacity.
- Battery Protect Mode : Device stops charging at 60% capacity.

Optimizing Battery Savings

The following tips can help you save on battery consumption.

- Reduce screen brightness.
- Set the screen to turn off after short periods of non-use.
- Turn off Wi-Fi and Bluetooth when not in use.
- Turn off automatic syncing.
- Minimize use of applications such as for music and videos that prevent the device from entering suspended mode.

Barcode Scanning


The TC605 supports barcode data capture using an integrated 2D scan engine that provides omnidirectional reading of a wide variety of common barcode symbology including postal, QR Code, PDF417 and 2D matrix code types. The easy point-and-shoot operation utilizes a red crosshair or red dot aiming tool. The imager takes a picture of the barcode, stores the image, and uses the latest decoding algorithms to acquire data from the barcode.

Scanning a Barcode Label

1. Point the TC605's scan window at the barcode you wish to scan.
2. Press the scan button on either side of the device. You can also access the Scan App described below and tap the scan or trigger button.
3. The imager projects an aiming pattern to position the barcode in the imager's field of view. Center the red aiming pattern on the barcode.
4. Release the scan button or press stop on the trigger button to capture and decode the image.


Scanner Settings

1. Swipe down from the status bar to open the quick access panel.
2. Tap the **Settings** icon: 
3. Tap **BarcodeSettingsX** to go to the barcode settings screen.




4. Normal Settings

- a. **Scanner Settings:** From the barcode settings screen, tap Scanner settings to set scanner engine behavior.




- b. Good Read: From the barcode settings screen, tap Good read to enable / disable vibrator and other behavior settings.




- c. Formatting:


- i. From the barcode settings screen, tap Formatting to set Label prefix /suffix.
- ii. Enable or disable code ID or set up separator characters of data formats when you scan a barcode.



- d. Wedge: From the barcode settings screen, tap Wedge to enable or disable intent wedge / keyboard wedge. This is intended for developers' use only. For details, please contact iMozen.




- e. Symbology Settings: Tap Symbology Settings. Parameters of each code are different.




Note: For a list of the codes supported, please refer to **Barcode Support Information** in the Appendix.

5. Global Settings

- a. Enable all symbologies
- b. Disable all symbologies
- c. Reset configuration




6. Export: Export the barcode configuration file to the root directory of internal storage.



7. Tap the **Home Key**  to return to the Home screen.


NTP Server

1. Swipe down from the status bar to open the quick access panel.
2. Tap the **Settings** icon: 
3. Tap **NTP Server** to go to the barcode settings screen.




Programmable key

1. Swipe down from the status bar to open the quick access panel.
2. Tap the **Settings** icon: 
3. Tap **Programmable key** to go to the barcode settings screen.




BarcodeStage

1. In the Home screen, swipe up from the bottom to access apps.
2. Tap  to open BarcodeStage.
3. Allow the program to take photos and record videos.
4. Use the Scan key or camera to scan the Board code; this function is a shortcut function for customized settings.



MDMClient


1. In the Home screen, swipe up from the bottom to access apps.
2. Tap  to open MDM Client.
3. This function is customized, please contact iMozen for details.





ScanAPP

1. In the Home screen, swipe up from the bottom to access apps.

2. Tap  to open ScanAPP.



3. Tap the **Scan** button on the screen and aim at a barcode. Note that you can also use the scan buttons on each side of the TC605. The content of the barcode is displayed when decoding is complete.




4. Tap the **Home Key** to return to the Home screen.

Chapter 3: Utility Applications

Google Mobile Services

The TC605 comes preinstalled with Google Mobile Services (GMS) and comes with Google apps.



The bundled GMS apps include:

	Google –The Google app keeps you in the know about things that matter to you. Find quick answers, explore your interests, and stay up to date with Discover. The more you use the Google app, the better it gets.
	Google Maps – Gives you more than just reliable, real-time navigation. It also helps you find things to do and places you'll love across the world and around the corner. With millions of businesses on Google Maps, you can connect with the places you're interested in, and make your plans happen.
	YouTube –See what the world is watching in music, gaming, entertainment, news and more. Subscribe to channels, share videos with friends, edit and upload videos, and watch on any device.
	Google Drive – A smart online storage and backup that puts all your files within reach from any smartphone, tablet, or computer. Every file in Drive — like your photos, PDFs and documents — is backed up safely so you can't lose it. You can even invite others to view, download, and collaborate on all the files you want.
	Youtube Music –A new music service with official albums, singles, videos, remixes, live performances and more for Android, iOS and desktop.

	Google TV –The Movie streaming service.
	Meet –Simple, high-quality video chat for everyone.
	Photos –The home for all your photos and videos that help you find, relive and share your memories. Automatically organized and searchable by the people, places, and things in them, your photos and memories are always easy to find and share.
	Calendar –Integrated online calendars designed for teams. Spend less time planning and more time doing with shareable calendars that integrate seamlessly with Gmail, Drive, Contacts, Sites and Meet so you always know what's next.
	Contacts –Integrated online calendars designed for teams. Spend less time planning and more time doing with shareable calendars that integrate seamlessly with Gmail, Drive, Contacts, Sites and Meet so you always know what's next.
	Clock –Combines all the clock functionality you need into one simple package.
	Play Store – Your entertainment unbound brings together all the entertainment you love and helps you explore it in new ways, anytime, anywhere. We've brought the magic of Google to music, movies, TV, books, magazines, apps and games, so you get more from your content every day.
	Gmail –An easy-to-use email app that saves you time and keeps your messages safe. Get your messages instantly via push notifications, read and respond online & offline, and find any message quickly.
	Chrome –Browse fast on your Android phone and tablet with the same Chrome browser you love on your desktop. Pick up where you left off on your other devices with tab sync, search by voice, and save up to 60% of data usage while browsing.

The Google apps offer both free and subscription services. Click the app icons for more information on signing up and using the apps.

* [Google, Android, Google Play and other marks are trademarks of Google LLC.](#)

Chapter 4: Basic Care

This chapter provides information on basic care and troubleshooting for the TC605.

Basic Care of the TC605

The following basic care tips will ensure long, trouble-free use of the TC605.

- ❗ Protect the TC605 from temperature extremes. Do not leave the device in high temperature conditions such as near open heat sources or in a closed vehicle on a hot day.
- ❗ Do not store this device in harsh conditions, such as dusty or damp locations.
- ❗ Do not drop this device on hard surfaces.
- ❗ The TC605's touchscreen is glass. Do not scratch the screen.
- ❗ Clean the TC605 housing with a soft dry lens cloth.
- ❗ Clean the touchscreen with a small amount of water on a soft cloth for cleaning.

Product Storage

1. When storing the TC605, ensure that it is kept in a dry place and at a reasonable temperature.
2. To maintain battery health, avoid overcharging, over-discharging, and exposing the battery to prolonged high-temperature conditions (such as fully charged battery voltage, temperature above 70°C or 80°C), as these actions may lead to battery swelling.
3. The environmental temperature for storing the battery should be within a reasonable range (around 25°C). Ensure that the battery level is maintained at around 50%±10% for optimal storage.

Cleaning

According to your environment and needs, clean the TC605 regularly as much as possible. Do not directly apply liquids; instead, use a soft cloth or a

pre-moistened wipe to wipe the device, then allow it to air dry before use.
Clean the camera lens periodically for optimal performance.

Housing

Wipe the housing including the buttons with a soft cloth.

Touchscreen

Clean the touchscreen using a damp cloth, and immediately dry it with a soft lens cloth or lens tissues.

Camera

Wipe the camera windows occasionally with lens tissues.

Connectors

Wipe the scanning window with lens paper or a lens cleaning cloth.

Troubleshooting

Common problems, their causes, and suggested solutions are covered in the table below.

Problem	Cause	Solution
The TC605 does not turn on.	1. Battery depleted. 2. System crash.	1. Charge the battery. 2. Reset the device.
Battery does not charge.	1. Device disconnected from the charge cable. 2. Ambient temperature out of range.	1. Reconnect the charge cable. 2. Charge battery with ambient temperature between 0°C (32°F) and 40°C (104°F).
No characters in the display	Device not on.	Press the power button.

Data not transmitting over Wi-Fi or Bluetooth	1. Wi-Fi or Bluetooth not on. 2. Out of range of access point.	1. Turn on Wi-Fi or Bluetooth. 2. Move closer to access point.
No sound.	Volume off or set too low.	Adjust volume.
Display keeps shutting off.	1. Inactivity. 2. Battery depleted.	1. Set Display Sleep to a longer setting 2. Charge the battery.
No response to tapping buttons or tiles.	System crash.	Perform a reset.
The device is not reading barcode	1. Barcode is unreadable. 2. Scanner is not in range. 3. Device is not programmed for the barcode. 4. Device does not beep when reading barcode. 5. Battery low.	1. Make sure barcode is not damaged. 2. Scan closer to the barcode. 3. Program the device to read that type of barcode. 4. Set the application to beep. 5. Check battery level if scanner does not emit a light beam. If low, charge battery.
Device does not unlock.	Incorrect password entered.	Enter correct password.

Appendix A: Technical Specifications

The tables below provide product specifications for the TC605 mobile computer.

Key Features

- Qualcomm® Snapdragon™ QCM4490 Octa Core 64-bit Processor
- 6.0" 18:9 IPS High Quality LCD Module
- Gorilla 7 (rugged glass) capacitive touch panel
- 5000mAh Replaceable Battery

Specifications

Internet	• TC605AN: WWAN version • TC605AW: WLAN version
Weight	280g (with standard battery)
CPU	Qualcomm® QCM4490, 2.4GHz Octa Core
Memory	Memory Space: uMCP 6GB LPDDR4x + Flash Memory: 128GB UFS2.1 (User can utilize at least 70GB or more of storage space)
Display and Panel	• 6", 18:9 IPS Full-HD (1080 x 2160) • Gorilla® Glass 7
Expansion Slots	• Micro SD card slot x 1 (with SDHC compliance, supports up to 1TB and software image upgrade features) • Nano SIM slot x 2 • Type-C support USB OTG • Cradle charging port, can be used with a charging dock (optional). • Back expansion port, can be used with custom accessories (optional).

Wireless PAN	Bluetooth 5.2
Wireless LAN	• 802.11 a/b/g/n/ac/ax • Wireless LAN, 2.4GHz and 5/6GHz (Wi-Fi 6/6e) • Compliant with WEP, WPA and IEEE 802.11i WPA2, WPA3 • Fast Roaming, 2x2 MIMO
Wireless WAN (Only TC605AN)	• GSM: 850, 900, 1800, 1900 MHz • WCDMA: B1, B2, B4, B5, B6, B8, B19 • LTE: B1, B2(25), B3, B4(66), B5, B7, B8, B12(B17), B18, B19, B20, B26, B28, B38, B39, B40, B41, B42, B43, B48 • 5G NR: n1, n2, n3, n5, n7, n8, n12, n20, n25, n28, n66, n38, n40, n41, n48, n77, n78, n79
GNSS (Only TC605AN)	• aGPS, GPS, GLONASS, Beidou, Galileo, QZSS, SBAS • L1+L5 dual band
NFC	• ISO14443-4 (Type A, Type B), ISO15693 • MIFARE, FeliCa (ISO/IEC18092)
Power Adaptor	• 100~240Vac, 50/60Hz Input • 9V/2A 18W output (Support QC3.0)
Camera	• Front camera: 8M pixel CMOS color camera • Rear camera: 16M pixels CMOS color camera with auto focus • LED flashlight
Scanner	• Support 1D/2D - Zebra SE4710 - Zebra SE4770 - Zebra SE55 (optional)
Keys and Buttons	• Virtual key x 3 • Scan key x 2, Volume key x 2, Power key, Function key
Audio and Voice	• Speaker x 1 (95dB @ 10cm) • Receiver x 1, Dual noise-cancelling microphones x 1 • Support Type-C headsets
Sensor	Gyroscope, Light sensor, e-Compass, Proximity sensor, Accelerator sensor
Battery	Replaceable battery: 3.87V/5000mAh

Notification	• Vibration • Ring tone • LED behavior ➤ Charging - Pre charge: Red (Blinking on) - Charging: Red - Charge full: Green - Battery low: Red ➤ Scan - Scan Start: Red - Decoder: Green (Blinking once) ➤ In battery replacement mode - Flashing red light: The backup battery is about to run out of power, and you should promptly complete the replacement. - Continuous red light: Low backup battery power, and the replacement action should be completed within 5 minutes. - Green light: Sufficient backup battery power, and the replacement action can be completed within 30 minutes.
Software	• Android 13 with GMS • AER (Android Enterprise Recommended)
User Environment	• Operating Temp.: -20~50°C • Storage Temp. : -40~60°C (without battery) • Charging Temp. : 0~45°C • Humidity: 5%~95%(non-condensing) • Sealing: IP65&IP68 • Drop Spec. : 1.8 meter drop (2.1 meter drop with protective boot) • Tumble Spec. : 0.5m tumbles for 500 cycles and 1000 drops • ESD: ±8KV direct discharge, ±15KV air discharge
Certifications	• CB, CE, UKCA, FCC, NCC, Japan certification, Australia certification • RoHS, REACH, WEEE • BQB compliance • Wi-Fi compliance

Technical characteristics

The table below describes power and frequency range from EU-Type Examination Certificate.

Radio Type	Description	Frequency	Maximum Conducted Power
Bluetooth		2400~2483.5 MHz	10dBm
WLAN	2.4GHz	2400~2483.5 MHz	20dBm
	5GHz	5150~5250 MHz	23dBm
		5250~5350 MHz	20dBm
		5470~5725 MHz	20dBm
		5725~5850 MHz	14dBm
	6GHz	5945-6425 MHz	14dBm (VLP) 23dBm (LPI)
GSM (only TC605AN)	GSM 900	880~915 MHz	33dBm
	GSM 1800	1710~1785 MHz	30dBm
WCDMA (Only TC605AN)	WCDMA Band I	1920~1980 MHz	24dBm
	WCDMA Band VIII	880~915 MHz	24dBm
LTE (Only TC605AN)	LTE Band 1	1920~1980 MHz	23dBm
	LTE Band 3	1710~1785 MHz	23dBm
	LTE Band 7	2500~2570 MHz	23dBm
	LTE Band 8	880~915 MHz	23dBm
	LTE Band 20	832~862 MHz	23dBm
	LTE Band 28	703~748 MHz	23dBm
	LTE Band 38	2570~2620 MHz	23dBm
	LTE Band 40	2300~2400 MHz	23dBm
	LTE Band 41	2496~2690 MHz	23dBm

	LTE Band 42	3400~3600 MHz	23dBm
	LTE Band 43	3600~3800 MHz	23dBm
5G NR (Only TC605AN)	n1	1920~1980 MHz	23dBm
	n3	1710~1785 MHz	23dBm
	n5	824~894 MHz	23dBm
	n7	2500~2570 MHz	23dBm
	n8	880~915 MHz	23dBm
	n20	832~862 MHz	23dBm
	n28	703~748 MHz	23dBm
	n38	2570~2620 MHz	23dBm
	n40	2300~2400 MHz	23dBm
	n41	2496~2690 MHz	26dBm
	n48	3550~3700MHz	23dBm
	n77	3300~4200MHz	26dBm
	n78	3300~3800MHz	26dBm
	n79	4400~5000MHz	26dBm
Other	NFC	13.56 MHz	-16.03 dBuA/m
Other (Only TC605AN)	GNSS	L1 1575.42 MHz L5 1176.45MHz	Rx only

Appendix B: Battery & Adaptor Notes

This appendix describes precautions for using the battery and Adaptor with the TC605.

Battery Precautions

It is important to consider the temperature when the battery pack is charging. Charging is most efficient at normal room temperature or in a slightly cooler environment. It is essential that batteries are charged within the stated range of 0°C to 45°C. Charging batteries outside of the specified range could damage the batteries and shorten their life cycle.

Replacing Batteries

1. For optimal performance, it is recommended to replace the battery annually or after completing 500 full charge cycles. Slight swelling of the battery after one year or 500 cycles is normal. Although it won't cause damage, continued use is not recommended.
2. If the battery performance decreases by more than 20%, the battery is approaching the end of its life cycle, and it is advisable to discontinue using the battery.
3. Disposed batteries must be handled in accordance with the battery disposal regulations of the respective country. Do not dispose of them casually.

Storing Batteries

Although charged batteries may be left unused for several months, their capacity may be depleted due to a buildup of internal resistance. If this happens, the batteries require recharging prior to use. Batteries may be stored at temperatures between -20°C to 60°C, however they may deplete more rapidly at higher temperatures. It is recommended to store batteries at room temperature.

Adaptor Precautions

Please follow the power Adaptor precautions below:

- Do not leave the power Adaptor in the socket when it is not connected to the TC605 for charging.
- Remove the power Adaptor when the battery is fully recharged.
- The bundled power Adaptor that comes with your iMozen product is not meant to be used outdoors. An Adaptor exposed to water or rain, or a very humid environment can cause damage to both the Adaptor and the product.
- Only use the bundled power Adaptor or same specification of Adaptor to charge the TC605. Using the wrong power Adaptor can damage this device.

Appendix C: Barcode Types

The TC605 supports the following bar code types that can be individually enabled or disabled.

Linear	Composite Code	Postal
Codabar	GS1 Composite	Chinese Postal
Code 11	TLC-39	Korean Postal
Code 128		Australian Postal
ISBT 128	2D Barcode	Canadian Postal
GS1-128	Aztec Code	Japanese Postal
Code 39	Data Matrix	KIX Code/Dutch Postal
Code 32	DotCode	UK Royal Mail
Trioptic	HAN XIN	US Planet
Code 93	Maxicode	US Postnet
Industrial 2 of 5(IATA)	Micro PDF417	UPU 4-State
EAN-13	PDF417	USPS 4CB/IMb
EAN-8	QR Code	
GS1 DataBar-14	Micro QR Code	Advanced Setup
Interleaved 2 of 5		OCR
Matrix 2 of 5		Misc. Properties
MSI		
UPC-A		
Coupon Code		
UPC-E		
UPC-E1		
GS1 UDI		

Appendix D: Product Certification

FCC Interference Statement

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
- This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
- This device meets all the other requirements specified in Part 15E, Section 15.407 of the FCC Rules.

FOR PORTABLE DEVICE USAGE

Radiation Exposure Statement :

The product complies with the FCC portable RF exposure limit set forth for an uncontrolled environment and is safe for intended operation as described in this manual. Further RF exposure reduction can be achieved if the product is kept as far as possible from the user body or if the device is set to a lower output power if such function is available. This equipment should be installed and operated with a minimum distance of 15mm between the radiator device and your body.

FOR COUNTRY CODE SELECTION USAGE (WLAN DEVICES)

Note: The country code selection is for non-US models only and is not available for all US models. Per FCC regulation, all Wi-Fi products marketed in the US must be set to US operation channels only.

Operation of transmitters in the 5.925-7.125 GHz band is prohibited for control of or communications with unmanned aircraft systems.

NCC Interference Statement

1. The operations near the radar system shall not be influenced.
2. The directed antenna with high gain must apply to the fixed point-to-point system only.
3. Without permission granted by the NCC, any company, enterprise, or user is not allowed to change frequency, enhance transmitting power or alter original characteristic as well as performance to a approved low power radio-frequency devices. The low power radio-frequency devices shall not influence aircraft security and interfere legal communications; If found, the user shall cease operating immediately until no interference is achieved. The said legal communications means radio communications is operated in compliance with the Telecommunications Management Act. The low power radio-frequency devices must be susceptible to interference from legal communications or ISM radio wave radiated devices.
4. Standard SAR value: 2.0 W/kg, actual value measured on product: 1.914 W/kg.
5. Risk of possible damage to vision in case of excessive use

6. Protect your eyes: rest your eyes 10 minutes for every 30 minutes of use. It is advised to keep children under 2 years old from looking at the screen and children above 2 years old from watching for more than an hour every day.

設備名稱：手持行動電腦(資料收集器)，型號（型式）：TC605AW Equipment name Type designation (Type)						
單元Unit	限用物質及其化學符號 Restricted substances and its chemical symbols					
	鉛Lead (Pb)	汞Mercury (Hg)	鎘Cadmium (Cd)	六價鉻 Hexavalent chromium (Cr ⁺⁶)	多溴聯苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)
外殼	—	—	—	—	—	—
電源適配器	—	○	○	○	○	○
屏幕	○	○	○	○	○	○
主板	○	○	○	○	○	○
攝像頭(前後置)	-	—	—	—	—	—
喇叭	○	○	○	○	○	○
備考1. “超出0.1 wt %” 及 “超出0.01 wt %” 係指限用物質之百分比含量超出百分比含量基準值。 Note 1 : “Exceeding 0.1 wt %” and “exceeding 0.01 wt %” indicate that the percentage content of the restricted substance exceeds the reference percentage value of presence condition.						
備考2. “○” 係指該項限用物質之百分比含量未超出百分比含量基準值。 Note 2 : “○” indicates that the percentage content of the restricted substance does not exceed the percentage of reference value of presence.						
備考3. “—” 係指該項限用物質為排除項目。 Note 3 : The “—” indicates that the restricted substance corresponds to the exemption.						

CE Warning Statement

- Hereby, [iMozen Group] declares that the radio equipment type [TC605AN/AW] is in compliance with Directive 2014/53/EU.
- The full text of the EU declaration of conformity is available at the following internet address: iMozen Group.

UKCA Note

- Hereby, [iMozen Group] declares that the radio equipment type [TC605AN/AW] is in compliance with RER 2017 (SI 2017/1206).
- The full text of the UK declaration of conformity is available at the following internet address: iMozen Group
-

Note:

- *SAR Distance Caution: This device should be used with a minimum separation distance of 5 millimeters from the human body.*
- *This device is intended for indoor use only and operates in the frequency range of 5250 to 5350 Hertz / 5945 to 6425 Hertz (for LPI)."*

	AT	BE	BG	HR	CY	CZ	DK
	EE	FI	FR	DE	EL	HU	IE
	IT	LV	LT	LU	MT	NL	PL
	PT	RO	SK	SI	ES	SE	UK(NI)
	IS	LI	NO	CH	TR		

Appendix E: Partners

[iMozen's Partners](https://www.imozengroup.com/imozen-partners/)

<https://www.imozengroup.com/imozen-partners/>

Appendix F: Power and Frequency Ranges

The table below describes power and frequency range specifications. The frequency band is mainly in accordance with local laws and regulations and cooperation with telecommunications operators.

Radio Type	Description	頻率	Maximum Conducted Power
Bluetooth		2400~2483.5 MHz	10dBm
WLAN	2.4GHz	2400~2483.5 MHz	20dBm
	5GHz	5150~5250 MHz	23dBm
		5250~5350 MHz	20dBm
		5470~5725 MHz	20dBm
		5725~5850 MHz	14dBm
	6GHz	5945-6425 MHz	14dBm (VLP) 23dBm (LPI)
GSM (only TC605AN)	GSM 850	824~849 MHz	33dBm
	GSM 900	880~915 MHz	33dBm
	GSM 1800	1710~1785 MHz	30dBm
	GSM 1900	1850~1910 MHz	30dBm
WCDMA (only TC605AN)	WCDMA Band 1	1920~1980 MHz	24dBm
	WCDMA Band 2	1850~1910 MHz	24dBm
	WCDMA Band 4	1710~1755 MHz	24dBm
	WCDMA Band 5	824~849 MHz	24dBm
	WCDMA Band 6	830~840 MHz	24dBm
	WCDMA Band 8	880~915 MHz	24dBm
	WCDMA Band 19	830~845 MHz	24dBm
LTE (only TC605AN)	LTE Band 1	1920~1980 MHz	23dBm
	LTE Band 2	1850~1910 MHz	23dBm
	LTE Band 3	1710~1785 MHz	23dBm
	LTE Band 4	1710~1755 MHz	23dBm

	LTE Band 5	824~849 MHz	23dBm
	LTE Band 7	2500~2570 MHz	23dBm
	LTE Band 8	880~915 MHz	23dBm
	LTE Band 12	699~716 MHz	23dBm
	LTE Band 17	704~716 MHz	23dBm
	LTE Band 18	815~830 MHz	23dBm
	LTE Band 19	830~845 MHz	23dBm
	LTE Band 20	832~862 MHz	23dBm
	LTE Band 25	1850~1915 MHz	23dBm
	LTE Band 26	814~849 MHz	23dBm
	LTE Band 28	703~748 MHz	23dBm
	LTE Band 38	2570~2620 MHz	23dBm
	LTE Band 39	1880~1920 MHz	23dBm
	LTE Band 40	2300~2400 MHz	23dBm
	LTE Band 41	2496~2690 MHz	23dBm
	LTE Band 42	3400~3600 MHz	23dBm
	LTE Band 43	3600~3800 MHz	23dBm
	LTE Band 48	3550~3700 MHz	23dBm
	LTE Band 66	1710~1780 MHz	23dBm
5G NR (only TC605AN)	n1	1920~1980 MHz	23dBm
	n2	1850~1910 MHz	23dBm
	n3	1710~1785 MHz	23dBm
	n5	824~894 MHz	23dBm
	n7	2500~2570 MHz	23dBm
	n8	880~915 MHz	23dBm
	n12	699~716 MHz	23dBm
	n20	832~862 MHz	23dBm
	n25	1850~1915 MHz	23dBm
	n28	703~748 MHz	23dBm
	n38	2570~2620 MHz	23dBm
	n40	2300~2400 MHz	23dBm
	n41	2496~2690 MHz	26dBm
	n48	3550~3700MHz	23dBm

	n66	1710~1780MHz	23dBm
	n77	3300~4200MHz	26dBm
	n78	3300~3800MHz	26dBm
	n79	4400~5000MHz	26dBm
其他	NFC	13.56 MHz	-16.03 dBuA/m
其他 (only TC605AN)	GNSS	L1 1575.42 MHz L5 1176.45MHz	Rx only

DoC hyperlink

<https://www.imozengroup.com/support-category/download/>