

PSII RF 2.4GHz Wireless Gamepad FCC/CE TEST Device (Controller)Test Mode Manipulate Manual

1. open for power switch (Power ON the Device/Controller).
2. Whether in common pulsatile frequency connect manipulate mode just the same pulsatile frequency transmit test mode under , can pass to press the row combination key to set the new test mode

Setup Different TEST MODE:

- L3 + × (Fork) into connect manipulate test mode
- L3 + □ (Square) into RF transmit test mode
- L3 + L2 into RF receive test mode
- L3 + LEFT into Sleep test mode

Setup Different power estate:

- L3 + ○ (Circle) setup RF power for 0dB
- L3 + △ (Triangle) setup RF power for -5dB

Setup channel :

- L3 + UP setup RF channel fastness for Channel 78(2.480GHz)
- L3 + RIGHT setup RF channel fastness for Channel 39(2.441Ghz)
- L3 + DOWN setup RF channel fastness for Channel 0(2.402GHz)

Setup motor estate:

- L3 + L1 open for motor to maximal
- L3 + R1 motor comeback natural estate

Example 1:

Under the condition of POWER switch on after the DEVICE AND HOST being placed in the connect, to want into -5dB, 78 channels transmit to test the mode, can carry out with the operation step of underneath

Step 1: L3 + △

Step 2: L3 + UP

Step 3: L3 + □

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Modifications not authorized by the manufacturer may void users authority to operate this device

For FCC/CE Test Use

For FCC/CE Test Use