


ITEM NO. 3701



Full-Function Radio Control Vehicle

OPERATING INSTRUCTIONS

CAUTION: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

PLEASE DO NOT
RETURN TO STORE
For more information
or questions, please call
Consumer Services:
1-877-FUN-TOYS
(1-877-386-8697)

Colors and decorations may vary.
Keep content details
for future reference.



Manufactured & Distributed by

© 2005 Planet Toys Inc.

NY, NY 10010

All Rights Reserved

MADE IN CHINA

www.planettoysltd.com

102405

Table of Contents

PAGE 1: Table of Contents, Malibu Wakesetter VLX Features.

PAGE 2: Malibu Wakesetter VLX Checklist.

PAGES 3-4: Installing the Vehicle Battery Pack & Controller Battery

PAGE 5: Power On/Off Switch, Alignment Control & Controller Antenna Installation.



PAGE 6: Operating the Vehicle, Proper Use, Precautions & Care.

PAGE 7: Please Note and Troubleshooting.

PAGE 8: Caution, Warning & Attention Parents.

Malibu Wakesetter VLX Features

Malibu Wakesetter VLX




Comes in 2 Different Styles



Malibu Wakesetter VLX Checklist

To prevent damage, the contents of the package that are listed below have been packed in the tray and may be out of plain sight. Please remove all contents from the tray.


VEHICLE



STAND



CONTROLLER





CONTROLLER ANTENNA

Installing the Battery Pack



1. Turn the three locking tabs and remove the top of boat to expose the battery compartment.

2. Locate battery compartment in the center of the boat's chassis.




3. Open battery compartment by turning the two locks located on either side of the battery cover.

4. Remove battery cover and insert 6 'AA' batteries.



5. Replace the battery compartment cover and rotate the battery cover locks so that it is secure.




Lock Battery Compartment cover


Controller Battery Installation

1. On the back of the controller, locate the battery compartment.
2. Unscrew the battery compartment cover.
3. Insert 1 "9v" size battery. Make sure the plus (+) and minus (-) markings on the battery match up with the plus (+) and minus (-) places on the battery cap.

Match up battery cap with plus (+) and minus (-) on the battery




Unscrew Battery Cover




4. Place battery in battery compartment slot.

5. Replace cover and screw back into place tightly.



Place battery in battery compartment



Screw Battery Cover on Tight

CAUTIONS


1. Do not mix old and new batteries.
2. Do not mix alkaline, standard or rechargeable batteries.
3. Use Alkaline batteries only.

NOTE: Replace with Alkaline Batteries for longest life and best performance. Remember to take out all the batteries from the vehicle and the controller if the vehicle will not be used for a long time.

5

Power On/Off & Alignment Control Switch


Alignment Control Dial



Power On/Off


Controller Antenna Installation

Insert the transmitter antenna into the transmitter and screw in tightly (clockwise).



Operating the Vehicle

6



Proper Use, Precautions & Care

2. Operating multiple vehicles with the same frequency in close proximity will cause interference and poor performance.

FCC CAUTION:

The manufacturer is not responsible for the radio interference caused by unauthorized frequency modification to this equipment. Such modifications could void the user's authority to operate the equipment.

3. Works best away from high voltage power lines, large buildings and walls.

4. Hold the controller antenna up for the best performance.

5. When the product does not respond, slows down, or loses range, replace the batteries.

6. This product is not recommended for use on loose dirt or wet surface.

7 Please Note & Troubleshooting

PLEASE NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technician for help

TROUBLE SHOOTING

Problems	Reasons	Solutions
Running problems	The batteries inside the radio control are too weak.	Replace with new alkaline batteries inside the control unit.
	There is a weak or low reception for the radio control.	
	The batteries inside the vehicle are too weak.	Replace with new alkaline batteries inside the vehicle.
Operation problems	A small object obstructs movement of the vehicle.	Use tweezers or a paper clip to remove obstruction.
Other	The vehicle does not respond to the radio control.	Try playing at another location.
	The radio control's frequency is disrupted by something around the environment.	Some other equipment using the same radio wave could disrupt the radio control. Either play in another location or turn off other equipment. If you are planning to race your vehicles with another friend, purchase vehicles with 2 different frequencies (49MHz and 27MHz) to avoid disruption

8 Cautions & Warnings

Do not charge a damaged, leaking, hot or wet Battery Pack.

When not in use, remove Battery from its compartment.

Under no circumstance should the Battery Pack be disposed of in fire. This may cause injury, leakage or explosion.

Do not stall the motor during use.

WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation