" CAUTIONS & WARNINGS

Do not recharge the Battery Pack if it is warm to the touch. Allow the Battery Pack to cool before recharging. Recharging a warm Battery Pack will shorten the life of the Pack.

Recharging batteries should be done by an adult.

Do not charge a damaged, leaking, hot or wet Battery Pack.

When not in use, remove Battery from its compartment.

When not in use, Transformer should be unplugged from the electrical outlet.

Under no circumstance should the Battery Pack be disposed of in fire. This may cause injury, leakage or explosion.

Please dispose of Ni-Cd Battery cells properly.

Do not break open or disassemble the Battery Pack.

Do not use the Battery Pack or Charger for any other reason than charging and running a West Coast Choppers RC Vehicle.

Do not stall the motor during use.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and

TABLE OF CONTENTS

PAGE 3: Charging the 9.6V Ni-Cd Battery Pack.

PAGE 1: Table of Contents.

PAGE 2: Chopper Checklist.

PAGE 4: Battery Pack Installation.

PAGE 5: Controller Battery Installation

PAGE 7: Controller ON/OFF switch.

PAGE 6: Setting up the Oil Burnout Feature.

PAGE 9: CUDA & SS Features and Functions.

PAGE 11: Caution, Warning & Attention Parents.

PAGE 10: Please note and troubleshooting.


PAGE 8: Operating the Vehicle, Proper Use, Precautions & Care.


2. This device must accept any interference recieved, including interference that may cause undesired operation of the device.


ATTENTION PARENTS: The Battery Charger & Battery Pack need to be periodically examined for potential hazards and any potential hazardous parts be repaired or replaced.













Lights will glow while driving forward.

BURN OUT

Rear body of car wil

rise and burn-out

HEADLIGHTS


BURN OUT FEATURE

Rear body of car will rise and burn-out

when burn-out

FEATURE


HEADLIGHTS





WORKING

TAILLIGHTS





control towards the "R" marking. If the

vehicle pulls to the rights while driving,

adjust the trim control towards the "L"

try to correct the interference by one or more of the following measures Reorient or relocate the receiving antenna

7.Do not immerse in water.

 Increase the separation between the equipment and receiver - Connect the equipment into an outlet on a circuit different from that to

5. When the product does not respond, slows down, or loses range, replace the batteries.

PLEASE NOTE & TROUBLESHOOTING

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to

can be determined by turning the equipment off and on, the user is encouraged to

6. This product is not recommended for use on loose dirt or wet surface.

which the receiver is needed.

Consult the dealer or an experienced radio/TV technician for help

TROUBLE SHOOTING

Problems	Reasons	Solution
Running problems	The battery inside the radio control unit is too weak.	Replace with new alkaline batteries inside the control unit.
	There is a weak or low reception for the radio control.	
	The rechargable battery inside the vehicle is too weak.	Recharge the 9.6V Ni-Cd Battery Pack.
Operation problems	A small object obstructs movement of the tire or axle.	Use tweezers or a paper clip to remove obstruction.
	The vehicle was driven on the carpet and has fabric threads caught in the axle.	Playing on the carpet is not recommended.
Other	The vehicle does not respond to the radio control.	Try playing at another location.
	The radio control's frequency is discrupted by something around the environment.	Some other equipment using the same radio wave could discrupt the radio control. Either play in another location or turn off other equipment. If you are planning to race your vehicles with another friend, purchase vehicles with 2 different frequencies (49MHz and 27MHz to avoid disruption