## CAUTIONS & WARNINGS

Do not recharge the Battery Pack if it is warm to the touch. Allow the Battery Pack to cool before recharging. Recharging a warm Battery Pack will shorten the life of the Pack.

Recharging batteries should be done by an adult.

Do not charge a damaged, leaking, hot or wet Battery Pack.

When not in use, remove Battery from its compartment.

When not in use, Transformer should be unplugged from the electrical outlet.

Under no circumstance should the Battery Pack be disposed of in fire. This may cause injury, leakage or explosion.

Please dispose of Ni-Cd Battery cells properly.

Do not break open or disassemble the Battery Pack.

Do not use the Battery Pack or Charger for any other reason than charging and running a THIRTYS Radio Control Vehicle.

Do not stall the motor during use.

#### **WARNING:**


Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

- This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference recieved, including interference that may cause undesired operation of the device.

ATTENTION PARENTS: The Battery Charger & Battery Pack need to be periodically examined for potential hazards and any potentially hazardous parts to be repaired or replaced.

### ITEM NO. 3372 & 3373 CHARGING THE BATTERY PACK

IMPORTANT: The included 9.6V Ni-Cd Bettery is not charged, please charge prior to use.



1. First, plug the Transformer into a Standard 110/120V Household electrical outlet. Then, insert the connecting plug into the opening located on the side of the Charger.

CONTROLLER BATTERY INSTALLATION

NOTE: Replace with Alkaline Batteries for longest life and best performance. Remember to

take out all the batteries from the vehicle and the controller if the vehicle will not be used

- - 3. Charge the battery pack for 5 hours. The battery pack will feel warm. In this condition, the battery is fully charged. NOTE: Leaving the Battery in the Charger will not increase the life of your battery.

2. Plug the battery wire connector and transformer wire connector together.

4. After charging and during use, the Battery Pack will become warm.

NY, NY 10001 IMPORTANT: Please allow the Battery Pack to cool prior to recharging. All Rights Reserved Charging before doing so will greatly reduce the life of the Bettery. MADE IN CHINA www.planettoys.com

1. On the bottom of the Controller, locate the

2. Pull off the Battery Compartment Cover.

4. Replace the Battery Compartment Cover

Make sure the plue (+) and minus (-) markings

minus (-) markings inside the Battery Compartment.

2. Do not mix alkaline, standard or rechargeable batteries.

on the battery match up with the plus (+) and

**Bettery Compartment.** 

3. Insert 1 "9V" size batteries.

1. Do not mix old and new betteries.

1. On the top of the vehicle,

you will find an opening


where the vehicle antenna

3. Use Alkaline betteries only.

1. Carefully turn the vehicle on its side and locate the battery compartment found on the bottom of the vehicle chassis.

INSTALLING THE BATTERY PACK

2. Unscrew to open and remove the battery cover on the vehicle chassis.







4. Place the wire plug into the gap in the bettery compartment.

3. Connect the wire plug on the battery to

the wire plug on the vehicle.

- 5. Insert the 9.6V Ni-Cd battery to the
- 6. Replace the battery compartment cover and screw back on.



### **OPERATING THE VEHICLE**

Steering Wheel

# PLEASE NOTE: LED will light when controlls Reorient or relocate the receiving antenna Increase the separation between the equipment and receiver which the receiver is needed. TROUBLE SHOOTING

### PROPER USE, PRECAUTIONS & CARE

1.The Toy can perform better on a vinyl floor. Thick carpets are not recommended since carpet does not provide sultable traction and lint from the carpet may damage vehicle.

2.Operating multiple vehicles with the same frequency in close proximity will cause interference and poor performance.

modifications could void the user's authority to operate the equipment. 3. Works best away from high voltage power lines, large buildings and walls.

The manufacturer is not responsible for the radio interference caused by unauthorized frequency modification to this equipment. Such

4.Hold the controller antenna up for the best performance.

5. When the product does not respond, slows down, or loses range, replace the batteries.

6. This product is not recommended for use on loose dirt or wet surface.

7.Do not immerse in water.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residentia installation. This equipment generates, uses and can radiate radio frequence quarantee that interference will not occur in a particular installation. If this can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures

- Connect the equipment into an outlet on a circuit different from that to

PLEASE NOTE & TROUBLESHOOTING

- Consult the dealer or an experienced radio/TV technician for help

Problems	Reasons	Solutions
Running problems	The batteries inside the radio control are too weak.	Replace with new alkaline batteries inside the control unit.
	There is a weak or low reception for the radio control.	
	The rechargable battery inside the vehicle is too weak.	Recharge the 9.6V Ni-Cd Battery Pack.
Operation problems	A small object obstructs movement of the tire or axle.	Use tweezers or a paper clip to remove obstruction.
	The vehicle was driven on the carpet and has fabric threads caught in the axle.	Playing on the carpet is not recommended.
Other	The vehicle does not respond to the radio control.	Try playing at another location.
	The radio control's frequency is disrupted by something around the environment.	Some other equipment using the same radio wave could disrupt the radio control. Either play in another location or turn off other equipment.

## TABLE OF CONTENTS

PAGE 1: Table of Contents, THIRTYS Features. PAGE 2: THIRTYS Checklist.

PAGES 3-4: Charging & Installing the 9.6V 'AA' size Ni-Cd Battery Pack.

PAGE 5: Controller Battery Installation, Vehicle & Controller Antenna Installation

PAGE 6: Power On/Off Switch & Alignment Control.

PAGE 7: Operating the Vehicle, Proper Use, Precautions & Care.

PAGE 8: Please Note and Troubleshooting. PAGE 9: Caution, Warning & Attention Parents.

# THIRTYS CHECKLIST

Full-Function 9.6V Ni-Cd Radio Control Vehicle

CAUTION: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO

OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS

Ford Oval and nameplates are registered

Manufactured by Planet Toys

under license to Planet Toys Inc.

THIRTYS is a trademark of Vanilla Gorilla L. P. under license.

©2006 Vanilla Gorilla L.P.

trademarks owned and licensed by Ford Motor Company.

Buick, Regal, all related Emblems and vehicle model


body design are General Motors Trademarks used

THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S

REPLACE THE 9.6V NHCD BATTERY PACK.

AUTHORITY TO OPERATE THE EQUIPMENT.

To prevent damage, the contents of the package that are listed below have been packed in the tray and may be out of plain eight. Please remove all contents from the tray.







9.6V Ni-Cd BATTERY PACK

PLEASE DO NOT

RETURN TO STORE

For more information

or questions, please call Consumer Services:

(1-877-386-8697)

Colors and decorations may vary.

Keep content details

for future reference.

Tellowers and the second of th

Manufactured & Distributed by

© 2006 Planet Toys Inc.

042506


























2. Slide the vehicle antenna

3. Tying a simple knot

in the antenna wire

will hold the vehicle


wire through the vehicle

antenna tube. The tube

will fit inside the opening

found on the top of the car.

3 antenna tube in place.




**Battery Compartment** 

# POWER ON/OFF ALIGNMENT CONTROL SWITCH

Power On/Off



### **Alignment Control Dial**



between the front wheels. If the vehicle begins to pull to the left, adjust the trim control towards the "R" marking. If the vehicle pulls to the right while driving adjust the trim control towards the "L" markings.

#### CONTROLLER TRANSFORMER VEHICLE & CONTROLLER ANTENNA THIRTYS FEATURES INSTALLATION



Transformer included

- for vehicle included

   9V batt. for controller included

NOT CHARGED PRIOR TO SHIPMENT AND MUST BE CHARGED BEFORE USE.

1977 BUICK REGAL









