
Integrative Laser Presenter User's Manual



Be sure to carefully read this user manual first for the proper use of the Integrative Mini Presenter and keep it for future reference.

Instruction

It is a great tool for PowerPoint presentations! With it, you don't need to stand beside your computer or have an additional person click the slide for you!

It contains two parts: transmitter and USB receiver.

Features:

1. Easy carry

The transmitter and receiver are integrated into one unit to easy carry!

2. Easily control the pace of your presentation

Advanced radio frequency (RF) technology that works through walls and control distance is 10-meters / 32-feet away, so you never need to stand at beside of your computer.

3. Multifunctional presenter


It combines the functions of laser pointer and slide changed.

Easy to use

It is USB plug-and-play. No driver required. Just plug the receiver into the USB port on a PC and it works within seconds.

I . Operation System

Windows 2000 and above, Windows XP, Vista, Win 7



Note:

- 1. "PageUp", "PageDown" and "Laser Pointer" three buttons adopt touch sensitive technology, just touch the button to realize the function.
- 2. Power switch function to save power when product is not used.

Ⅲ. Battery installation

Laser Pointer

- The product is powered by 2x AAA battery.
- · Push and remove the battery cover.
- Insert 2x AAA battery into the battery holder.
- · Put the battery cover back into position.



Note

- 1. Do not insert battery into the device in the wrong direction.
- 2. Do not leave bad or exhausted battery in the device
- If you do not use the device for a long period of time, remove the battery to avoid possible damage from battery corrosion.
- If the device does not function correctly or if the operating range becomes reduced, try to replace the battery with new one.

IV. Operating Hints

- For optimal performance and RF reception place the receiver at least 15cm away from all electrical devices, such as your monitor, speakers or external storage devices.
- Please make sure your fingers don't contact the touch key when turning on the power switch, otherwise, the touch key may not work. Please keep waiting in case of improper operation, the function will resume automatically around 10 seconds.
- It is normal phenomenon that if hold down the laser button for 5 seconds, the laser will become brighter. (for green laser presenter only)
- The laser button can't keep working above 20 seconds, which may cause the product damaged. (for green laser presenter only)
- It's normal phenomenon if no laser or weak laser under low temperature, please reuse after preheating. (for green laser presenter only)

V. Technical parameters

Transmitter

RF Frequency	2.4GRF
Control distance	10 meters
Laser	Green or red laser
Max output	< 1mW or < 5mW
Laser distance	Up to 200M
Working temperature	0~45°C for red laser;
	10~45°C for green laser
Battery	2 x AAA
Battery Working voltage	2 x AAA 2.4~3.0V
Working voltage	2.4~3.0V
Working voltage Sleep current	2.4~3.0V <50uA
Working voltage Sleep current Dimension	2.4~3.0V <50uA 140.5x25.8x15.8MM

Receiver

Operation system	Windows 2000 and above,
	Windows XP, Vista, Win 7
Interface	USB1.1, Compatible with USB2.0
Working voltage	USB electricity supply (4.5~5.5V)
Dimension	20.3x14.5x7.3MM
Weight	1.9g

VI Safety Measures

- To avoid possible eye damage, never point the presenter at people especially their faces, or look directly into the presenter's laser beam.
- Avoid pointing the presenter's laser beam at a mirror or other highly reflective surface.
- · Keep the presenter away from children.

- Never view the presenter's laser beam using telescopic devices, such as a microscope or binoculars.
- Any attempt to disassemble, adjust or repair the presenter may result in exposure to laser light or other safety hazards.

NOTE 🛕

The product adopts advance RF technology, the USB receiver will identify the first transmitter which is used. If you want to use different transmitters with the same receiver, please pull off the receiver and plug it again, after 6 seconds, press any key of the transmitter you want to use. Then it can work successfully.

Warning **A**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.