



Change your Skype profile

In **My profile** you can tell other Skype users a bit about yourself. Please note that any Skype user can see all configurations you make in **Details shown to all**, even the Skype users you have not authorised.


You must be signed into Skype to change your profile.




- 1) From the **Idle screen**, press left to enter the main menu.




- 2) Press and left to select **Status**.



- 3) Press and left to select **My profile**.




- 4) Press and left or just press left to select your preferred profile (**Details shown to all, Private**).



- 5) In **Details shown to all**, press and left to select your preferred setting (**Show my picture, Skype name, Full name, Gender, Birthdate, Country/region, State/province, City, Language, Home phone, Office phone, Mobile, Home page, About me, Mood**).

- a) In **Show My Picture**, press left  to select.
- b) In **Skype name**, please note that you cannot change your Skype name here.
- c) In **Full name**, use the keypad to enter your data.
- d) In **Gender**, use left  to select (**Male, Female, Unspecified**).
- e) In **Birthday**, enter the month using the keypad, press ARROWRIGHT to go to the day and enter the day using the keypad, press ARROWRIGHT again to go to the year and enter the year using the keypad.
- f) In **Country/Region**, use  and left  or just left  to select (A ÷ Z).
- g) In **State/Province** and **City**, use the keypad to enter your data.
- h) In **Language**, use  and left  or just left  to select (A ÷ Z).
- i) In **Home phone, Office phone, Mobile, Home page, About me** and **Mood**, use the keypad to enter your data.

In **Private** you can enter your e-mail address. The address will *not* be shown to other Skype users and is merely used for the search function: Save your private e-mail address in **Private**, and users who know this address will be able to find you by searching for it on Skype.




- 1) In **Private**, press left  to select options (**Edit, Remove, Add**).

NOTES:


- In **Show My Picture**, the pictures for use with your profile must be edited on a computer with a Skype client.
- All data regarding home phone, office phone and mobile supplied by a Skype user will be recorded in your Contact list when you add the user.

Change your password


You can change the Skype password used for signing in to your Skype account. See **Create a new Skype account** in the **Installation and basic functions** section for more information.




- 1) From the **Idle screen**, press left  to enter the main menu.



- 2) Press  and left  to select **Status**.



3) Press and left to select **Change password**.




4) Enter your password using the keypad, then press left .

5) Enter your new password, then press the "OK" softkey.


6) Repeat your new password, then press the "Change" softkey.

Create a personal voicemail greeting


Skype voicemail has a default voicemail greeting. You can also create your personal welcome greeting, which will be played back to people calling you when you are unable to answer the call.




1) From the **Idle screen**, press left to enter the main menu.




2) Press and left to select **Settings**.




3) Press and left to select **Call divert**.



- 4) Press and left to select **Welcome message**.




- 5) Press left to select options.




- 6) Press **Record new** to record your welcome greeting, and press **Play** to hear the recorded message.

Listen to your voicemail

Callers can leave a message for you. Whenever someone sends you a voicemail, the message **You have 1 new voicemail** will be displayed on your DUALphone.




- 1) From the **Idle screen**, press left to enter the main menu.




- 2) Press and left to select **History**.



3) Press and left to select **Voicemail**.



4) Press and left or just press left to select the voicemail of your choice.



5) Press left to select options (**Play, Call, Send voicemail, Details, Delete, View profile, Add to contacts, My greeting**).


- | | |
|-------------------------|---|
| Play: | Play back the voicemail. |
| Call: | Call the person who has left the voicemail for you. |
| Send voicemail: | Send the person who has left the message for you a voicemail. |
| Details: | View the details of the voicemail (Name, number, date, time, duration). |
| Delete: | Remove the voicemail. |
| View profile: | View the profile of the person who has sent the voicemail. |
| Add to contacts: | Add the person who has left the voicemail for you to your Contact list. |
| My greeting: | Play back or record your personal welcome greeting. |

NOTE:


- If you activate your voicemail through Settings ÷ Divert ÷ Voicemail, the voicemail will work only with incoming Skype and Online Number calls, not with calls on your landline.

Privacy


You can make restrictions as to whom you wish to accept a Skype or a call to your online number from. Your choices are:




1) From the **Idle screen**, press left to enter the main menu.



2) Press and left to select **Settings**.




3) Press and left to select **Privacy**.



4) Press left to select **Skype calls**, then press and left or just press left to select your preferred privacy status for incoming Skype calls (**Anyone**, **Contacts**, **If details shared**).

- Anyone:** All Skype users can call you, even users not on your Contact list.
Contacts: Skype users can call you only if they are on your Contact list.
If details shared: Only Skype users authorised by you can call you.




5) Press and left to select **Online Number calls**, then press and left or just press left to select your preferred privacy status for incoming Online Number calls (**Anyone**, **Contacts**, **Known numbers**).


- Anyone:** You can receive calls from anyone calling your online number.
Contacts: Only SkypeOut contacts on your Contact list can call you.
Known numbers: Only online number calls providing a Caller ID will be accepted.

Notification


You can choose whether you want to be alerted by a tone whenever you receive a voicemail or an authorisation request.




1) From the **Idle screen**, press left  to enter the main menu.




2) Press  and left  to select **Settings**.



3) Press  and left  to select **Tones**.



4) Press  and left  to select **Notification alert**.



5) Press  and left  or just press left  to select your preferred alert type (**Beep, Silent**).


NOTE:

- Whenever you receive a voicemail, miss a call, or get an authorisation request, the light indicator on the top left of your handset will flash a blue light signal. Just press left  to see your options.


PHONE SETTINGS

Tones


You can configure keypad tones, ring tones etc. on your DUALphone. The following are just a few examples.



1) From the **Idle screen**, press left  to enter the main menu.



2) Press  and left  to select **Settings**.



3) Press  and left  to select **Tones**.


Change the call alert

You can define how you want your DUALphone to alert you with incoming calls:

- Ringin:** The handset will ring as long as the incoming call is active.
- Ring once:** The handset will ring only once.
- Beep once:** The handset will make one beep only on an incoming call.




1) From **Tones**, press left  to select **Incoming alert type**.



- 2) Press and left or just press left to select your preferred alert type (**Ringing, Ring once, Beep once**).

Change the ring tone

You can define how you want your DUALphone to ring on incoming calls.




- 1) From **Tones**, press and left to select **Ring tones**.




- 2) Press and left or just press left to select your preferred ring tone (**Silent, Melody 1 ± 11, Beep, Melody 13**).

Adjust the ringing volume

You can adjust the ringing volume of the handset for incoming calls.




- 1) From **Tones**, press and left to select **Ringing volume**.




- 2) Change the ringing volume level using / .

Adjust the keypad tones

You can choose whether you want to hear a tone whenever you press a key or whether you want your keys to be silent.



1) From **Tones**, press and left to select **Keypad tones**.




2) Press and left or just press left to select your preferred setting (**On**, **Off**).

Set the time and date


Your DUALphone will always obtain time and date information from the Internet. Thus, you only have to configure the **Time zone** and **Daylight saving** settings. When this is done, the time and date obtained by your DUALphone from the Internet will be adjusted according to your choices.




In **Time zone** it is important that you choose the correct time zone, otherwise the time shown on the idle screen will not be right. In **Daylight saving** you have two options. Choose **Daylight saving** when you are in a zone with summertime, and choose **Standard** in all other zones.




1) From the **Idle screen**, press left to enter the main menu.




2) Press and left to select **Settings**.



3) Press and left to select **Time and date**.




4) Press and left to select **Time zone**.



5) Press and left or just press left to select your preferred time zone (**GMT -12** ÷ **GMT +13**).



6) Press and left select **Daylight saving**.




- 7) Press and left or just press left to select your preferred mode (**Daylight saving, Standard**).

If you wish to adjust the **Time format** and **Time separator** as well as the **Date format** and **Date separator** settings, this is easily done here.


Set the preferred line

You can configure how you want to route your outgoing calls when using . These are your options:


- Landline:** Select this option if you always want to route your landline and/or mobile phone calls via the landline (traditional telephony).
- SkypeOut:** Select this option if you always want to route your calls to the landline and/or mobile phones via the Internet (SkypeOut).
- Always ask:** Select this option if you want to always be prompted to specify the preferred routing for a call.



- 1) From the **Idle screen**, press left to enter the main menu.




- 2) Press and left to select **Settings**.



- 3) Press and left to select **Phone settings**.



- 4) Press and left to select **Preferred line**.



- 5) Press and left or just press left to select your preferred port (**Landline, SkypeOut, Always ask**).


Change the country code

As Skype does not know where in the world you are connected to the Internet, you will always have to enter the country setting when calling landline phones and/or mobile phones via the Internet (SkypeOut). This applies even when you call a phone in your own country. If you save your country settings in **Country code**, you do not have to enter the country code every time you call a phone in your own country. Thus, a country code is only needed when calling someone in a country other than your own.


In some countries area codes are used, for instance when calling between states or regions. If you live in a country where area codes are used, you can save your settings in Area code. Please note that you can choose this function only if the code you have saved in Country code applies to a country where area codes are in fact used.



- 1) From the **Idle screen**, press left to enter the main menu.




- 2) Press and left to select **Settings**.




3) Press and left to select **Phone settings**.



4) Press and left to select **Region**.



5) Press left to select **Country code**, then enter your preferred country code using the keypad.




6) Press and left to select **Area code**, then enter your preferred area code using the keypad.

Change the landline country setting


As your DUALphone works both with Skype telephony and ordinary telephony via landline connections, your DUALphone has to know in what country you are connecting to the landline system. In other words, the configuration you make here has nothing to do with Skype, only with landline telephony.

PLEASE NOTE:


- Emergency calls can only be made via the landline.



- 1) From the **Idle screen**, press left  to enter the main menu.



- 2) Press  and left  to select **Settings**.



- 3) Press  and left  to select **Phone settings**.




- 4) Press  and left  to select **Landline country**.




- 5) Press  and left  or just press left  to select the country you are located in.

Change the handset language


You can change the language displayed on your handset. You can select another language than English only if your DUALphone is connected to the Internet.



1) From the **Idle screen**, press left  to enter the main menu.



2) Press  and left  to select **Settings**.



3) Press  and left  to select **Phone settings**.




4) Press  and left  to select **Language**.



5) Press  and left  or just press left  to select your preferred language (A ÷ Z).

Should you accidentally select a language which makes it hard for you to find the **Language** menu again, use this shortcut:




- 1) From the **Idle screen**, press left (←) to enter the main menu.




- 2) Press three times on the number 8 key.

Register / deregister your handset


Use the **Register** function whenever you need to register your handset with a base station, for instance when registering the handset with a base station other than the one you are already registered to. Use the **Deregister** function to deregister your handset from a base station.



- 1) From the **Idle screen**, press left (←) to enter the main menu.



- 2) Press (⌂) and left (←) to select **Settings**.



- 3) Press (⌂) and left (←) to select **Cordless settings**.



- 4) Press  and left  or just press left  to select **Register handset** or **Deregister handset**.


NOTE:

- To make registration possible, make sure that the base station has registration mode enabled. This is done by pressing **Reset** on the back of the base station.


Internet settings

You can configure settings such as IP mode, IP address, Skype proxy and Firmware proxy. However, if you have an advanced Internet connection and are not familiar with firewalls and ports, we recommend that you consult someone with knowledge on this or read more on the topic at www.skype.com.


In **IP mode** you can choose **Dynamic** or **Static**. The default setting of your DUALphone is dynamic IP mode, which covers the needs of most users. Should you wish to attach the base station to an Internet connection using the static IP mode instead, this is how to configure this mode:




1) From the **Idle screen**, press left (←) to enter the main menu.



2) Press (⌂) and left (←) to select **Settings**.




3) Press (⌂) and left (←) to select **Advanced**.



4) Press (⌂) and left (←) to select **Internet settings**.




5) Press left (←) to select **IP mode**.




6) Press  and left  to select **Static**.




7) A wizard will guide you through the configuration.



7a)



7b)




7c)




7d)


In **Skype proxy** you can configure all the settings regarding this proxy. This is how to do it:




- 1) From the **Idle screen**, press  to enter the main menu.




- 2) Press  and left  to select **Settings**.




- 3) Press  and left  to select **Advanced**.




- 4) Press  and left  to select **Internet settings**.




- 5) Press  and left  to select **Skype proxy**.



6) Press left (←) to select **Proxy**.




7) Press (⌂) and left (←) to select **Yes**.




8) Press (⌂) and left (←) or just press left (←) to select the proxy host type (**Automatic, HTTPS, SOCKS5**).

9) **Automatic** may be selected if your proxy supports this feature. If you select one of the other options, a wizard will guide you through the relevant configuration.

In **Firmware proxy** you can configure all the settings regarding this proxy. This is how to do it:




1) From the **Idle screen**, press left (←) to enter the main menu.



2) Press (⌂) and left (←) to select **Settings**.




3) Press  and left  to select **Advanced**.




4) Press  and left  to select **Internet settings**.



5) Press  and left  to select **Firmware proxy**.




6) Press left  to select **Proxy**.




7) Press  and left  to select **Yes**.

8) Use the keypad to enter the HTTP proxy IP Address. A wizard will guide you through the configuration.


In **Skype ports** you can configure all the settings regarding the incoming connection port. This is how to do it:




- 1) From the **Idle screen**, press left to enter the main menu.



- 2) Press and left to select **Settings**.



- 3) Press and left to select **Advanced**.



- 4) Press and left to select **Skype ports**, then enter your choices for **Port** and **Alternative ports** using left .

Adjust the earpiece volume

During a call just press / to increase or decrease the volume. The setting will be retained after the call is terminated.

Mute the microphone

During a call just press to mute the microphone. Press again to unmute.

Connect a headset


Free your hands while talking – connect an external headset. The connector is of the mono type, plug size 2.5mm. Please note that not all headsets will be suitable. Ask for a set with an impedance of 30 Ohms or higher.

NOTE:


- We recommend that you use the Plantronics Backbeat 116 with a universal 3.5mm jack.

Reset the phone and base


To restore the DUALphone's factory settings you can reset the phone and base. Please note, though, that all your personal settings will be lost.




- 1) From the **Idle screen**, press left  to enter the main menu.



- 2) Press  and left  to select **Settings**.



- 3) Press  and left  to select **Advanced**.



- 4) Press  and left  to select **Reset**.


CONTACTS

Your list of contacts contains all Skype users as well as all landline phone users that you have added. There is a limit to the number of entries you can make, but your contact list can nevertheless hold hundreds of contacts.

It is easy to access your list of contacts:



1) From the **Idle screen**, press left (←) to enter Contacts.



2) Press left (←) to select Contacts.




3) Browse your contacts using (⌂).




4) Or search for a contact with the quick search feature by using the letters on the keypad. For example, if you press the letter J, you will see a list showing all of your contacts beginning with this letter.

5) Press left (←) to select a contact.



6) Press (⌂) and left (←) or just press left (←) to select the desired action (**Call, Send voicemail, View profile, Advanced**).



- 7) Under Advanced you have access to more options (**Rename, Remove, Edit, Block, Request details, Add contact**).

Your contacts are ordered as follows:

- Online Skype contacts (alphabetically by full name)
- Offline Skype contacts with call forwarding and SkypeOut contacts (alphabetically by full name)
- Offline, voicemail divert, and non-authorised Skype contacts (alphabetically by full name)

NOTE:


- If you have more contacts than your DUALphone supports, you might experience that your DUALphone will not show all the available contacts.

Exchange contact details request


You can send an authorisation request to a Skype user – and if it is accepted, you can see his or her online status.

When adding a contact to your Contact list you will be prompted to specify if you want to send an authorisation request. We recommend that you send this request but you do not have to do so – and you can send the request whenever you wish to. If you do not send the request, you will never be able to see the contact's online status. Users who have not been authorised will be indicated by  on your contact list.


Similarly, you will receive an authorisation request whenever a Skype user adds you to his or her Contact list. By accepting the request, you allow the user to see your online status.




- 1) From the **Idle screen**, press left  to enter the main menu.




- 2) Press left  to select **Contacts**.



- 3) Press  and left  or just press left  to find a contact, and select the contact by pressing left .



- 4) Press  and left  to select **Advanced**



5) Press and left to select **Request details**.

6) Use the keypad to enter any text to be sent along with your request.

7) Press left to send the request.


NOTE:

- You can only request details from users whose online status is shown with a question mark.


Rename a contact

You can change the name of a contact.

If a contact has a Skype user name that is not very informative, you can give him or her a more distinctive name to be shown on your contact list.




1) From the **Idle screen**, press left to enter the main menu.




2) Press left to select **Contacts**.



3) Press and left or just press left to find a contact, and select the contact by pressing left .



4) Press and left to select **Advanced**.



5) Press left  to select **Rename**.


6) Enter the desired new name using the keypad.

Remove a contact


You can remove a contact. Your options are:

Remove and block: Remove and block a contact. Please note that this option applies only to Skype contacts.


Remove: Remove a contact from your Contact list. This option applies to Skype as well as landline contacts.




1) From the **Idle screen**, press left  to enter the main menu.




2) Press left  to select **Contacts**.




3) Press  and left  or just press left  to find a contact, and select the contact by pressing left .



4) Press  and left  to select **Advanced**.



5) Press and left to select **Remove**.




6) Press and left or just press left to select the required type of removal (**Remove and block, Remove**).


7) In both cases you are asked whether you really want to remove the contact. Press left to remove the contact, right to cancel.

Block a contact

You can block a Skype contact to prevent him or her from calling you. Please note that this option applies only to Skype calls. You can see your blocked contacts under **Settings ≠ Manage blocked users**. At any time you can choose to unblock a blocked contact.




1) From the **Idle screen**, press left to enter the main menu.




2) Press left to select **Contacts**.




3) Press and left or just press left to find a contact, and select the contact by pressing left .



4) Press and left to select **Advanced**.



5) Press and left to select **Block**.




6) Press left to block, press left again to unblock.


■ MAKE AND RECEIVE CALLS

Dialling

Dial editor



1) From the **Idle screen**, type the phone number you want to call using the keypad; alternatively, press right to select the number from **Contacts**.




2) Press left to select the line (Dial on SkypeOut, Dial on landline).

3) Select the preferred line by pressing and left or just pressing left .

How to pre-dial a Skype user:



1) From the Idle screen, hold down  for more than two seconds.



2) Type the Skype name of the person you want to call.

3) Press left  to call.

Character map

For keys 0 ÷ 9, multi tapping is possible.

Multi Tap Order:


KEY	MULTI TAP ORDER:
0	Space 0 +
1	1 . , ? ! - _ @
2	a b c 2 æ å ä á à â ã ç
3	d e f 3 ë é è ê
4	g h i 4 ï í ì î
5	j k l 5
6	m n o 6 ø ö ñ ó ò ô õ
7	p q r s 7 ß
8	t u v 8 ü ú ù û
9	w x y z 9 ÿ ý æ ø å

PLEASE NOTE:


When in the text editor, press  to see all special characters. When in the text editor, press  to switch between lowercase, uppercase and numerical entry.

Speakerphone

During a call you can switch between the speaker and earpiece.




- 1) Press left  to select **Speaker**.




- 2) Press left  again to return to **Earpiece**.

Start a new call during a call


This is how to start a new call during an active call:



- 1) Press right  to put your active call on **Hold**.




- 2) Use the keypad to enter a new number manually or locate the number on your Contact list by using "**Options->Search in contact list**"



- 3) Press  to start the call. You can switch between the calls by pressing right 
- 4) Press  to terminate the active call.


Conference call

From your DUALphone you can initiative a 3-party conference call between one Skype user, one landline caller and yourself.




1) Start a Skype or landline call.

2) Put the active call on **Hold** by pressing right .



3) Start a landline or Skype call.



4) Choose **"Options->Join in conference"**, and the conference is established.

5) Press left  to end the conference.

Skype Conference call

The DUALphone cannot initiate a Skype conference call, but you can participate in a Skype conference call initiated from a computer.

If the active call is a Skype conference call, you can see the participants via the **View participants** menu.

Divert all calls

You can configure your DUALphone to forward all incoming Skype calls either to a landline/mobile phone or to your Voicemail. Please note that in order to use this function, you have to have Skype credits. Your options are:


Call forward: Activate forwarding to another phone number. You will be prompted to enter the relevant number. Please remember to enter the country code.

Call forward number: Edit the phone number when **Call forward** is active.


Voicemail: Activate your Voicemail, allowing callers to leave a message after listening to your welcome message.

Welcome message: After activating **Voicemail** you can record your welcome message. If you do not record a personal message, the Skype standard message will be used instead.


Regarding forwarding of landline calls: Please contact your landline provider.




- 1) From the **Idle screen**, press left  to enter the main menu.




- 2) Press  and left  to select **Settings**.



- 3) Press left  to select **Call divert**.



- 4) Press left  to select **Call forward**.



- 5) Press  and left  or just press left  to select the required option (**Yes**, **No**).

- 6) After selecting **Yes** you will be prompted to enter a call forward number. Press the keypad.

View call history

You can see all call history information, including missed calls, outgoing calls, incoming calls, authorisation requests or voicemails. Whenever there is an entry on one of the lists, you can see the details, such as the phone number, name (when accessible) and a time log indicating when the entry was received. Please note that the lists can contain minimum 40 entries – the oldest ones will be deleted first. Also, please note that the lists will be deleted whenever you sign out of Skype. Your options are:

All calls: A list containing all missed, incoming and outgoing calls. Please note that landline as well as Skype calls will be registered.


These are your options when working with the lists:

<i>Call:</i>	Call the number.
<i>Send voicemail:</i>	Return a call with a voicemail. Please note that this works only with Skype calls.
<i>Details:</i>	View details regarding the call.
<i>Delete:</i>	Remove the entry.
<i>View profile:</i>	View the profile for the entry. Please note that this works only with Skype calls.
<i>Add to contacts:</i>	Add an entry to your Contact list.
<i>Clear list:</i>	Delete all entries on the list.


Missed calls: A list showing only the missed calls.
Please note that landline as well as Skype calls are registered.

Incoming calls: A list showing only the incoming calls.
Please note that landline as well as Skype calls are registered.

Outgoing calls: A list showing only the outgoing calls.
Please note that landline as well as Skype calls are registered.



1) From the **Idle screen**, press left  to enter the main menu.




2) Press  and left  to select **History**.




- 3) Press and left or just press left to view the preferred history (**All calls, Missed calls, Incoming calls, Outgoing calls, Voicemails, Contacts requests**).

Set privacy for calls


You can specify which kinds of Skype and online number calls you want to accept.




- 1) From the **Idle screen**, press left to enter the main menu.




- 2) Press and left to select **Settings**.



- 3) Press and left to select **Privacy**.



- 4) Press and left or just press left to select your preferred Privacy setting (**Skype calls, online number calls**).



- 5) Under **Skype calls**, press  and left  or just press left  to select your preferred setting (**Anyone, Contacts, If details shared**).




- 6) Under **Online Number calls**, press  and left  or just press left  to select your preferred setting (**Anyone, Contacts, Known numbers**).

Call waiting

When someone calls you during an active call, you will be notified by a tone in the earpiece as well as the message 'Call waiting' on the display.

There are two types of waiting calls: Calls on the same line you are presently using, and calls on the other line.

Example one:




- 1) You have an active Skype to Skype call.

- 2) When you receive a second Skype call, you will hear a beep.


- 3) Hold down  to answer the new call while automatically putting the original call on hold.

- 4) Hold down  again to switch between the calls.


Example two:



1) You have an active Skype call.



2) When you receive a landline call, you will hear a beep.




3) Press left (←) to answer the new call while automatically putting the original call on hold.


4) To switch between the calls, press right (→).

DIAL OUTGOING CALLS

Dial a telephone number from the outgoing calls list



1) From the idle screen, press (ⓘ) to access the list of outgoing calls.



2) Press left (←) for **Options**.

3) Press left (←) to select **Call**.

■ FIRMWARE UPDATE

You can check to see which software version your DUALphone is presently using as well as upgrade to the most recent version. Your options are:

- Latest Firmware:


Displays the latest firmware version. Please note that you cannot use your DUALphone during the update process. The update typically lasts 15 minutes, depending on your Internet connection.
- Current firmware:

Displays the firmware version currently used by your DUALphone.
- All Firmware vers.:


Displays a list of all accessible firmware versions that your DUALphone can use. Thus, you can choose to downgrade to an older version.



1) From the **Idle screen**, press  to enter the main menu.



2) Press  and left  to select **Settings**.



3) Press  and left  to select **Advanced**.



4) Press  and left  to select **Firmware update**.



- 5) Press and left or just press left to select the required option (**Latest Firmware, Current Firmware All Firmware vers.**).



- 6) Under **Latest Firmware**, press left to install. Please be aware that the download can take some time. The handset will prompt you when the firmware update is finished.



- 7) Under **Current Firmware**, you find specifications of the firmware version presently used by the base station and the handset.



- 8) Under **All Firmware vers.**, you can see prior updates. Press and left or just press left to select your preferred version.
- 9) Press left again to install the selected version. You will then be asked if you are sure you want to update. Press left to accept the update, right to cancel.

NOTE:

- If your DUALphone has not been updated after 30 minutes, you must restart the DUALphone by disconnecting and reconnecting the base station to the power outlet.

SUPPORT INFORMATION

Please visit **www.dualphone.net** for updated help and support. Here you will find documentation on FAQ, troubleshooting and new features.

■ ADVANCED TROUBLESHOOTING

PROBLEM	CAUSE	SOLUTION
I have nowhere to plug in the base station.	Your computer or other equipment may be occupying the Internet connection port.	Get a router, allowing you to attach more units to the same Internet connection port. If you are buying a new one, we recommend a peer2peer-friendly router.
I have problems with my DUALphone.	- You are not using the latest software. - There is a problem between your DUALphone and the device (modem/router/switch) to which it is connected.	- Update the software via Settings > Advanced > Firmware update > Latest firmware. - Restart your modem/router/switch and then restart the base station by turning the power off and on.
I cannot sign in to Skype.	- You are using an incorrect Skype name and/or password. - You have no Skype account. - Your base station is not connected to the Internet. - The base station has not been provided an IP address.	- Check the Skype name and/or password and try again. Be sure to enter large and small letters and special characters correctly. - Create a Skype account via Status > Create new account. - Check that all cables are attached correctly. - Check via Settings > Information that an IP address is shown under IP address. If not, check your Internet connection. If you are using a router, switch or hub, restart the device(s) and then restart the base station. Please refer to My base station does not receive an IP address under Advanced troubleshooting.

(continues)

PROBLEM	CAUSE	SOLUTION
I cannot sign in to Skype. (continued)	- Your Internet connection timed out because you are not using an "Always on" connection. - A firewall/NAT/router is blocking access to the Internet.	- Some broadband connections require that you log on the Internet every time you wish to use it, and the connection will automatically close after for example 20 minutes of inactivity. Your DUALphone does not work with such connections, only with "Always on" connections. Contact your Internet provider and get an "Always on" connection. Possibly "Always on" may be enabled via your provider's homepage. - Restart your router and then restart your base station. If this does not help it may be because you are using a very restrictive kind of router/NAT. Please contact your Internet provider or router manufacturer. - If you are about to buy a new router we recommend a peer2peer-friendly router. Skype needs unrestricted outgoing TCP access to all destination ports over 1024 or to ports 80 and 443 in order to work properly. To obtain even better sound, we recommend that you open the specific port to incoming TCP and/or UDP traffic. Please check Settings > Advanced > Internet settings > Skype ports.
My base station does not receive an IP address.	- You may be using an Internet connection with a static IP address. - Other equipment, for instance a computer, has been connected to the Internet connection.	- Configure the static IP address via Settings > Advanced > Internet settings > IP mode. Select Static and enter the IP address; then follow the wizard to make the further required entries. - Connect the base station to the Internet connection port. Turn on the base station and wait for about one hour. Restart the base station and check if your DUALphone works. Check via Settings > Information if the base station has received an IP address.
I cannot connect to Skype from my workplace or school.	Most likely your base station is behind a proxy server, which are often used by companies and schools.	Configure the Skype proxy via Settings > Advanced > Internet settings > Skype proxy. Also, you have to configure via Settings > Advanced > Internet settings > Firmware proxy. Please contact the IT support resource at your workplace or school for further information.

PROBLEM	CAUSE	SOLUTION
The time on the idle display is incorrect.	- The base station is not connected to the Internet. - You have not programmed your Time Zone and Daylight saving. - Your DUALphone is behind a proxy server.	- The handset gets the time and date from the Internet. Connect the base station to the Internet and wait for a few minutes. - Select your time zone via Settings > Time and Date > Time zone. Then select Settings > Daylight saving and choose Daylight saving if you are in a zone with summertime, otherwise select Standard. - In order for the SNTP (Simple Network Time Protocol) to work, UDP/IP port 123 must be set to open proxy.
I cannot make a Skype to Skype call.	- You are not signed in. - You have no Internet connection.	- Choose Status > Sign in and enter your Skype name and password when prompted for it. If you have no Skype account, you can create one via Status > Create new account. - Please refer to "I cannot sign in to Skype" under Advanced troubleshooting.
I cannot make a SkypeOut call.	- You are not subscribing to this service. - You are out of Skype credits.	- You can buy SkypeOut at www.Skype.com. - Check your available Skype credits via Service > Skype Credit.
My SkypeOut call does not reach the person intended.	You have not stored your country code.	Check that your country code is registered via Settings > Phone settings > Region > Country code. You may also need to check your area code via Settings > Phone settings > Region > Area code.
I cannot receive Skype calls from certain persons.	- You have specified restrictions as to whom you want to communicate with. - The person is a blocked Skype contact. - You are signed out.	- Check the person who is unable to call you via Settings > Privacy > Skype calls (or Online Number calls). Select a privacy option which allows the person to call you. - Check if the Skype contact is blocked via Settings > Manage blocked users. Unblock if required. - Sign in to your Skype account via Status > Sign in to Skype.
My DUALphone does not ring on incoming calls.	- You have muted your handset. - You have enabled Call divert, which means that all incoming Skype calls are forwarded.	- Adjust the volume via Settings > Tones > Ring tones. - Disable call forwarding via Settings > Call divert > Call forward.

PROBLEM	CAUSE	SOLUTION
I experience a bad sound quality during Skype calls.	- You are probably behind a router which interferes with the sound. - Another unit (for instance a computer) is using the Internet connection.	- In order to obtain better sound, we recommend that you open the specific port shown under Settings > Advanced > Internet settings > Skype ports to incoming TCP and/or UDP traffic. However, on some routers you cannot configure incoming UDP traffic although you can still configure rerouting of ports with incoming TCP traffic. If you are using several Skype clients on the same router, you must make sure that they are not using the same Skype Port. - Free up bandwidth by ending other ongoing Internet traffic or get an Internet connection with more bandwidth.
I cannot send voicemails.	You are not subscribing to this service.	You can buy SkypeOut at www.Skype.com. Check if your voicemail is active via Service > Voicemail.
Landline and mobile phones cannot call me via Online Number.	- You are not subscribing to this service. - You are out of Skype credits. - People calling your Online Number do not wait long enough before they hang up.	- You can buy credit at www.Skype.com. - Check your status via Service > Online Number. - People calling you should allow the phone to ring at least five times before they hang up due to the delay before the Online Number call reaches you.
I cannot call via my landline connection.	- The base station is not connected to your landline. - The landline is out of order. - The landline connection is occupied by another phone in the house. - The base station is not turned on.	- Connect the landline to your base station. - Check your landline connection with a traditional phone and hear if there is a dialling tone. If not, contact your landline provider. - Check that the landline connection is not occupied. - Turn on the base station.
I cannot receive calls via my landline connection.	You are using incorrect landline country setting.	Select the correct landline country setting via Settings > Phone settings > Landline country. Please note: The landline country setting has no influence on Skype calls.

PROBLEM	CAUSE	SOLUTION
I cannot access the main menu Contacts .	You are signed out.	Your contact list resides on a central Skype server and is therefore visible only when you are signed in. Sign in via Status > Sign in to Skype.
I cannot see if a Skype contact is online as his or her online status is always shown as 	The contact in question has not been authorised.	Send an Authorisation request: From Contacts, select Options > Advanced > Request details. Whenever a person has accepted your request, you will be able to see his or her online status.
The main menu History is suddenly empty.	You are signed out.	The History list is deleted whenever you sign out. Sign in via Status > Sign in to Skype. Please note: Old call details will not be restored at the next sign in.
My friends cannot find me on Skype by searching for my e-mail address.	You have not configured your data under My profile.	Save your e-mail address via Status > My profile > Private. Other Skype users cannot see your e-mail address, they can only use it for searching for you if they know the address already.
The handset does not charge when placed in the charger.	- The handset is not placed correctly in the charger. - The charger is not connected to the power outlet or it is not turned on. - The batteries are not inserted correctly in the handset.	- Check that the charger makes a beep when the handset is placed correctly. - Check that the power supply is connected to the outlet and that the unit is turned on. - Check that the batteries are inserted correctly. Use only rechargeable batteries, type Ni-MH.
I cannot turn the handset on.	- The batteries are empty. - The batteries are not inserted correctly in the handset.	- Place the handset in the charger. The handset will turn on automatically after some time in the charger. - Place the batteries correctly in the handset.
The display is black.	The handset is not turned on.	Hold down  for approximately two seconds to turn on the handset.
There is no antenna symbol in the upper right hand corner of the display.	- You are too far away from the base station. - The base station is not turned on.	- Move the handset closer to the base station. - Turn on the base station. The red LED light must be on at all times.

(continues)

PROBLEM	CAUSE	SOLUTION
There is no antenna symbol in the upper right hand corner of the display. (continued)	The handset is not registered.	Register the handset via Settings > Cordless settings > Register handset.
I do not understand the language on the handset.	You have chosen the wrong language.	From the idle screen, press Menu > 888, then select your preferred language from the list.
I cannot register the handset to the base station, the message 'Open base station could not be found' is shown on the handset.	- The base station is turned off. - The base station is not in registration mode. - You are too far away from the base station.	- Turn the base station on. The LED light on the base station must be red. - Press the Reset button on the back of the base station, then press left  for Retry on the handset. - Move the handset closer to the base station (for instance in the same room).
No Caller ID is shown when I receive landline calls.	- You are not subscribing to this service with your landline provider. - You are using an incorrect country setting.	- Contact your landline provider. - Select the correct country setting via Settings > Phone settings > Landline country.
I do not get a new line on my landline connection when sending a flash (by pressing ).	You are using an incorrect country setting.	Select the correct country setting via Settings > Phone settings > Landline country.

FAQ

QUESTION	ANSWER
Why is the DUALphone 4088 for Skype better than a Wi-Fi phone for Skype?	Because it is more reliable (DECT), has no interference problems with other wireless devices (Wi-Fi, Bluetooth), has a much longer talk time (more than 10 hours), standby time (more than 140 hours) and range (up to 300 meters). In practice the DUALphone 4088 has a superior voice quality with increased distance between the handset and the base station/router. This is due to less packet loss and interference compared to a Wi-Fi phone. Furthermore, with the DUALphone 4088 you get a 2-in-1 telephone for both Skype and ordinary landline calls, as well as you have the possibility for dual Skype accounts on one base station.
Where can I buy the DUALPhone 4088?	You can buy the DUALphone 4088 at www.dualphone.net and www.skype.com and retailers. Please visit www.dualphone.net for further information.
What is a DUALphone?	Your DUALphone combines two phones in one unit, allowing you to use Skype, SkypeOut /Online Number as well as traditional telephony via landline. Thus, you can use your DUALphone on two networks, for instance allowing you to establish a conference call between users on both networks.
Is it easy to connect my DUALphone to the Internet?	Yes. It only requires you to connect the base station to a power outlet and to your Internet connection. However, you might need a router/switch/hub if you want to connect more units to the same Internet connection, for instance both your computer and your DUALphone. We recommend that you use a peer2peer friendly router for this purpose.
Are there any special requirements on my Internet connection?	Yes. You have to use an Internet connection that is "Always on". Some broadband connections demand that you log onto the Internet every time you wish to use it, and the connection will automatically close after for example 20 minutes of inactivity. Your DUALphone does not work with such connections, only with 'Always on' connections. Contact your Internet provider and get an "Always on" connection. Possibly "Always on" can be enabled via your provider's homepage.
Can my DUALphone be updated with new software?	Yes. Unlike many other products, the firmware of your DUALphone can be updated to always give you access to the latest features.
What Skype services does my DUALphone support?	Your DUALphone supports Skype, SkypeOut, online number and Voicemail.
How many skype accounts can be signed in at the same time?	Your 4088 dualphone can be signed in to two different skype accounts at the same time. To use this feature you must purchase one additional handset. With two account only one account can hold an active call on skype at the same time.

QUESTION	ANSWER
What Skype features does my DUALphone support?	• Superior Skype sound quality • Calling via Internet: Skype to other Skype users • Calling via SkypeOut to ordinary telephone numbers • Works with Online Number – enables reception of calls from ordinary telephone numbers (PSTN) • Works with Skype Voicemail™ (view, play, delete, record personal greeting) • Skype conference call (invited party) • View, search and call Skype contact list • Skype Call Forwarding • Skype Call Waiting • Caller Identity with Skype name and picture of calling party • Notification of missed calls, new voicemail • Set your Skype online status (Offline, Away, Do Not Disturb etc.) • View the status of your Skype contacts on the handset display • View Call History of Skype and ordinary calls (30 entries) • Contact list (Telephone book): 250 entries • Create a new Skype account • Manual and automatic sign-in to Skype account • Edit my profile • Update notification when new Skype and DUALphone software is available • View Skype credits
What is SkypeOut?	SkypeOut allows you to call ordinary phones and mobile phones at very competitive prices. There might be restrictions applying to calls to special service numbers in certain countries.
What is the price of a call to ordinary phones and mobile phones via SkypeOut?	You can make big savings. Check the prices at http://www.skype.com/intl/en/prices/?intcmp=CS-Upsell-MA25
Is it expensive to use Skype with a volume based Internet connection?	No. Skype does not take up much bandwidth. On average, Skype uses 0-0.5 Kbps during standby and 3-16 Kbps during calls.
Does Skype work behind a NAT router?	Yes. Skype works behind most NAT routers. We recommend that you use a peer2peer friendly router.
Does my DUALphone support several languages in the menus?	Yes. You can choose between 11 languages: Italian, Portuguese, Polish, Spanish, Dutch, Finnish, Danish, Swedish, English, German and French
Does my DUALphone support connections via proxy servers and firewalls with approval?	Yes. Your DUALphone supports HTTP or HTTPS proxies, authenticating HTTPS/SSL and SOCKS5 proxies.

QUESTION	ANSWER
In which countries has the DUALphone 4088 been approved?	The DUALphone 4088 has been approved in the following European Union Member States: Austria, Belgium, Cyprus, Czech Republic, Denmark, Estonia, France, Germany, Greece, Hungary, Ireland Italy, Latvia, Lithuania, Luxembourg, Malta, Poland, Portugal, Slovakia, Slovenia, Spain, The Netherlands, United Kingdom. Other countries: Iceland, Liechtenstein, Bulgaria, Faroe Island, Greenland, Romania and Switzerland, Australia, South Africa and New Zealand.
Can I use the DUALphone as a conference phone?	Yes, the DUALphone 4088 has a handsfree speakerphone, just as you can be the invited party on a Skype conference call. DUALphone 4088 can also manage a 3-party call between landline and Skype calls.
Is it safe to call via Skype?	Yes. All your Skype calls are encrypted, thus increasing the safety and protection of personal information.
Is it safe to have my user data on the Skype server?	Yes. All your profile data and your contacts are located on a Skype Server, not on your DUALphone. A digital signature, based on a public and a private key, protects all profile data. The public key is used to encrypt the data, allowing only the person with the right key to make the data readable again.
Can I make an emergency call via Skype?	No. Skype does not allow emergency calls, but provided you have an active landline connection and your DUALphone is connected to the base station and the base station is connected to the landline, you can route emergency calls via this line. Please note that emergency calls can only be made when the base station is connected to the power outlet and it is turned on. The phone cannot be used during a power failure.
Can I protect myself against harassment via Skype?	Yes. You can always block certain persons from contacting you via Skype. You can also prevent groups of persons from contacting you.
Can my DUALphone use a static IP address?	Yes. You may configure a static IP address.
Can I call ordinary phones and mobile phones via Skype?	Yes. However, this requires that your Skype account supports SkypeOut, a service you can buy at www.skype.com . With SkypeOut you can call ordinary phones and mobile phones at very competitive prices.
Can ordinary phones and mobile phones call me via Skype?	Yes. However, this requires that your Skype account has an online number, a service you can buy at www.skype.com . With Online Number you get an ordinary phone number that your contacts can call.
Can I take my DUALphone with me and use it in another country?	Yes. Your DUALphone can be connected to the Internet anywhere with an active Internet connection. The landline connection will also be working in other countries.
What is the range of my DUALphone?	The maximum distance between the handset and the base station depends on the environment you are working in. However, you should typically have a range of some 50 metres indoors and 300 metres outdoors. (US 30 meter indoor and 250 meter outdoor).

QUESTION	ANSWER
Is the handset GAP compatible?	Your DUALphone uses a number of features specific to Skype. Therefore we recommend that you do not use other handsets than the one provided with your DUALphone.
Can I use several handsets with the same base station?	Yes. You will be able to use up to four handsets which can all take advantage of the same Skype account.
Can I divert an incoming Skype call?	Yes. However, this requires you to have Skype credits on your Skype account.
Can I check my Skype credit status?	Yes, you can check your Skype credits from your DUALphone handset.
Is there an answering machine in my DUALphone?	Yes, provided your Skype account supports Voicemail, a service that you can activate via www.skype.com . This allows you to divert all incoming Skype calls to your voicemail.
Can I send instant messages (chat) via my DUALphone?	No.
Can I associate a picture with my Skype account?	Yes. However, you have to sign in to your Skype account via your computer and upload the picture from there. Skype will automatically change the uploaded picture to the correct size. In order to have the best picture quality we recommend that you upload a 96 x 96 pixel picture. You can upload in JPG (.jpg) as well as bitmap (.bmp) format.
Which protocol does my DUALphone use?	The Skype part of your DUALphone uses a protocol of its own. The HTTP protocol is used for Firmware updates and all data transmissions are encrypted.
How long is the talk time on fully charged batteries?	Minimum 10 hours.
How long is the stand by time on fully charged batteries?	Up to 140 hours.
Do I need a computer?	No, there is no need to have a computer – simply connect the DUALPhone base station to your broadband router or modem. If you want to use the landline connection feature, you will also need to connect the base station to the landline connection.
How many Skype contacts does the DUALphone support?	250.

QUESTION	ANSWER
Which headset works with the DUALphone?	The connector is of the mono type and the plug size 3.5 mm. Please note that not all headsets will be suitable. Ask for a set with an impedance of 30 Ohms or higher. We recommend that you use the Plantronics Backbeat 116 headset.
I don't have a land-line wall receptacle near the place where I want to put the DUALphone base station and I don't want to do install new telephone wires between the base station and the landline receptacle. What do I do?	We recommend that you purchase a wireless phone jack, which can be installed in 1 minute. Please visit www.wireless-phonejack.com .
Does the Skype online status Do not disturb work with landline calls?	Yes, you will not be disturbed by any landline calls, but you can see the calls under missed calls
Why does call forward not work?	If your calls are forwarded to a phone or mobile number be sure to have enough Skype Credit on your Skype account, otherwise your calls will not be forwarded. If your calls are forwarded to another Skype user, this must be someone in your contact list, otherwise your calls will not be forwarded. (NOTE: if both call forwarding and voicemail are set up, incoming calls will first be forwarded to the call forward number, and if not answered here the call will be sent to your voicemail instead).

■ CE DECLARATION OF CONFORMITY

This product is manufactured for RTX Products Hong Kong Limited. Please also refer to the introduction in the Installation Guide and User Manual, guarantee and safety & warranty information sheets.

The DUALphone 4088 complies with the requirements of EC directives:
99/05/EC Directive for radio facilities and telecommunication terminals

Conformity with essential requirements of Council Directive 99/05/EC is assured according to:

R&TTE	Directive 99/05/EC	Standard: EN301406 V2.1.1 (2009-07)
-------	--------------------	-------------------------------------

Additionally, the DUALphone 4088 is in conformity with the directives below:

EMC	Directive 89/336/EC	Standard: EN301489-1 V1.8.1 (2008-04) Standard: EN301489-6 V1.3.1 (2008-08)
Safety	Directive 77/23/EC	Standard: IEC/EN60950-1 2ed. + A11:2009 + A1:2010
Health/SAR	Recommendation 99/519/EC	Standard: EN50361, EN50385


Due to existing differences between public telecommunication networks in different states, this authentication does not in itself constitute an unconditional guarantee of the successful operation of these units on every network terminal point.

Intended use:

The DUALphone 4088 is designed to switch onto the analogue telephone network via the normal telephone socket and a LAN interface on a broadband connection. Any other use is deemed as not intended use.

The company does not accept any claims resulting from unauthorised alterations or modifications not described in this user manual.

Denmark, Noerresundby, 10 March 2012



Peter Christensen
RTX Products Hong Kong Limited
Stroemmen 6
9400 Noerresundby
Denmark
Telephone: +45 96322300
Fax: +45 96322310