

WR5-64C22V Simplified Instructions

Features-

- Full Function Radio Control.
- 2.4GHz Frequency – allows up to 3 vehicles to run at the same time.
- Wheel Alignment – Adjust the wheel alignment located on bottom of vehicle between front wheels.
- Controller charges vehicle
- Lights

Transmitter Functions - How to Drive:

- Forward Driving – Push left joystick forward for forward driving.
- Reverse Driving – Pull left joystick back for reverse driving.
- Left and Right Steering – Move the right joystick left to turn left. Move the left joystick to the right to turn right.

Required Batteries (Not Included):

Transmitter – 2 "AA" batteries

Install Batteries in the Controller:

1. Remove screw to open battery compartment.
2. Insert 2 "AA" batteries in the battery compartment at the back of the controller. Be sure the (+) and (-) are properly matched.
3. Replace compartment cover and secure with screw.

Note: When replacing batteries:

- Use Alkaline batteries only.
- Do not mix old and new batteries.
- Do not mix Alkaline, Standard and Rechargeable batteries.

Pairing Transmitter to Vehicle:

Before first use and after any time the batteries are replaced, the transmitter must be paired to the vehicle.

To sync transmitter and vehicle, follow the steps below:

1. Correctly install batteries in the transmitter.
2. Place vehicle upside down, and turn Vehicle ON/OFF switch to the ON position. The vehicle is only in sync mode for 30 seconds.
3. Immediately push the left joystick on the transmitter forward and hold it in place. Keep holding until wheels move (up to 30 sec.).

Lights

- When the vehicle is in motion the lights will turn ON.
- Lights will turn off when vehicle stops.

Steering Trim:

Adjust the steering trim located underneath the vehicle between the front wheels.

Charging the Vehicle:

1. Move vehicle ON/OFF Switch to the OFF position.
2. Raise the Charging Stick on controller.
3. Align the Charging Stick with the Charging Port, located on the underside of vehicle.
4. Plug the Charging Stick into the vehicle Charging Port.
5. Indicator light on controller will turn on. When charging is completed, in approximately 6-8 minutes, the charging indicator light will turn off.
If indicator light is flashing while vehicle is connected it means the batteries in the controller do not have enough power to charge the vehicle and should be replaced.

Notes:

- 1 Operate the vehicle within 80 feet range.
- 2 Switch off the toy when not in use.
- 3 Remove all batteries when not in use long periods.
- 4 If the vehicle is not functioning properly, replace batteries or check for electrical interference.
- 5 Adult Supervision recommended.
- 6 Please remove all packaging attachments before giving this toy to your child.

The reception performance may be affected under a strong interference disturbance environment.

This product would not perform normally under a strong electrostatic environment.

The instructions must be kept since it contains important information.

We wish you many happy hours of pleasure with your toy.

TROUBLESHOOTING

Problem- Vehicle does not move or moves slowly.

- Has the internal battery in the vehicle been fully charged?
- Make certain there are fresh alkaline batteries in the transmitter and that they have been installed in the correct position.
- Are the (+) and (-) markings on the alkaline batteries in the same position as the (+) and (-) markings in the Transmitter Battery Compartment?
- Make certain that the vehicle ON/OFF switch is in the "ON" position.

Problem - Vehicle moves by itself or exhibits reduced range from the transmitter.

- Make certain there is no outside radio interference in your area. The best way to test this is to take the vehicle as far away from radio towers, electrical lines or tall buildings as possible to ensure no further radio interference will occur.

FCC CAUTION:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Contact Motor Dayz Customer Service at:

1-248-863-3000
Monday – Friday
8:00am to 5:00pm Eastern Time

Motor Dayz Customer Service
3000 N. Pontiac Trail
Commerce Township, MI 48390
www.motordayz.com

ENGLISH