



## HOW TO USE

1. TURN DOWN THE VOLUME OF THE CAR CASSETTE DECK.
2. PREPAIR THE MP3 PLAYER WORK FINE.
3. INSERT THE FM-TX08 INTO THE CAR CIGARETTE LIGHTER SOCKET OF DECK,AND PULL OUT THE AUDIO WIRE PLUG THEN INSERT TO THE FM-TX08'S CONNECTOR END(INPUT) INTO MP3 OR ANY AUDIO SOURCE. (CONNECTING AS FIGURE 1).
4. START MP3 PLAYBACK AND ADJUST THE VOLUME.
5. SELECT THE FREQUENCY EITHER OF SUCH AS 88.1,88.3 88.5,88.7,107.3,107.5,107.7,107.9 ON THE FM-TX08.
6. SELECT THE SAME FREQUENCY ON THE CAR CASSETTE DECK SAME AS FM-TX08,TURN THE VOLUME OF DECK WHICH YOU LIKE.

## CAUTION:

1. IF NO SOUND IS HEARD,PLEASE CHECK THE FM-TX08'S INDICTOR(LED) WHETHER IT IS LIT UP, OR CHANGE THE DIRECTION OF THE FM-TX08 ON THE CAR CASSETTE DECK. OR PUSH UP THE PUSH KNOB(AS FIGAUE 2).
2. TO REMOVE THE FM-TX08,PLEASE PULL IT OR OUT CAREFULLY WITH PROPER FORCE FROM THE CAR CIGARETTE LIGHTER SOCKET OF THE CAR CASETTE DECK.

3. IT IS NORMAL FOR THE FM-TX08 TO GET WARM WHEN IN USE.
4. DO NOT EXPOSE THE FM-TX08 TO THE RAIN OR MOISTURE.
5. DO NOT BY EXCEED YELLOW MARKER THEN PULL OUT AUDIO WIRE.(FIGAUE 3)
6. INPUT VOLTAGE: 12VDC.

## FCC Compliance and Advisory Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try correct the interference by one or more of the following measures:

- Reorient the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into and outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.