

---

# **PSP FM 3 channels audio stereo transmitter (BW007A-3F)**

## **Instruction Manual**

### **The FCC wants you to know**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions.

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

**Change or modifications not expressly approved by party responsible for compliance could void the user's authority to operate the equipment.**

---

## ***Main Function:***

- 1.Appropriate PSP 3 channels audio stereo transmitter
- 2.Frequency channel: 88.1 / 88.5 / 88.9MHz, 3 channels through transforming the switch.
- 3.Inside PSP decode port;
- 4.Connecting PSP power supply directly.

## ***Function of the switch:***

SW to → left : 88.1MHz middle : 88.5MHz right : 88.9MHz

## ***Operation instruction:***

### **一. Precondition**

Open your PSP on, when there is frequency output needed to be transformed to, put the data port and frequency port of this FM stereo transmitter insert into each relevant frequency port of your PSP console.

Open this FM stereo transmitter on then, Switch the channel to any of the following 3 channels : 88.1 / 88.5 / 88.9MHz, then you can receive the music from PSP console.

### **二. FM frequency channels transforming:**

When you need to transform frequency between every channels, ensure already have inserted into the PSP frequency port correctly, switch “SW” which is on the body side face, the channel point to is the current emission frequency one. After this FM stereo transmitter is transformed to the relevant frequency channel too. Transform is done.

### **三. Volume measure**

Turn the volume of your PSP console directly, ensure no distortion emission status, keeping the volume of your PSP as much as possible, the SNR will be increase. As some sound supply is too large in relatively, if there distortion happens, turn a little lower of the output volume of your PSP. In order to keep voice no distortion.

### **四. Note**

When FM stereo transmitter is not in use, keep it off your PSP console in order to save power.

