## 1. Set-Up

- Power up the device using the adaptor and cable that comes from the box.
- Unit will initialize (pan/tilt). Wait for the audio prompt and front LED start flashing red.
- Open Lorex connect app and add a device (+) at top right corner, not add the device in the middle.

- Make sure to enable Bluetooth in mobile devices for connectivity.

Select **IC501A** and then it will search for devices then add IC501A that as found

Select the desired network. The camera supports 2.4GHz and 5Ghz. Input the password of selected Wi-Fi then name the camera.

Preview: Tap device to see live view (Top camera), slide to left to see the bottom camera

2-way talk: Use siren button, call button, speaker icon, or talk button to verify this.

Pan & Tilt： For the top camera check Pan, tilt function. Click PTZ, click to control PT.

Playback: Click Playback to play the recordings

Note: need install the SD card.

Call function:

In the actual camera, tap the call touch button two times to enable two-way talk > App will get notification and should be able to answer the call. During this process you will see that the call touch button will be flashing blue.

FCC Regulations

- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

  (1) This device may not cause harmful interference, and

  (2) this device must accept any interference received, including interference that may cause undesired operation.

- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

  —Reorient or relocate the receiving antenna.

  —Increase the separation between the equipment and receiver.

  —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

  —Consult the dealer or an experienced radio/ TV technician for help.

- Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

FCC RF Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. To comply with FCC RF Exposure compliance requirements, this grant is applicable to only Mobile Configurations. The antennas used for the transmitter must be installed to provide a separation distance of at least 20cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.