

Lorex


Baby Camera

User Manual



Ver. 1.0

Overview




Getting Started

Power On

Please connect the camera with the provided power adapter.

Press Power button  for 1 second, you'll see the red light flashing and then change to orange in a few seconds. That means the camera is ready.



Before you start, you need:

1. Please download [LOREX WONDER] from Google Play or Apple Store on your mobile before camera setup.




LOREX WONDER

2. Before connecting your camera to internet, please make sure you have a WiFi AP and a mobile connected to internet.



WiFi AP



Mobile

Connect camera to internet

LOREX Baby

Now you need to do two things. First, setup a WiFi AP for your camera. Second, add the camera to your mobile.

1) Setup a WiFi AP for your camera

Step 1.

(iOS)




(Android)




Turn on Wi-Fi on your mobile and select camera (Lorex-XXXXXX) as the AP. This will enable a connection between your mobile and camera.

Step 2.




Tap to run LOREX WONDER APP.

Step 3.



Tap in main page.

Step 4.



Choose the camera and tap .

Connect camera to internet

LOREX Baby

Step 5.



Tap  to select the WiFi AP for camera to connect internet.

Step 6.



Password is strongly recommended.
And then tap .

Tap  to go back to main page.
Camera LED will flash and turn to steady green.

Connect camera to internet

LOREX Baby

2) Add the camera to your mobile

Step 7.



(iOS)



(Android)


Press  (iOS) or  (Android) to go to your mobile settings.

Step 9.




Run LOREX WONDER  APP. Tap  to add the camera to your mobile.

Step 8.



You need to switch the AP or 3G/4G for internet connection.

Step 10.



Tap  to scan your camera ID or you can key-in camera ID manually. (for Android: you will be guided to install barcode scanner app if it's not on your mobile.)

Connect camera to internet

LOREX Baby

Step 11.



Tap and then shoot a picture for easy camera identification.


Step 12.



Tap , then tap . Your camera is added.

3) Start Live View

Step 13.



You will see your camera in main page. Now tap you camera name.

Step 14.




You should be able to live view from your camera now.

Audio & Video features

LOREX Baby



Tap to take a photo to your mobile storage.



Tap to record a video to your mobile storage. and tap again to stop.



Tap and start talking, your baby will hear your voice from camera. And tap again to stop.




Tap to mute the sound from the camera.

Audio & Video features

LOREX Baby



Tap **LCD** for audio only monitoring.



Video recorded on mobile




Photo taken on mobile



Video record on camera when any alert goes off

Lullaby & Controls



Control night light in 3 levels




Alert Notification

Camera provides 3 kinds of alert settings to monitor your baby.

1. Audio Detection
2. Motion Detection
3. Temperature Alert

An alert email and mobile message will be sent to you if any of alert settings go off.

Step 1.



In main page, tap  and go to setup page for [Alert Notification] setting.

Step 2.



Setup alert settings and enter e-mail address then tap .

Getting Help


Q1: Do I need to go from step 1 to step 14 all over again if there's another mobile'd like to get connected as well?

A1: If you've completed the internet connection of camera with the 1st mobile, you could just start from step 7 for the other mobile(s).

Q2: If I'm outdoors and have no internet access, how do I make the camera work?


A2: If you're outdoors and AP is not available, there's a simple way for you to see the camera.

Step 1.




Press the Mode button  for 1 second, LED will turn to steady orange.

Step 2.




Turn on Wi-Fi on your mobile and select camera (Lorex-XXXXXX) as the AP.

Step 3.



Tap  to run LOREX WONDER APP.

Step 4.



In main page, tap  then tap camera name directly.

Getting Help

Q3: How to power off your camera?

A3: You can press Power button  for 3 seconds to turn it off (with 3 beep sound).

Q4: What can I do when camera is no response?

A4: You can press Power button  for 10 sec to reset camera back to power off state. To turn on camera again, you need to press Power button  twice.

Q5: How to use WPS button?

A5: You can use WPS button to connect camera to internet.

Step 1.



Step 2.



Press the WPS button on AP.

Press WPS button on camera, LED will flash and turn to steady green when connected.

You can go to page 5, step 7 to step 14 to start live view.

LED & Beep

Condition	LED	Beep
Power on	Steady red for 20 seconds	N/A
Power off	No indication	3 times
Connect to internet	Connecting: Flash green Connected : Steady green	N/A
Fail connect to internet	Flash red for 10 seconds then turn to orange	N/A
Low battery	No indication	3 times
Firmware upgrade	Flash between green and orange back and forth, and turn to steady green when completed	N/A

FCC Regulations:**§ 15.19 (a)(3)**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 (b)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Exposure Information (SAR)

This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government. The exposure standard for wireless devices employs a unit of measurement known

as the Specific Absorption Rate (SAR). The SAR limit adopted by the FCC is 1.6W/kg for an uncontrolled environment. Tests for SAR are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands. The FCC has granted an Equipment Authorization for this device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines.

Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This is because the device is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

IC Regulations:

RSS-Gen 7.1.3

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement."

CAN ICES-3(B)/NMB-3(B)

IC RF Exposure Statement (SAR)

This device is tested in accordance with the measurement requirement and procedure specified in IEEE 1528 and IEC 62209. This device complies with SAR for general population/uncontrolled RF exposure limits in IC RSS-102.

All trademarks belong to their respective owners. No claim is made to the exclusive right to use the trademarks listed, other than the trademarks owned by Lorex Technology Inc. We reserve the right to change models, configurations or specifications without notice or liability. Product may not be exactly as shown. Images are simulated.

Distributed by/Distribué par/Distribuido por
LOREX CORPORATION
901 Elkridge Landing Road, Suite 100, Linthicum,
Maryland 21090
Technical Support and Customer Service: 1-905-940-5355
© 2013 Lorex Technology, Inc.



Made in China / Fabriqué en Chine / Hecho en China