


**'TailWindS' Bluetooth StereoWireless™ Sporty Wearable TWS Speakers**



- [1] Bluetooth/play/call ○ button
- [2] volume + / next track ○ button
- [3] volume - / previous track ○ button
- [4] Bluetooth LED (under speaker cloth)
- [5] built-in mic. for speaker phone function (under speaker cloth)
- [6] input recharging port – micro USB under the cover
- [7] LED for charger indication
- [8] wearable neckband for speakers
- [9] dual micro USB recharge cord

#### Product Features

- 'Click-and-Go' Neckband Wearable- amazing 3D sound effect
- Detachable as a pair of TWS speakers
- IPX-4 splash proof for sporty actions
- 2W+2W stunning surround stereo
- hands-free & ears-free when doing sports
- bass vibration effect- great for gaming
- handsfree call pick function
- Bluetooth v5.0 wireless


#### Charging the speakers

- i) lift up BOTH speakers' rubber cover, plug recharge cord the micro USB ends;
- ii) plug recharge cord the USB end to an USB power source;
- iii) RED LED lights up, indicates charging;
- iv) when fully charged (approx. 1.5 hrs), LED will turn into GREEN


#### Wearing the speakers

1. snap in the speakers to the holder ring on the wearable neckband,
2. (speakers facing upwards; buttons' side near to neckband ends for ease of access),
3. bend open the neckband a bit wider for ease to put this product on the neck around the shoulders,
4. do the other way around step 3>2>1 for taking off headset and snap back to the charger case to carry

**\*NOTE\* This is a pair of \*TWS\* Stereo speakers - you need to power ON BOTH speakers together to let them pair themselves first!!!**



In case accidentally you have paired only ONE side with your phone > Delete all previous 'TailWindS' from your phone's Bluetooth list, and then turn phone Bluetooth OFF, and then ON again to repeat below steps 'Pairing the speakers'...



#### Pairing the speakers


- a) Press & hold Bluetooth/play/call ○ button ● 3s for **BOTH L&R** speakers at the same time, until hear 'dodooo...';
- b) Speakers are turned ON, both LEDs flashing fast (**L side Blue LED; R side White LED**) > then 'dodu' sound;
- c) wait about 5 sec till one speaker automatically paired the other (hear 'dodu'; **R** speaker **White** LED lit constant; main **L** speaker Blue LED flashing fast) > ready for pairing with phone;
- d) phone Bluetooth ON, search and select (TailWindS);
- e) hear tone 'buloop', (main **L** speaker Blue LED lit constant);
- f) now pairing with your phone is successful (as a pair of Stereo Wireless™ Bluetooth TWS speakers);
- [Besides wearing on shoulders, you can opt to place the 2 speakers apart 1~2M in between, for desktop use with stereo effect]

#### Disconnect the speakers

- g) switch off phone Bluetooth function,
- h) main speaker Blue LED will flash fast;
- i) both speaker then press & hold Bluetooth/play/call ○ button ● 3s until hear 'beepbeep' > OFF, (the pairing memory will be kept there);

#### Re-connect Phone

- j) (previous phone Bluetooth ON, before turn on speakers)
- k) press & hold Bluetooth/play/call ○ button ● 3s for **BOTH** speakers at the same time, until hear 'dodooo...';
- l) wait about 5 sec till one speaker automatically paired the other (hear 'dodu'; second **R** speaker **White** LED lit constant; main **L** speaker Blue LED flashing fast) >
- m) wait 5 sec...hear tone 'buloop', (main speaker Blue LED lit constant);
- n) pairing successful again



(-con't)

(-con't)

**Pair with another / new phone**

- a) switch off Bluetooth function on your previous phone,
- b) then power on the another / new phone's Bluetooth function.
- c) ...main speaker hear 'beep beep' (blue LED flashing fast);
- and then you repeat steps as in above d) to f).

**Play / Pause music**

- click Bluetooth/play/call ○ button ● = play (from player previous track position)
- click Bluetooth/play/call ○ again ● = pause

**Adjust volume**

during music playback or call,

- click volume + / next ○ button ● = increase volume;
- click volume - / previous ○ button ● = reduce volume.

(You may multiple clicks until adjust volume to desire level)

**Next-forward / Previous-backward**

during music playback only,

- press & hold volume + / next ○ button ● = next track;
- press & hold volume - / previous ○ button ● = previous track.



**Call-pick / end / reject / redial - \*\*(main speaker only)**

- during incoming call, (if playing music > stop)
- > hear 'ring, ring, ring...'
- click Bluetooth/play/call ○ button ● = call pick, then talk;
- click Bluetooth/play/call ○ again ● = call end (resume music playing);
- OR Press & hold Bluetooth/play/call ○ button ● 1s\* = reject call directly (resume music playing)
- at NO incoming call, double click Bluetooth/play/call ○ button; ●● = redial last no. in call out history of the phone

**Battery low > recharge**

There will be some beeping alert sound during playback. Then charge the 2 speakers as mentioned steps in above section.

(You can play music at the same time while charging...)

**Troubleshooting**

If you come across some problem such as

- only L side main speaker has sound, not as a pair, and/or
- too many same speaker pairing name appeared on your phone
- sudden sound dropped and cannot link again to play normally

- 1) switch OFF BOTH L & R speakers,
- 2) plug and recharge L & R speakers, until BOTH speakers' LED lit GREEN (fully charged),
- 3) clear/unpair all speaker pairing names from your phone's list,
- 4) turn OFF Bluetooth from your phone, and then

**RESET speakers to factory setting**

- 5) Press & hold Bluetooth/play/call ○ button ● 3s for L main speaker to power ON,
- 6) press & hold volume - / previous ○ button ● 15s\*, until hear 'beepbeep' and Blue LED blinking,
- 7) (now all previous pairing memory are cleared for L main speaker), repeat E. to switch OFF this speaker;
- 8) Press & hold Bluetooth/play/call ○ button ● 3s for R sub speaker to power ON,
- 9) press & hold volume - / previous ○ button ● 15s\*, until hear 'beepbeep' and Blue LED blinking,
- 10) (now all previous pairing memory are cleared for R sub speaker), repeat H. to switch OFF this speaker;

(Then you can repeat above steps a)~f) for new pairing again and use ...)

**Specifications:**

dimensions:	W 198 x D 45 x H 187 mm (including wearable neckband);
product weight:	169g
Bluetooth wireless connection	v5.0; class II; typ. 8M visible distance; max. 10M
driver:	dia. 31mm
driver max. output :	2Wx2
signal to noise ratio:	>=85db
built-in 3.7V Li-polymer rechargeable battery	
battery charging voltage	typ. 5V; max. 5.5V DC (via. USB port)
battery charging current	500mA max.
battery charging time	1.5 hours.
playback time	up to 5.5 hours
(fully charged, volume at 1/3 level)	
standby time	up to 12 hours

**Note-**

\*The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Manova International Limited is under license. Other trademarks and trade names are those of their respective owners.

\*Design and specifications are subject to change per technical needs, without prior notice

**FCC Warning**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.