

Remote control operation instructions

RCS25

IMPORTANT SAFETY INFORMATION

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1)

This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC warning:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

IC warning

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:


(1) this device may not cause interference, and (2) this device must accept any interference, including interference

that may cause undesired operation of the device. Le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. Le dispositif peut être utilisé dans des conditions d'exposition portatives sans restriction.

Operating by Remote Handset

Ensure that 2 AAA batteries are installed into the remote control handset. The battery power level is indicated by the column of bars to the right side of the temperature display when the appliance is in standby mode. 5 bars indicate the batteries are full, and 1 bar indicates the batteries are empty and need to be replaced immediately.

Multifunction Infrared Remote Handset



ICON	TITLE	FUNCTION
	POWER	Press the POWER button to turn the appliance on and off. The appliance will resume the previously selected settings when turned on (except Thermostat and Timer).
	PRESET	Press the PRESET button to turn on/off the preset function. To save your favorite lighting effect as the present, press and hold the PRESET button for 3 seconds.
	+/-	Press + or - to adjust the settings for each of the separate functions. After pressing FLAME, DOWNLIGHT, SOUND, EMBER,

		TIMER, or THERMOSTAT buttons (within 10 seconds) use
	HEATER	Press the button to cycle from ON to OFF , press '+' or '-' to set the temperature ('←' or '→' to set the temperature is also acceptable if needed). Press button to reset from manual mode.
	FLAME	Press the FLAME button to cycle through 9 flame colors and OFF. Use +/- to control brightness.
	EMBER	Press EMBER button to cycle through 13 colors, rotating colors, and off setting. Use +/- to control brightness.
	ACTIVEEMBER BED	Press the ACTIVE EMBER BED button to turn the feature ON and OFF. Use +/- to control brightness.
	DOWNLIGHT	Press the DOWNLIGHT button to cycle through warm, cool, and OFF setting. Use +/- to control brightness.
	SOUND	Press the SOUND button to cycle through Active Fire (S.01), Mature Fire (S.02), and OFF settings. Use +/- to control volume.
	TIMER	Press the TIMER button to turn timer ON and OFF. Initial setting when turned on is 0.5H. Use +/- to control timer settings up and down.
	THERMOSTAT	Press the THERMOSTAT button to toggle between ON and OFF. Use +/- to increase or decrease the temperature set point. Press and hold the THERMOSTAT button for 3 seconds to switch between Celsius and Fahrenheit.

