



# OPERATION MANUAL

CADENT  
**iTero**<sup>TM</sup>  
*creating the perfect byte.*

**Wireless Foot Pedal**  
**P/N EA03586**  
**FCC ID: UZ2EA03586**



## Foot Pedal Maintenance

### Checking Foot Pedal Battery

The foot pedal unit contains two AA 1.5V batteries. It is recommended to keep back-up batteries of this type in your office.

When battery is low, the following indications will be provided by the system:

- ⇒ Pressing a foot pedal causes no response within the iTero Scanner software.
- ⇒ A warning dialog requests that the battery be replaced.




### Replacing Foot Pedal Battery

To change the foot pedal battery, follow the instructions below:

1. Open the battery cover



2. Replace batteries with new ones and close the cover.



**CAUTION:** Be sure to follow local governing ordinances and recycling instructions regarding disposal or recycling of batteries.

**CAUTION:** Refer to qualified service personnel for verifying that pedal dongle is assembly on HDU cart.

## FCC Radio frequency interference statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Cadent Ltd. is not responsible for any radio or communication interference caused by using other than specified or recommended cables and battery or by unauthorized changes or modifications to this equipment. Unauthorized changes or modification could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.