



PAX TECHNOLOGY LIMITED

PINPAD Instruction Manual

(SP20, SP30, S200, S300)

1. Instructions

PINPAD connect to POS or ECR by a communication line for entering password during transaction process. In order to correct using, you should refer to following instructions.

1) Magnetic Stripe Card

Put magnetic stripe side of magnetic card towards device interior, swipe the card with a steady speed during through magnetic reader slot. (Support bi-directional swiping)

2) IC Card

Put IC card chip side upward, push-in IC card slot and to bottom.

3) Tap contactless card (optional).

Put the contactless card into the sensing area above the LCD

4) SAM Card

① Remove the SAM card cover (At the bottom of the terminal).

② Insert the SAM card to the corresponding card slot.

2. Installation and Usage Tips

- 1) Avoid putting the terminal in direct sunlight, high temperature, moist, or dusty environment.
- 2) Forbid non-professional to repair the terminal.
- 3) Before insert the card, please check internal and around of IC card slot . when you found some suspicious objects , must report to related administrator.

3. Password Entering Tips:

It is highly recommended to enter password as following ways:

- 1) Set up peep shields. Enter password with shield by the structures of cashier desk;
- 2) Place the POS terminal at an appropriate angle and make sure it is difficult to peer the password.
For example, the POS was installed above the movable bracket.
- 3) In enter password perspective, avoid surrounding video surveillance;
- 4) Paste text instructions to remind the customers to shelter with body or palm when enter password.
- 5) Merchants can also choose other ways to protect the customer input password.

PAX TECHNOLOGY LIMITED

To know more product details, please visit <http://www.pax.com.cn>

P/N: 20031200000199

Caution:

This device complies with Part 15 of the FCC rules and Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or change to this equipment. Such modifications or change could void the user's authority to operate the equipment.

This radio transmitter (identify the device by certification number or model number if Category II) has been approved by Industry Canada to operate with the antenna types listed below with the maximum permissible gain indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.