Troubleshooting

- Operating System requests for Device Driver installation
- → *If AT77UR100 has been connected to the PC before software installation, then uninstall the device in device manager and restart the setup in the correct order.*

- Fingerprint image poor quality
- → *Improve finger swipe by:*
  - *starting at last knuckle joint and swiping to finger tip,*
  - *keeping finger flat against sensor*
  - *maintaining consistent pressure over sensor throughout swipe*

5290-BIOM-10/07

AT77UR100 WELCOME AND QUICK START GUIDE

Dear Valued Customer,

Thank you for choosing FingerChip® for your biometrics needs.

Atmel's FingerChip fingerprint solution for notebook applications offers in one package the most reliable and highest performance fingerprint sensor on the market together with a comprehensive security suite.

This device is intended to acquire fingerprints when connected to a Personal Computer.

Learn more and download recent updates by connecting to Atmel's Biometrics Products website at www.atmel.com/products/biometrics. We also invite you to contact us at support.fingerchip@atmel.com for any assistance we can provide.

Best regards,

Your Atmel Biometrics Team

Package Contents

- 1 AT77UR100 USB Reader
- 1 CD-ROM
- FingerChip® Security Chipset Flyer
- UR100 Quickstart Guide

ADAPTING UR100 TO YOUR NOTEBOOK

System Requirements

- PC 32-bit or 64-bit with CD-ROM reader
- Windows XP Professional editions,
  Windows Vista Business or Ultimate editions
- 512 MB RAM
- 1 USB 2.0 communication port available

Demonstration Software Installation

⚠ *Perform Demonstration Software Installation before plugging in your AT77UR100 USB Reader.*

- Insert CD-ROM in your PC
- Select Install FSP Demo from main page menu

Note: You must have Administrator rights to run this utility.