


User Manual
Floor Lamp
FCC ID: VVO-DSDYKQ

Introduction

Thank you for choosing our Floor Lamp. Please read the user manual carefully and keep it for future reference. If you need further assistance, please contact customer support.

Package Contents




Specifications


Model	MF19334
Input Voltage	AC110-120V 60Hz
Maximum power	60W
Material	Metal
Dimension	D250*H1670mm

Connection Introduction

1. For better installation, please tighten the connection bracket, then screw each two parts clockwise in order.





2. Please tighten the bottom and the lamp base secondly.



Operation Introduction

There is a on/off foot switch.



-  Short press for turning on/off.
-  Short press for 1 hour timer, will be released once pressed any other buttons.
-  Short/long press to enhance the brightness as you like.
-  Short/long press to change three color temperature from 3000 - 4500 - 6000 K step by step or step-less.

When can you use the remote control?

One intelligent bulb is included in the package. You may use regular bulb to replace the intelligent bulb if you prefer that. Please note that regular bulb cannot match the remote control. Need to repair the remote control and bulb if you replace one of them. Please check the repair method below. Foot switch is the prerequisite for remote control. Make sure you have turned on the lamp with the foot switch when you are using the remote.

How to Repair the Remote Control and the Bulbs if the Remote is not Working?

- 1, Turn off the lamp with the foot switch firstly
- 2, long press .
- 3, Keep on pressing the button and turn on the lamp with the foot switch.
- 4, The lamp will flash for two times means repair is done.

Cautions

- Do not put the lamp close to TV or other radio devices to avoid noise
- Do not repair, disassemble, or modify under any circumstances
- Do not place near any heat source or in direct sunlight
- Do not place the lamp on uneven, insecure floor
- Do not use appliance with frayed or damaged electric cords
- Do not touch electric appliance with wet hands or when liquids are present
- Please keep the lamp and all appliances dry and clean
- Unplug the adapter when the lamp is not used
- Power off before cleaning
- Clean the lamp only with a soft dry cloth
- Never overload electric circuits as it may cause electrical shock or fire

Warranty

We warrant Floor Lamp for 12 MONTHS from date of the original purchase. If the lamp fails due to any manufacturing defect, please contact support with your purchase order ID and details of the problem.

We only provide after sales support for products purchased from our authorized distributors. If you have purchased the product from a seller other than , please contact your seller for warranty cover.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in the exposure condition without restriction.