




RBW 3 MHz
* VBW 3 MHz
Ref -10 dBm Att 20 dB SWT 100 ms

I PK *
CLRWR

★
A
SGL



Duty Cycle
$$= [7(0.85) + 89(0.35)]/100$$
$$= (5.95 + 31.15)/100$$
$$= \underline{0.371}$$

Average Factor
$$= 20 \log (0.371)$$
$$= \underline{-8.6 \text{ dB}}$$

Center 433.956 MHz

10 ms /

