


DD2152HT

Emitter Instructions

Version: A/o

Instruction Of Buttons

Note: 1,For the emitters without setting button like DD2152HT, you can press up button and stop button at the same time to work as the same function as setting button.
2,After the operation is completed, after the back cover of the emitter is closed, please screw on Turnbuckle of the back cover.



Technical specification


Battery: 3V (CR2430)	Transmitting power: 10 milliwatt	Radio frequency: 433.92MHz
Working temperature: -10°C~50°C	Radio range: 200 meters outdoor, 35 meters indoor	

Warning

- 1, Emitter couldn't expose to moisture or be struck heavily, or else the emitter line will be affected.
- 2, If the emitter is not so sensitive or the radio range becomes shorter, pls check whether to change the battery.
- 3, It's forbidden to use different type battery to avoid any dangerous risk.
- 4, Dispose of used batteries properly.

Max. Channels Adjustment

Max. channels. Press CH+ or CH- button to



RF exposure statement

This equipment complies with the FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Tool Warning

(1) This device may not cause harmful interference, and (2) this device

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the

instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna
 Increases the separation between the equi-

- Increase the separation between the equipment and receiver
- Connect the equipment into a circuit so that no circuit is different from the others

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.