

# Slumber 2



## Interactive Setup Guide

**Version 1.5**

**Start Setup**

< Back

# Main Menu

1. Before You Start
2. Button Functions
3. How to Charge
4. Use Bluetooth Mode
5. Use White Noise Mode
6. Use AUX Wired Mode
7. Advanced Features
8. Common Errors & Fixes
9. Register Your Product
10. Live Agent Help
11. Rate This Guide
12. Advocate for Us

Next

< Back

Back to  
Menu




## 1. Before You Start

- Pillow Speaker – Place it on your pillow to help you sleep.
- Play audio via Bluetooth or use built-in white noise.
- Remote has a battery, or connect to power for all-night use.


Next

< Back

Back to  
Menu



## 2. Button Functions



### MP3/BT

- Press to switch modes.
- In BT, hold 3s to pair.
- In MP3, hold 2s to cycle modes.



- Press to set/cancel timer (30/60/90 mins).


Next

[Back](#)[Back to  
Menu](#)

### 3. How to Charge

- Use USB-C (5V, 0.5~2A) to charge.
- Fully charged: LEDs turn solid for 5s then off (~1.5 hrs).
- Low battery: Left LED blinks **white** (<10%).
- Playtime: up to 10 hours.

[Next](#)

[< Back](#)[Back to  
Menu](#)

## 4. Use Bluetooth Mode

### 4.1 Ideal Placement

Place Slumber on top of your pillow, inside the pillowcase, for minimal sound leakage.



**Note:** Position the zippered side facing down.

[Next](#)

[Back](#)[Back to  
Menu](#)

## 4. Use Bluetooth Mode

### 4.2 Enter Bluetooth Mode

Slide the switch to 'ON' to auto-pair. 'BT' LED flashes **red & blue**.

If not, hold 'MP3/BT' button for 3s to pair.

[Next](#)

< Back

Back to  
Menu




## 4. Use Bluetooth Mode

### 4.3 Connect Your Phone

1 On your phone, turn on Bluetooth.

2 Select '**Slumber 2**' from the list.

Once connected, '**BT**' LED stays **blue**.



Next

< Back

Back to  
Menu



## 4. Use Bluetooth Mode

### 4.4 Reconnect Tips

- Auto-connects to last device after turning on.
- If not, select '**Slumber 2**' on your phone to reconnect.
- Still not working? Re-pair manually.

Next

< Back


Back to  
Menu



## 4. Use Bluetooth Mode

### 4.5 Adjust Volume


Adjust the volume on both the Slumber and your device.



Next

< Back

Back to  
Menu



## 5. Use White Noise Mode

- 1 Turn on & press to switch to 'MP3'.
- 2 Hold 2s to cycle playback modes.  
"MP3" & related LED stays **white**.

**Note: MP3 Mode = White Noise Mode**

Slumber has 20 built-in white noise tracks.  
No memory card is needed.



Next

< Back

Back to  
Menu




## 6. Use AUX Wired Mode

- 1 Unplug the remote.
- 2 Plug the Slumber into your device's AUX jack.
- 3 Play the audio.



Next

[< Back](#)[Back to  
Menu](#)

## 7. Advanced Features

### 7.1 Remove & Install Pillowcase

The pillowcase can be removed to hand or machine washed.

[Next](#)

< Back

Back to  
Menu



## 7. Advanced Features

### 7.1 Remove & Install Pillowcase

When installing, ensure the '**BACK**' side faces the zipper.



Next

[Back](#)[Back to  
Menu](#)

# 7. Advanced Features

## 7.2 Setting a Sleep Timer

Press  button to set or cancel timer (30/60/90 mins).

[Next](#)

[Back](#)[Back to  
Menu](#)

# 7. Advanced Features

## 7.3 How to Reset

1. Turn on Remote.

2. In **BT** mode, hold **+** for 10s.

'**BT**' LED turns pink, then blinks **red** & **blue**.

This will clear pairing history and enter pairing mode.

[Next](#)

< Back

Back to  
Menu



## 8. Common Errors & Fixes

- **Low volume?**

Place Slumber on the pillow and ensure both the remote and device volumes are at max.

- **Sound quality low?**

Hold the timer button for 5s to switch to Balanced mode.

- **One side not working?**

Ensure the AUX cable and remote are firmly connected.

[More Troubleshooting & FAQ ↗](#)

Next

< Back

Back to  
Menu



## 9. Register Your Product

Register now to:

- Extend warranty to 24 months—FREE.
- Enjoy priority service support.

[Register Now ↗](#)

You're Ready

< Back

Back to  
Menu



## 10. Live Agent Help

We'll respond within **1 business day**

Quick support options:

- Email: [support@avantree.com](mailto:support@avantree.com)
- Schedule callback ↗
- Submit a ticket ↗
- Live chat ↗

< Back

Back to  
Menu



## 11. Rate This Guide

Thanks for choosing Slumber 2!

We hope this guide helped you get started.

Your quick rating helps us improve:



< Back

Back to  
Menu



## 12. Advocate for Us

We've supported hearing-impaired  
customers for **20+** years.

Did we help you? Leave a quick review  
on Amazon to support us!

Select your store:

Amazon US

Amazon UK

## FCC Requirement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.