

MINI Sliding & Standing Bluetooth Keyboard For iPhone 5 User Guide



iPad, iPhone, iPod Touch are trademarks of Apple Inc.



Bluetooth Keyboard Specification and Pairing Instruction

1.0 Keyboard Specification

1. Bluetooth 2.0 interface standard
2. Operating Distance to 10 meters
3. Modulation System: GFSK
4. Operating Voltage: 3.0-5.0V
5. Working Current: <5.0mA
6. Standby Current: 2.5mA
7. Sleeping Current: <200μA
8. Charging Current: ≥100mA
9. Standby Time: 45 days
10. Charging Time: 2-2.5 hours
11. Lithium Battery Capacity: 200mA
12. Uninterrupted Working Time: 30 hours
13. Lithium Battery Life: 3 years
14. Lithium Battery Specifications: 45x16x3mm
15. Key Life: 5 million strokes
16. Operating Temperature: -10 ~ +45℃

2.0 Bluetooth Keyboard Pairing

Step 1: Turn on the power toggle switch. The [power] and [Bluetooth] indicator light will be in 5 seconds, then the light will go off.

Step 2: Press [Link] key for two seconds. The [Bluetooth] indicator light will be blinking, and the [power] indicator will be on. The keyboard is now ready to be connected to iPhone.

Step 3: Turn on and unlock iPhone. Click on the iPhone [settings] icon.



iPhone [setting] icon

Step 4: On the settings menu, select item [General] to access [Bluetooth] settings. Click on [Bluetooth] to turn on the connection. iPhone will automatically search for a Bluetooth-enabled device.



Click to turn on Bluetooth setting

Step 5: Wireless Keyboard found. Click on the device to connect.



Click on the keyboard to connect

Step 6: Enter the password code as displayed on screen.



Enter password code using the wireless keyboard

Step 7: Wireless keyboard connected successfully. [power] indicator light will stay on until the keyboard is switched off.



Keyboard connected successfully

Special Note:

The wireless keyboard can be connected to iPhone4G and iPhone4S that had installed iOS 4.0 or later. For other Bluetooth enabled device, please verify the Bluetooth standard & compatibility before attempting to connect to the keyboard.

3.0 Charging

When the battery power is low, the [power] indicator light will start blinking, it is time to recharge the keyboard.

Step 1: Connect USB-B of the native USB power cable to the keyboard charging interface

Step 2: Connect USB-A to the power adaptor or computer's USB interface

Step 3: The [charge] red indicator light will stay on when the keyboard is charging. Once it is finished charging, the [charge] indicator light will turn off.

4.0 Energy Saving Sleep mode

The keyboard will kick into sleep mode when it is inactive for 15 minutes. To activate from sleep mode, just press any key and wait 3 seconds, the keyboard will come back on.

85mm

5.0 Safety Caution

1. Do not place heavy object on top of the keyboard.
2. Do not Microwave the item.
3. Do not force or distort the keyboard.

6.0 Troubleshooting

(A) Unable to connect

1. Make sure the power switch is on.
2. Make sure the keyboard is within the operating distance.
3. Make sure the battery is charged.
4. Make sure iPad Bluetooth setting is on.
5. Make sure wireless keyboard is connected to iPad.
6. Make sure the wireless keyboard has been paired with the iPad.


(B) Unable to charge keyboard

1. Make sure the USB power cable is connected properly to the keyboard and the power source.
2. Make sure the wall charger is plugged into the power outlet.

7.0 Special keys description



8.0 Product structure diagram



- 1----Power switch
- 2----Link button
- 3----Charge
- 4----Charging indicator
- 5----Power indicator
- 6----Pairing indicator

Note: The light will flash when lack of electricity. Charge light will flash when charging. Charge light will be off when charged fully.

Backlight Note: When it's operating, press **Fn** and **O** together at the same time to turn on / off the backlight function.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
--Reorient or relocate the receiving antenna.

--Increase the separation between the equipment and receiver.

--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help.

Replaceable batteries

If an equipment is provided with a replaceable battery, and if replacement by an incorrect type could result an explosion (for example, with some lithium batteries), the following applies:
-If the battery is placed in an OPERATOR ACCESS AREA, there shall be a marking close to the battery or a statement in both the operating and the servicing instructions;
-If the battery is placed elsewhere in the equipment, there shall be a marking close to the battery or a statement in the servicing instructions.

This marking or statement shall include the following or similar text:

CAUTION:
RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

iPad, iPhone, iPod Touch are trademarks of Apple Inc.

117mm

HUIZHOU CHINFAL ELECTRONIC CO., LTD
YINGFENG INDUSTRIAL PARK SANHE ECONOMIC
DEVELOPMENT ZONE, HUIYANG DISTRICT, HUIZHOU,
CHINA
WWW.Silicon-rubber.com

