

S-KW427B User Manual



Num Lock Bluetooth Connection
Caps Lock Battery Charging
Scroll Lock Battery Low

①

English(US/UK)

Thank you for your purchase of PERIBORAD420 from Perixx. Before installing this product, please make sure your PC has Bluetooth dongle or feature. If your computer is not Bluetooth ready, please contact with your local dealer for the purchase of Bluetooth dongle.

Installation Procedure

1. Open the setup program of your system.
2. Please use "Search New Device" function in the program
3. Press the "Connect" Button of the Keyboard
4. Now you can see the "PERIBORAD420" in the Wireless Keyboard on your Bluetooth dialog.
5. Then double click the Bluetooth Keyboard icon, the system will give you a set of pin-code.
6. Please enter this pin-code on your Bluetooth keyboard directly. (Step 5 & 6 may differ from program to program, the user needs to refer to the system's software manual)
7. The program should show that the connection has been made, and the keyboard is ready to use
8. If the pairing process failed, please make sure your Bluetooth receiver is properly installed with driver.
9. Please then repeat from step 1

Battery Low

Low Battery is indicated by the illumination of the keyboard lens. Please recharge the battery when the LED lights up.

Caution

- The manufacturer and re-sellers are not responsible for any malfunctions, damage, or personal injury incurred by –
 - A misuse of the product.
 - Any attempt to change, change or modify the product in any manner.
- You are cautioned that changes or modifications not expressly approved by the party responsible for the compliance could void your authority to operate the equipment.
- The manufacturer is not responsible for any damage or damage occurring to the equipment, within the guarantee period:
 - Malfunction or damage is due to misuse or incorrect operation or repair,
 - Malfunction or damage caused by the falling after the purchase,
 - Malfunction or damage caused by a fire, salt, gas, earthquake, lighting, wind, water, or other natural calamities, or abnormal voltage,
 - Malfunction or damage is caused by other devices connected to the keyboard.

• All brand names, trademarks and logos are the properties of their respective owners.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

FCC Radiation Exposure Statement The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be collocated or operating in conjunction with any other antenna or transmitter.

This device complies with Part 15 of the FCC rules

Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation

②