

**RC LAMBORGHINI
SUPERLEGGERA 1:64 SCALE**
User's Guide

Please Visit Us @ www.EBExcalibur.com




RC Lamborghini
Superleggera 1:64 scale
Model No.: 9331BK/OR
090209

Model No.: 9331BK/Y/OR

Congratulations on your purchase of EB Excalibur's Lamborghini. Now you can race anywhere with this super-fast, full-function replica of the real Lamborghini. Go in all directions with its smooth, fully-directional steering, and enjoy hours of fun.

Before starting, please read this guide thoroughly, especially noting safety, care and battery information. Keep this guide for reference.

CONTENTS
1 - Lamborghini
1 - Transmitter
1 - User's Guide

BATTERY INSTALLATION - TRANSMITTER	
<ol style="list-style-type: none"> 1. Remove the battery compartment cover by using a small Phillips screwdriver then sliding the cover off. 2. Insert 3 x AA batteries into the compartment, making sure to match the polarity (+ and -) as shown by the diagram inside the compartment. 3. Slide the compartment cover back on and screw in firmly. 	



90-DAY LIMITED WARRANTY

EB EXCALIBUR, INC., warrants to the original consumer that its products are free from any electrical or mechanical defects for a period of 90 DAYS from the date of purchase. If any such defect is discovered within the warranty period, EB EXCALIBUR, INC., will repair or replace the unit free of charge upon receipt of the unit, shipped postage prepaid and insured to the factory address below.

The warranty covers normal consumer use and does not cover damage that occurs in shipment or failure that results from alterations, accident, misuse, abuse, neglect, wear and tear, inadequate maintenance, commercial use, or unreasonable use of the unit. This warranty does not cover cost of repairs made or attempted outside of the factory.

Any applicable implied warranties, including warranties of merchantability and fitness, are hereby limited to 90 DAYS from the date of purchase. Consequential or incidental damages resulting from a breach of any applicable express or implied warranties are hereby excluded. Some states do not allow limitations on the duration of LIMITED 90-DAY WARRANTY implied warranties and do not allow exclusion of incidental or consequential damages, so the above limitations and exclusions in these instances may not apply. The only authorized service center in the United States is:

EB Excalibur, Inc.
Miami, Florida U.S.A.
www.EBExcalibur.com

Ship the unit carefully packed, preferably in the original carton, and send it prepaid, and adequately insured. Include a letter, detailing the complaint and including your daytime telephone number, inside the shipping carton. If your warranty has expired and you want an estimated fee for service, write to the above address, specifying the model and the problem.

NOTE: Please do not send your unit without first receiving an estimate for servicing from EB EXCALIBUR, INC. Contact us before sending your unit. We cannot store your unit!

EB Excalibur, Inc. reserves the right to make technical changes without notice in the interest of progress.

This device complies with Part 15 of the FCC Rules Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC ID: XRB9331OR49RX

FCC ID: XRB9331OR49TX

FCC ID: XRB9331Y27TX

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the User's authority to operate the equipment.

OPERATING YOUR LAMBORGHINI

ANTENNA

Screw in the antenna as shown in the diagram on the previous page.

POWER

Turn the vehicle over and push the Power Switch to the ON position. Place the vehicle down and use the Transmitter to drive it around.

Push up to drive forward or down to drive backwards.

Use the Left & Right Stick to turn the vehicle as you drive in either direction.

RANGE

When the vehicle goes beyond radio signal contact, loss of control or slowness will occur. Extend the transmitting antenna higher for better signal. Make sure the antenna is screwed on tightly.

TRIM


Push up to drive forward. If the vehicle drifts to the right or left without you directing it then you must use the Trim to correct the alignment of the vehicle. Do this until the vehicle drives forward in a straight line.

INTERFERENCE

It is advisable not to use the vehicle close to high tension wires or CB radios. Interference from radio waves may affect the vehicle's performance.

BATTERY INSTALLATION

Turn the vehicle over and use a small Phillips screwdriver to open the battery compartment. Insert 3 x AG13 batteries into the compartment making sure they all face in the same direction.



TROUBLESHOOTING

If the vehicle does not move:

1. Are the battery contacts matched correctly in the transmitter?
2. Are the metal contact tabs in the transmitter touching, rusty or dirty?
3. Are there batteries in the transmitter?
4. Is the power switch on the transmitter turned on?
5. Are the batteries exhausted?

SPECIAL CARE & HANDLING

- Avoid rough handling such as bumping or dropping.
- Avoid moisture and extreme temperatures. For best results, use between the temperatures of 39°F and 100°F (4° C and 38° C) and keep away from fire.
- Avoid using the vehicle for long periods under direct sunlight. Sunlight or excessive heat may damage electronic parts.
- Store the vehicle transmitter in a dry, cool place away from heaters or warm areas.
- Do not use cleaners with chemical agent. Clean using only slightly damp cloth. Then use a dry cloth to wipe off the moisture. Dust, dirt, or other foreign objects can also be removed from your vehicle by using a brush or by tying a small bit of cloth to the tip of a toothpick or tweezers and using that to wipe off your car.

BATTERY & OTHER INFORMATION

- Batteries should be installed or replaced only by an adult. Also wires and plugs should be periodically checked by an adult.
- Install batteries with the correct polarity.
- Your car uses 3 AA alkaline batteries and one 9V battery for the transmitter, not included.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Do not mix old and new batteries.
- Do not use rechargeable batteries.
- Remove exhausted batteries from the unit.
- Take caution when removing leaking or damaged batteries.
- To avoid explosion or leakage, do not dispose of batteries in a fire or attempt to recharge alkaline or other non-rechargeable batteries.
- Leakage may occur if the battery is not used for an extended period of time.
- Dispose of all batteries properly and do not disassemble the batteries.
- Do not short circuit battery terminals.
- Remove batteries and store in a cool, dry place when not in use.

NOTES:
