

**EN - English**

# R/CCARSUSER MANUAL

**WARNING!** - Not suitable for children under 36 months. Small parts. Choking Hazard.  
Remove all packaging before giving this toy to a child. Please read and retain this information for future reference. **CAUTION!** Only for domestic use. To be used under the direct supervision of an adult. Made in China  
FOR ITEM NO.: 28624M/28724M/28824M/29224M/29324M/29524M/29624M/29724M/29824M/29924M/27124M/27224M  
FREQUENCY: 2.4GHz – 10mW Max  
CONTROL DISTANCE: 10M+  
SPEED: 7KM/HOUR

## NOTE:

- For best results use new, high quality, fully charged batteries.
- Parental guidance is recommended when installing or replacing batteries
- Users should keep and retain this information for future reference
- The colour and design of this product may vary from the images


## BATTERY REQUIREMENTS:

1. 3 X 1.5V "AA"/LR6 battery for Vehicle
2. 2 X 1.5V "AA"/LR6 for Transmitter



## FEATURES:

- Package contains: Vehicle, Transmitter and Instruction manual.
- Full Function Radio Control
- Forward/Reverse Driving
- If the car does not drive in straight line adjust the regulating rod under the front of the car to fine-tune the direction.



**Forward/Reverse Driving**



**Regulating Rod**

## DRIVING TIPS

- Point the antenna upward, do not point it down towards the vehicle.
- Do not touch or hold the antenna of transmitter
- Operate vehicle on flat, smooth firm and dry surfaces
- Do not drive your vehicle on sand or through water or snow
- Do not operate near concrete walls which may disturb radio signal transmission.
- Do not operate on public roads

## BATTERY INSTALLATION:

For transmitter and car:

1. Make sure the power switch is on OFF position
2. Open the battery cover at the bottom of the transmitter/vehicle by loosening the screw with a positive/Phillips screwdriver
3. Install the AA BATTERY with the correct polarity (+/-) as shown inside the battery compartment.
4. Close the battery compartment cover and fasten the screw.

## CAUTIONS:

1. Non - rechargeable batteries are not to be recharged
2. Rechargeable batteries are to be removed from toy before being charged
3. Rechargeable batteries are only to be charged by an adult
4. Different types of batteries or new and used batteries are not to be mixed
5. Only batteries of same or equivalent type as recommended are to be used
6. Batteries are to be inserted with correct polarity
7. Exhausted batteries are to be removed from toy
8. The supply terminals are not to be short-circuited
9. Do not mix Old and New batteries
10. Do not mix alkaline and standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries

## PRE-CAUTION AND CARE:

1. Do not crash the RC vehicle into hard objects
2. Operating Range of the transmitter can be affected by various factors:
  - Weak batteries in the vehicle and / or transmitter.
  - To get the best range from transmitter, operate the vehicle outdoors
3. Switch Off the power and remove all batteries from both transmitter and vehicle when not in use.
4. Keep fingers, hair and loose clothing away from the wheels
5. Wipe body with soft cloth
6. Do not use chemicals or water to clean
7. Brush areas where dirt gets trapped.

Disposal Information: The wheelie bin symbol indicates that the product and batteries must not be disposed of as domestic waste. They may contain substances which can be damaging to the environment and health. Please use designated collection points or recycling facilities when disposing of the item or batteries



**6+**

**UK  
CA** | **CE**

## FCC Compliance Statements

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.