


## USER MAUNAL

## Overview:



## Features:

- 2.4GHz wireless, 1200CPI optical technology;
- With CPI switch, between 600/800/1000/1200CPI.
- Hassle-free operation interface, easy to connect to the PC or Laptop by the USB nano dongle.
- 0-10 Meter working range;
- Work with 2pcs AAA alkaline battery;
- USB nano dongle, more convenient when plug in USB.
- 5 buttons, with more function.
- Ergonomic design, more comfortable when using;
- Compact size, easier to carry;
- With power switch, more economical and convenient for power command;
- Install and operate easily;

## Pairing the wireless mouse:

- Step 1. Open the battery's cover (underneath the mouse), place 2 alkaline AAA batteries into the battery slot properly. Take out the USB nano dongle, and close the battery's cover.
- Step 2. Turn on the mouse by switch the **power button** to "No" (underneath the mouse).
- Step 2. Connect the USB nano dongle to your computer's USB port.
- Step 3. Connecting the mouse with its USB nano dongle: Place your wireless mouse close to the nano dongle about 30CM, then press down the **pairing button** (underneath the mouse) and release, the red LED sensor (underneath the mouse) of the mouse will blind and light up . Your mouse will be ready to work.

## Note:

- When you do not need to use your mouse, strong recommend to turn off the mouse by switch the **power button** (underneath the mouse) to "OFF" in order to save power.
- When you need to use your mouse again, turn on the mouse and move it to restart it.
- If your mouse loses synchronisation with your computer, repeat the connecting process.

## Change the speed of your mouse:

(You may press the CPI switch (on the top of the mouse) to change the speed of the mouse between 600 CPI, 800 CPI, 1000 CPI, and 1200 CPI.)

## Mouse Status and Electrical Consumption

- Working: Electrical consumption 9mA.
- Stand-by: (without moving for 30 seconds) Electrical consumption 0.4mA, move the mouse or click on the top button to restart the mouse.
- Sleep: (without moving for 5 minutes) Electrical consumption 0.08mA, move the mouse or click on the top button to restart the mouse.

## Important information:

- FCC radiation declaration:
- 1. This device complies with the FCC regulations on radiation emissions.
- 2. The apparatus should not be placed near a radio antenna or other devices as these may interfere with its use.

## Specification:

- Frequency: 2.4 - 2.48 GHz
- Data Rate: > 700 Kbps
- Tracking Method: Optical (LED)
- Resolution: 1200 cpi
- Power: 2-5VDC
- Max/Min Working Current: 9mA/0.08mA
- Standby status Working Current: 0.4mA
- Sleep status Working Current: 0.08mA
- Dimensions: Mouse: 94 x 63 x 38mm
- Dongle: 18 x 14.5 x 6.5mm
- Weight: 60g (0.13 pounds) with Batteries

## System Requirements:

- Windows 98, Me, 2000, XP, Vista, windows 7, Mac OS 10.2.8 or later.

## FCC ID: Y3PRM-315

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.