


MINI TOWER BLUETOOTH SPEAKER




Instruction Guide
MODEL NO.: KM-BT04

Know your Bluetooth speaker



1. Disconnect Bluetooth
2. Volume+
3. Skip –
4. Volume –
5. Skip +
6. Play/Pause

*****Back of the remote is the battery compartment (Requires 2 x AAA batteries – NOT INCLUDED)



7. Charging indicator light
8. USB DC 5V
9. On / Off button
10. AUX

Using Bluetooth Speaker

- To turn ON, slide the [POWER ON/OFF] switch to the ON position, the LED flashes BLUE 6 times quickly then once every few seconds.
- To turn OFF, slide the [POWER ON/OFF] switch to the OFF position, the LED illuminates and the speaker will power OFF.

Product Specifications

- Dimension
Dimension: L=120 W=120 H=432
- Standard Battery: Built in rechargeable 800mAh Lithium battery
- Charge condition:
Charge time: 3-4 hours
Power input: DC 5V/300mA.

Speaker Specifications

- Diameter: ϕ 90 mm
- Impedance: 4 Ω
- Power output: 3W
- Dbspl: 80 ± 3 dB 1W/M

Wireless function

- Frequency: 2.402-2.480 GHz
- Receiving sensitivity: -82dBm
- Transmission distance: within 10 meters

Package & accessories

- Bluetooth Speaker
- AUX cable
- DC Power
- Instruction manual

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment should
be installed and operated with minimum distance 20cm between
the radiator & your body