





Location of controls



1. [VOL+] button
Quickpress = Next song
Press & Hold = Volume up
2. [MODE] button
Quickpress = Play/Pause/Answer Call/End Call
3. [VOL-] button
Quickpress = Previous song
Press & Hold = Volume down
4. LED indicator light
5. [POWER ON/OFF] switch
6. 3.5 mm Auxiliary Cord input
7. DCSV port / Mini USB charging port
8. Microphone

Inserting the rechargeable battery


1. Open the battery door located on the back of the speaker.
2. Insert the included battery into the compartment. Be sure to align the metal contacts of the battery with the metal contacts inside the battery compartment.
3. Close the battery door.



Charging the Bluetooth Speaker

1. Connect the small end of the Micro USB charging cord into the **DCSV** port on the side of the speaker.
2. Connect the other end of the Micro USB cable to your computer's USB port.
3. The **RED** LED indicator light turns on.
4. The **RED** LED indicator light shuts off when the speaker is fully charged (approximately 4 hours).


i When the battery is running low, the **RED** indicator light turns on.



i Make sure you charge your speaker for 8 hours before using it for the first time. You may use the Bluetooth speaker while charging.


Inserting the Speaker Stand

To stand the speaker, slide the speaker stand attachment into the slot located on the back of the speaker.




FRONT

8. Your Bluetooth enabled device will confirm that the pairing was completed, and prompt you to accept the connection. Please respond **YES** to connect the **Bluetooth Speaker** to your Bluetooth enabled device. If the pairing was successful, the **Bluetooth Speaker**'s indicator light will begin flashing blue every five seconds.



9. When attempting to reconnect the **Bluetooth Speaker** to your Bluetooth enabled device, you may see the message below, and your Bluetooth device will prompt you to accept the connection request to the PBT1000 speaker, and an option not to ask this again. Please accept the connection, and if you select "Don't ask this again", your Bluetooth device will automatically accept future connection requests from your **Bluetooth Speaker**.



6. When the device finds the **Bluetooth Speaker**, confirm by selecting EBT1000 from the list.



Using your Bluetooth Speaker

Powering ON/OFF

- To turn **ON**, slide the **[POWER ON/OFF]** switch to the **ON** position, the LED flashes **BLUE** 6 times quickly then once every few seconds.

- To turn **OFF**, slide the **[POWER ON/OFF]** switch to the **OFF** position, the **RED** LED illuminates and the speaker will power **OFF**.

Answering/Ending a call

- To answer a call quickpress the **[MODE]** button.

- To end a call quickpress the **[MODE]** button.

Adjusting the volume

- Press & HOLD the **[VOL+]** or **[VOL-]** button to adjust the volume to the desired level.

- A beep will be heard when maximum volume is reached.

i You may also adjust the volume from your mobile phone's volume control.

To make a call

Dial the number and press the send button on your mobile phone, the call is automatically transferred to the headset.

Using as a wired speaker

The PBT1000 can be used as a wired speaker by using the included 3.5mm Auxiliary Cord.

1. Plug one end of the Auxiliary Cord into the **AUX** jack on the side of the speaker.
2. Plug the other end of the Auxiliary Cord into the headphone jack of any media device which has a 3.5mm headphone jack (this is standard headphone-out-jack).

3. Use your media device's music controls to control the music. When using the Auxiliary Cord the speaker buttons will not function.

Dialing the last number called

(With devices that have the AVRCP Bluetooth profile)

Quick press the **[MODE]** button twice. The last number called will be dialed.

i Enter passcode "0000" if prompted by the device.

Stereo Bluetooth


This speaker allows you to listen to (in full stereo) and control* the music on your Bluetooth enabled device with the following Bluetooth profiles:

- **A2DP - Advanced Audio Distribution Profile**
- **AVRCP - Audio/Video Remote Control Profile**
- **HSP - Headset Profile**
- **HFP - Handsfree Profile**

To use the speaker to listen/control music, your Bluetooth enabled device must support the A2DP and AVRCP profiles. Please refer to the user guide of your Bluetooth enabled device for more information.

Playing Music

To enjoy wireless music on your Bluetooth Speaker, make sure you are connected to a Bluetooth enabled device. Once connected you can press **PLAY** on your Bluetooth device or you can press the **[MODE]** button on the PBT1000 Bluetooth Speaker. Once playback has begun, you can control the music or answer phone calls from the control buttons of the Bluetooth speaker (with devices that have the AVRCP Bluetooth profile).



7. Select "Pair" to connect the **Bluetooth Speaker** to your bluetooth enabled device.



Using your Bluetooth Speaker

Powering ON/OFF

- To turn **ON**, slide the **[POWER ON/OFF]** switch to the **ON** position, the LED flashes **BLUE** 6 times quickly then once every few seconds.

- To turn **OFF**, slide the **[POWER ON/OFF]** switch to the **OFF** position, the **RED** LED illuminates and the speaker will power **OFF**.

Answering/Ending a call

- To answer a call quickpress the **[MODE]** button.

- To end a call quickpress the **[MODE]** button.

Adjusting the volume

- Press & HOLD the **[VOL+]** or **[VOL-]** button to adjust the volume to the desired level.

- A beep will be heard when maximum volume is reached.

i You may also adjust the volume from your mobile phone's volume control.

To make a call

Dial the number and press the send button on your mobile phone, the call is automatically transferred to the headset.

Using as a wired speaker

The PBT1000 can be used as a wired speaker by using the included 3.5mm Auxiliary Cord.

1. Plug one end of the Auxiliary Cord into the **AUX** jack on the side of the speaker.

2. Plug the other end of the Auxiliary Cord into the headphone jack of any media device which has a 3.5mm headphone jack (this is standard headphone-out-jack).

3. Use your media device's music controls to control the music. When using the Auxiliary Cord the speaker buttons will not function.

Dialing the last number called

(With devices that have the AVRCP Bluetooth profile)

Quick press the **[MODE]** button twice. The last number called will be dialed.

i Enter passcode "0000" if prompted by the device.

FCC and telephone company information

*The Emerson Bluetooth Speaker is compatible with any brand of Bluetooth-enabled phone or music device that supports Advanced Audio Distribution Profile (A2DP) and Audio Video Remote Control Profile (AVRCP).


- **A2DP - Advanced Audio Distribution Profile**
- **AVRCP - Audio/Video Remote Control Profile**
- **HSP - Headset Profile**
- **HFP - Handsfree Profile**

In order for Bluetooth devices to communicate with one another properly, they must utilize the same Bluetooth profile. To determine the profiles supported by your device (mobile phone, gaming console, computer or mp3 player), please refer to the device's user guide.

Troubleshooting tips

i I can pair the Bluetooth Speaker with my Bluetooth device, but I cannot hear any music?

- Make sure your Bluetooth device supports A2DP profile.
- Turn up the volume on your Bluetooth device.



i Most media enabled smart phones will display "Connected to phone audio and media" when connecting to the Bluetooth Speaker. This means you can make phone calls and enjoy your music.

- Make sure your Bluetooth device supports A2DP profile.
- Turn up the volume on your Bluetooth device.

I cannot get the Bluetooth Speaker into Pairing

- Make sure the **Bluetooth Speaker** is turned **OFF** before beginning the pairing process.

- Slide the **[POWER ON/OFF]** switch to the **ON** position, wait for the LED to flash **BLUE** 6 times quickly then quickpress the **[MODE]** button. The **RED** and **BLUE** lights will flash alternately, this will signal that the **Bluetooth Speaker** is in **Pairing Mode**, and ready to connect to your Bluetooth device.

i You may also adjust the volume from your mobile phone's volume control.

Play/Pause*


Press the **[MODE]** button to pause the music. To resume music playback, press the **[MODE]** button again.

Skipping Songs*

(With devices that have AVRCP Bluetooth profile)

Quickpress the **[VOL+]** to go to the next song

Quickpress the **[VOL-]** to go to the previous song.



i Make sure the **[POWER ON/OFF]** is switched to the **OFF** position before beginning the pairing process.

- Slide the **[POWER ON/OFF]** switch to the **ON** position.

- Keep your **Bluetooth Speaker** and Bluetooth enabled device within 3 feet of each other during the pairing process.

- Check that YOUR device's Bluetooth feature is turned **ON**.

- Try repeating the pairing process, see "Pairing the Speaker with a Bluetooth enabled device".



Safety information

- Observe all signs in the designated areas where some electronic devices or RF radio products are required to be switched off. These could include airplanes, hospitals, blasting areas, and potentially explosive atmospheres.

In the unlikely event that this product is defective, or does not perform properly, you may within one year from your original date of purchase return it to the authorized service center for repair or exchange.

TO OBTAIN WARRANTY SERVICE:

- Provide proof of the date of purchase within the package (dated bill of sale).

- Prepay all shipping costs to the authorized service center, and remember to insure your return.

- Include a return shipping address (no P.O. Boxes), a telephone contact number, and the defective unit within the package.

- Do not include parts or accessories that are not defective.

- Do not include parts or accessories that are not defective.

- Do not include parts or accessories that are not defective.

- Do not include parts or accessories that are not defective.

- Do not include parts or accessories that are not defective.

- Do not include parts or accessories that are not defective.

- Do not include parts or accessories that are not defective.

- Do not include parts or accessories that are not defective.

- Do not include parts or accessories that are not defective.

- Do not include parts or accessories that are not defective.

- Do not include parts or accessories that are not defective.

- Do not include parts or accessories that are not defective.

- Do not include parts or accessories that are not defective.

- Do not include parts or accessories that are not defective.

- Do not include parts or accessories that are not defective.

- Do not include parts or accessories that are not defective.
</