Lenovo Vibe K6 NOTE

Quick Start Guide

Lenovo K53b36

Read this guide carefully before using your smartphone.

Reading before using your smartphone

For your safety

Before assembling, charging or using your mobile device for the first time, please read the important product safety and legal information provided with your product. If your mobile device becomes unresponsive, try a reboot—press and hold the On/Off button until the screen goes dark and your device restarts.

Usage

This phone supports apps and services that may use a lot of data, so make sure your data plan meets your needs. Contact your service provider for details. Certain apps and features may not be available in all countries.

Electrical requirements

Battery: 3.85 VCC 15.4 Wh 4000 mAh
Adapter: AC
Entrance: 100 - 240 VAC 50/60 Hz 0.3/0.5 A
Exit: 5.2 VDC 2.0 A

First glance



1 Front-facing camera
2 Receiver
3 Light/Proximity sensor
4 Indicator
5 Volume buttons
6 On/Off button
7 Touch screen
8 Back button
9 Home button
10 Multitask button
11 Headset connector
12 Anti-noise microphone
13 Rear-facing camera
14 Flash
15 Card tray
16 Fingerprint sensor
17 Micro USB connector
18 Microphone
19 Speaker

Installing the Nano-SIM & microSD cards

A Nano-SIM card provided by your carrier is required in order to use cellular services①. A microSD card is required to store data.
Install the Nano-SIM cards and the microSD card as shown②.



Step 1. Insert the eject tool that comes with your smartphone into the hole in the card tray.

Step 2. Pull out the card tray and do one of the following:

- Position a Nano-SIM card in Slot 1 and a microSD card in Slot 2;
- Position a Nano-SIM card in Slot 1 and another Nano-SIM card in Slot 2③.

Step 3. Carefully insert the tray with the installed cards back into the slot.

① Only Nano-SIM cards work with your smartphone.

② Always turn off your smartphone first before you insert or remove a Nano-SIM card. Insert or remove a Nano-SIM card with your smartphone on may damage your Nano-SIM card or smartphone permanently.

③ Both of the card slots support 4G/3G/2G data services, but you can enable only one Nano-SIM card for data connection at a time. If you want to change the Nano-SIM card used for data connection, go to **Settings** > **SIM management**.

Charging the battery

Charge the battery as shown.



Method 1. Connect your smartphone to a power outlet using the cable and USB power adapter that come with your smartphone.

Method 2. Connect your smartphone to a computer using the cable that comes with your smartphone.

Low battery power Fully charged Charging

Turning on or turning off your smartphone



Turn on: Press and hold the On/Off button until the Lenovo logo appears.

Turn off: Press and hold the On/Off button for a few seconds, tap **Power off**, then tap **OK**.

Restart: Press and hold the On/Off button for a few seconds, tap **Restart**, then tap **OK**.

FCC Regulations:

This mobile phone complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
This mobile phone has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

FCC Note:
Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user‘s authority to operate the equipment.

RF Exposure Information (SAR)

This phone is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the United States.

During SAR testing, this device was set to transmit at its highest certified power level in all tested frequency bands, and placed in positions that simulate RF exposure in usage against the head with no separation, and near the body with the separation of 10 mm. Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

The exposure standard for wireless devices employing a unit of measurement is known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg.

This device is complied with SAR for general population /uncontrolled exposure limits in ANSI/IEEE C95.1-1992 and had been tested in accordance with the measurement methods and procedures specified in IEEE1528.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of www.fcc.gov/oet/ea/fccid after searching on FCC ID: YCNK53B3.

For this device, the highest reported SAR value for usage against the head is 0.6 W/kg, for usage near the body is 1.18 W/kg.

While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirements.

SAR compliance for body-worn operation is based on a separation

distance of 10 mm between the unit and the human body. Carry this device at least 10 mm away from your body to ensure RF exposure level compliant or lower to the reported level. To support body-worn operation, choose the belt clips or holsters, which do not contain metallic components, to maintain a separation of 10 mm between this device and your body.
RF exposure compliance with any body-worn accessory, which contains metal, was not tested and certified, and use such body-worn accessory should be avoided.

Copyright and trademarks

Certain features, services and applications are network dependent and may not be available in all areas; additional terms, conditions and/or charges may apply. Contact your service provider for details.
All features, functionality, and other product specifications, as well as the information contained in this guide, are based upon the latest available information and believed to be accurate at the time of printing. Lenovo reserves the right to change or modify any information or specifications without notice or obligation.
Note: The images in this guide are examples only.

Product ID: Lenovo Vibe K6 NOTE (Model Lenovo K53b36)

Technical specifications

System

System: Android

Processor

Processor: Qualcomm MSM 8937, octa-core

Camera

Rear: 16 megapixels
Front: 8 megapixels

Display

Size: 13.97 cm (5.5 inches)
Resolution: 1080 × 1920 pixels
Screen: multi-touch
LCD type: IPS

Wireless communication

Bluetooth: Bluetooth 4.2;
WLAN: WLAN 802.11 b/g/n, 2.4 GHz;
Data: ①FDD-LTE/WCDMA/GSM;
GPS: Supported
GLONASS: Supported

① In some countries, LTE is not supported. To know if your smartphone works with LTE networks in your country, contact your carrier.

Learning more

Getting support

To get support on network service and billing, contact your wireless network operator. To learn how to use your smartphone and view its technical specifications, go to http://support.lenovo.com.

Downloading publications

To obtain the latest smartphone manuals, go to:
http://support.lenovo.com

Accessing your *User Guide*

Your *User Guide* contains detailed information about your smartphone. To access your *User Guide*, go to http://support.lenovo.com and follow the instructions on the screen.

SAR This product meets the applicable national or international RF exposure guidance (SAR guideline) when used normally against your head or, when worn or carried, at a distance of 10 mm from the body. The SAR guideline includes a considerable safety margin designed to assure the safety of all persons, regardless of age and health.

V1.0_20160908

Reduce | Reuse | Recycle

XXXXXXXXXX
Printed in China