

Package contents

- Earbud (L, R)
- Ear tip (S, M, L)
- Wing tip (S/M, M/L)
- Charging case
- Quick start guide


 The items supplied with the device and their images may vary by region.

Accessing more information


Visit www.samsung.com to check device information, the user guide, safety information, and more. You may incur additional charges for accessing the internet.

Device layout

Earbud




Charging case



Insert the earbuds in the charging case and close it. Begin charging by connecting the USB cable to the charger port of the charging case. The batteries of the earbuds and the charging case will be charged simultaneously.

 Use only Samsung-approved chargers.

-  • Chargers are sold separately.
- Keep the charging case closed while you store or charge the earbuds, or when you charge the charging case.
- If you touch the charging contacts while charging the charging case, it may affect charging.
- When not using the earbuds, store them in the charging case that has been charged. If you do not, the earbuds' touch-sensitive sensors will continue to operate and may mistakenly register the earbuds as being worn.

Connecting to a mobile device


Insert the earbuds in the charging case, then close the charging case and open it. When the connection pop-up window appears, follow the mobile device's on-screen instructions to complete the connection.


You can install the Galaxy Wearable app and connect the earbuds to your mobile device by following the on-screen instructions.


 To use all the earbuds' touch actions, open the **Galaxy Wearable** app on your mobile device and tap **Touch controls** to turn on the related features.

Wearing the earbuds

Check the direction of each earbud and insert them into your ears by holding them so that you see the imprinted direction marks. Wear the earbuds until they fit comfortably in your ears.



-  • If your ears or earbuds are wet or have foreign materials on them, or if you have prolonged skin contact with the earbuds, it may result in skin irritation. Make sure that your ears and earbuds are clean and dry before wearing the earbuds.
- If you experience any skin irritation while you are wearing the earbuds, stop wearing them immediately and consult a specialist.

 If the earbuds are not positioned correctly in your ears, features like calling through the earbuds may not work. Use a pair of ear tips that fit your ears and wear the earbuds properly.

Safety information

Read all safety information before using the device to ensure safe and proper use.

Follow the warnings below to prevent incidents, such as fires or explosions, injuries, or damage to the device

- Your device contains magnets. Keep it away from credit cards, implanted medical devices, and other devices that may be affected by magnets. In the case of medical devices, keep your device more than 15 cm apart. Stop using your device if you suspect any interference with your medical device and consult your physician or your medical device manufacturer.
- Do not expose the device or the battery to physical impact or damage.
- Use only Samsung-approved battery, charger, and cable specifically designed for your device.
- Prevent the charger port and charging contacts from coming into contact with foreign materials such as metal, liquids, or dust.

- If any part of the device, such as the glass or acrylic body, is broken, smokes, or emits a burning odor, stop using the device immediately. Use the device again only after it has been repaired at a Samsung Service Centre or an authorised service centre.
- Do not turn on or use the device when the battery compartment is exposed.
- Do not disassemble or reuse the battery.
- The device can be used in locations with an ambient temperature of 0 °C to 35 °C. You can store the device at an ambient temperature of -20 °C to 50 °C. Using or storing the device outside of the recommended temperature ranges may damage the device or reduce the battery's lifespan.



To prevent possible hearing damage when using a headset, do not listen to sound at high volume for long periods.



This marking on the product, accessories or literature and without the bar on batteries indicates that the product, battery and its electronic accessories (such as charger, headset, USB cable) should not be disposed of with other household waste.

PO BOX 12987, DUBLIN. IE

Specific Absorption Rate (SAR) certification information

Your earbuds are designed not to exceed the limits for exposure to radio waves recommended by international guidelines.

SAR value for European countries: The SAR value below is only for devices developed for use in European countries.

Maximum SAR for this model and conditions under which it was recorded

SAR	0.6 W/kg
-----	----------

For SAR values for all other countries: For SAR values specific to your model, visit www.samsung.com/sar and search for your region and device with the model number.

This product includes certain free/open source software. The licence information of the open source software used in this product can be found at opensource.samsung.com.

Copyright © 2025 Samsung Electronics Co., Ltd.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radiofrequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:-Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver,-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help

Samsung Limited Warranty Summary

Samsung Electronics Co., Ltd. ("Samsung") warrants this product against defects in material, design and workmanship to end-users who legally acquire possession of the product ("Customer") during the warranty period (hereinafter, "Warranty Period"), which commences on the original date of purchase of the product from Samsung or any of its authorised distributors. The Warranty Period may vary by country so please refer to Samsung's website in your country or call Samsung contact number. This Warranty will cease to be valid for any defect caused (howsoever) by wear and tear, accident, misuse, neglect, rough handling or abuse. This Warranty will cease to be valid when any alterations or repairs are carried out by unauthorised persons. This Warranty will be subject to the terms and detailed information available at samsung.com/support/warranty.

To receive a Warranty service, contact Samsung customer service or visit a Samsung authorised service centre. Samsung will, at its own discretion, repair any defects, replace the product at no additional charge or fully refund the product price. Available service options may vary depending on the country in which the service is requested and may be limited to the original country of sale. Repair parts or replacement of the product will be furnished on an exchange basis, and will either be new or refurbished to be functionally equivalent to new. All original items replaced in the performance of services shall become the property of Samsung and the new or replacement parts will become the property of the Customer. This Warranty is only valid when the Customer produces the original purchase invoice or receipt for the product (from when the product was first sold to the original Customer) which must not be defaced in any way and must show the purchase date, dealer name, and model name/number.

This Warranty does not affect the Customer's statutory or other legal rights under any applicable law. This Warranty will be the Customer's sole and exclusive remedy unless otherwise stated in the applicable law, which may vary from country to country. This is not an international warranty and is valid only in the country the product is sold by Samsung or by its authorised distributors.

FCC Notice

The device may cause TV or radio interference if used in close proximity to receiving equipment.

The device may cause TV or radio interference if used in close proximity to receiving equipment. The FCC can require you to stop using the mobile device if such interference cannot be eliminated. Information about the RF exposure from FCC In August 1996, the Federal Communications Commission (FCC) of the United States, with its action in Report and Order FCC 96-326, adopted an updated safety standard for human exposure to radio frequency (RF) electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both international and U.S. standards. The design of this tablet complies with FCC guidelines and these international standards.

Body effects

For body operation, this device has been tested and meets FCC RF exposure guidelines when used with any accessory that contains no metal and which provides a minimum separation distance of 0mm between this device and the body of the user. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. Class B Compliance under article 15 of the FCC This device complies with Part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.

Class B Compliance under article 15 of the FCC This device complies with Part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.