TMWatch100

Content

TMWatch100 Bluetooth® Watch	.2
Icons	3
Installation Presentation	. 4
Main features	5
Notes and Unexpected	. 7
FCC Statement	3.

TMWatch100

Bluetooth® Watch

TMWatch100 is an accessory design associated with Android devices (tablet/phone) that provides quick access of user information.


You are notified when you receive a test message. You can mute or reject your phone call, when your phone rings. You can control the music/ Video player on your phone to stop, change tracks and volume.

• Convenience:

(never miss something)

- Never miss a call→Skin-contact alert to incoming call/message.
- Remote controlling host device → Call mute/reject, media playback.
- Automatic data sync→time/date, alarm, schedule.
- Security:
- Protect your device from lost
 - → Distance alert.
- Enhance information privacy
 - →Guest mode activation, Keyless (auto lock/unlock host device)





Icons



Installation presentation

Open TMWatch of BT and BT Discoverable

As follows:

TMWatch: Home → settings
Click on Bluetooth and BT Discoverable,
the right of the light show was turned
into the green.

Note: TMWatch of BT Discoverable is opened, the phone can search TMWatch.

2. Mobile phone paired with TMWatch As follows:

Mobile Phone: menu→ settings→
Wireless & networks→ Bluetooth
settings→ Scan for devices
Search TMWatch, then click TMWatch,
followed by mobile phones and
TMWatch pair is displayed on the screen
asking the window, click YES and Pair,
so on the phone and TMWatch pair on.

3. The mobile phone to connect with TMWatch

As follows:

Mobile Phone: All Applications → TMWatch Applications → menu → connect a device

Phone will pop up on the list of devices to be connected, select TMWatch. After a while on the phone and watch the screen will show the connection window, the prompt window will display automatically disappears after a period of time. Then watch the upper left corner

of the Bluetooth logo and miniature watch designs will be displayed in blue, which represents watches and mobile phones have been connected.



Tap menu icon to apps menu screen



Drag screen right/left to view application items



Tap setting icon to activate setting application



Drag screen up/down to view setting items

Tap check box to select

Main features

1. Music & Video Control

TMWatch: Home → Music Control
Home → Video Control



Tap icon to activate music control application

Music control Play/pause Previous/next



icon to activate video control application

Tap Video Control

Video Control Play/pause Previous/next Fast forward /Rewind

2. Incoming Call & SMS

To connect the phone to send SMS TMWatch, the watch will display the message. (This feature is recommended before the test if it can demonstrate) or through the following steps to view the newsletter:

TMWatch: Home → Notification

SMS font zoom in or out, as follows:

TMWatch: Home→ Notification
Into a one newsletter, long fingers, hold down the TMWatch screen, after a while it pops up a bar, you can slide left and right to adjust the font size of the newsletter.



Calling the phone connected with TMWatch, TMWatch call is displayed on the window, this window on the "reject" and "Mute" buttons.



3. Anti-lost

When the phone watch some distance away (Bluetooth can control the distance), the watch will be issued a cell phone lost alarm.

This feature can be manually disconnect the phone and watch the connection to demonstrate:

All Applications → TMWatch
Applications → menu → disconnect a
device

And then manually connect the watch and mobile phone:

All Applications → TMWatch
Applications → menu→ connect a
device



4. Guest Mode

As follows:

TMWatch: Home → Guest Mode
Guest Mode by clicking on the icon to
open and close the Guest Mode
function. When the Guest Mode opens
the phone is limited on some of the
features will not be used, for example,
SMS cannot be viewed or cannot
remove the application. When the
Guest Mode is turned off the restore
function to those prohibited use.



5. **Keyless**

As follows:

TMWatch: Home-> keyless
By clicking on the icon to open and close
the keyless keyless function. When the
keyless opened the phone wakes up
from hibernation or does not require a
password can unlock the phone
directly. When the keyless turned off the
phone to wake from sleep or when you
must enter the password to unlock the
phone.





Notes and unexpected

circumstances

 Before the presentation please turn off the phone WIFI, when the phone WIFI open, TMWatch and mobile phone easily disconnected.

As follows:

Phone: menu→settings→ Wireless & networks→ Wi-Fi

 If TMWatch and phone suddenly disconnected or TMWatch cannot control your phone, by following two steps to resolve:

a: first manually disconnect TMWatch connected to the phone, then cancel TMWatch paired with the phone, re-pairing and connection. At this point TMWatch of BT Discoverable has been closed, be reopened in order to be mobile phones to scan, and because the phone is connected on each TMWatch and after, TMWatch the BT Discoverable will be automatically closed.

b: steps do not solve the problem in a case, disconnect and cancel the pairing in the need to enter the phone after the application management TMWatch clear the data and forced to stop the program and then restart the phone and TMWatch, and then re-pair and connection. Clear data and forced to stop as follows:

Phone: menu→ settings→

Applications → Manage applications → TMWatch

Click Clear data → OK, then click Force stop, and finally restart the phone.

FCC statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced

radio/TV technician for help.

Important: Changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.